


STEP 4




4. Turn the Cylinder Valve (21) on the tank in a clockwise direction to **TURN OFF SUPPLY** of the LP Gas supply .

Attach the preassembled Regulator (12/19) from the Fire Table / Column to the Cylinder Valve (21) by turning the Black Regulator Coupling Nut (20) clockwise.


Make sure it is fastened securely and tighten connections - by **HAND** only.

STEP 5



5. Replace and Close the Door (D) back to the Mainframe of the Fire Table / Column (C).

STEP 6




6. Remove the Electronic Ignitor Cap (14) on the electronic Ignitor (14) by unscrewing and slide the Battery (B) into the battery slot (14).

Make sure the positive side of the Battery(B) faces outwards.

Screw the Electronic Ignitor Cap (14) over the battery, tightly.

STEP 7




Subject to your preference, you may pour Lava Rocks over the Burer Ring. The Guard **MUST NOT BE BLOCKED**. Refer to guidance below :

Note : Do not place more than 1/4 inch depth of lava rocks above the burner holes. Doing so will suffocate the flame.


Note : Do not place more than 4KG of lava rocks above the burner holes. Doing so will suffocate the flame.




WARNING



Guard
DO NOT PLACE LAVA ROCKS
ON THE GUARD. KEEP
GUARD CLEAR .





CORRECT



INCORRECT

To ensure proper function, the Guard (01) on the Burner (08) should never have lava rocks (A) covered over it.

Part J.	SAFETY INFORMATION - OPERATIONS
<p>Before performing a leak test, be sure:</p> <ol style="list-style-type: none">1.) DO NOT press the Ignitor .2.) You are in a spacious outdoor area. <p>Connect the Propane Gas tank to the Regulator (12/19) and turn the Valve (22) on the unit to the “OFF” position.</p> <p>Brush soap and water mixture onto all connections.</p> <p>Turn the gas supply on;if extra large bubbles form on any connection there may be a leak. If you smell gas or a leak is discovered, IMMEDIATELY turn the gas valve off, disconnect Propane Gas tank.</p> <p>Do not use the appliance until the leak is repaired</p>	
<p>The Fire Table / Column has a Door. Remove the Door and leave the Door on the floor. Inspect the Gas Hose (12) before use the Fire Table / Column.</p> <p>If there are signs of wear or abrasion on the hose, you must replace the Gas Hose (12).And the Gas Hose must be supplied directly by manufacturer.</p> <p>Lava rocks could pop up and strike somebody’s face during the process of lighting this unit.</p> <p>Stand away from the Fire Table / Column for the initial 30 minutes after igniting.</p>	
 <div data-bbox="488 1144 790 1234">2 inches to 10 inches.</div>	<p>Observe flame colour and flame height when the Fire Table/Column after being lit :</p> <ol style="list-style-type: none">1.) Flame color should be yellow / blue.2.) Flame height burns at 2 - 10 inches high.
<p>Wait 10 minutes after extinguishing flame prior to replacing a lid (if applicable) or protective cover onto the Fire Table / Column.</p>	

Part K.	SAFETY INFORMATION USING YOUR FIRE TABLE / COLUMN
<p>Before each use, inspect the Gas Hose (12). Replace Gas Hose(12) if there are any signs of cutting, wear or abrasion.</p> <p>Before you light your Fire Table / Column, please proceed / adopt the following steps :</p> <ol style="list-style-type: none">1. Make sure the Control Knob (13) is in the “OFF” position.2. Open the Door (07) and slowly open the Valve (22) on the Propane Gas Tank by turning the Contol Knob (13) counterclockwise.3. Close the Door (07) on the Main Frame (06) of the Fire Table / Column.4. Push and hold in the Electronic Ignitor (14) to create sparks within the electrode continue to hold.5. Push in the Control Knob (13) and turn to the “LOW” position. Keep holding down the Control Knob (13) to allow gas to flow for 15 seconds.6. If ignition doesn’t occur within a few seconds release the Control Knob (13) and rotate to the “OFF” position. Wait for 5 minutes for gas to clear and then repeat the above lighting instructions.7. Once the Fire Table / Column is lit, the flame intensity may be controlled by turning the Control Knob (13) between the “LOW” and “HIGH” positions.	
 <p>2 inches to 10 inches.</p>	<ol style="list-style-type: none">8. Observe flame height when lit:8.1.) Flame color should be yellow / blue.8.2.) Flame height burns at 2 - 10 inches high.

Part L.	SAFETY INFORMATION : TO SHUT DOWN YOUR FIRE TABLE / COLUMN
To Shut Down your Fire Table / Column, please proceed / adopt the following steps :	
1. Turn Control Knob (13) clockwise to the “OFF” position.	
2. Close the Cylinder Valve (21) on the Propane Gas tank if you DO NOT intend to use it for a long time.	
Part M.	MAINTENANCE - FIRE TABLE / COLUMN
<ul style="list-style-type: none">• Before performing any maintenance work, ensure the Control Knob (13) is in the "OFF" position and always disconnect Propane Gas tank.• Keep the Fire Table / Column free and clear from all combustible materials.• Visually inspect Burner (08) for obstructions and keep tank enclosure free and clear from debris.• Use a soft brush to get rid of the mild stains, loose dirt and soil after the burner and lava rocks are completely cooled down. Wipe down with a soft cloth.• Harsh weather conditions may cause stubborn stains, discoloration and possibly rust pitting.• Permanent damage may occur if powder or solvent comes in contact with painted or plastic components on this Fire Table / Column.• Keep the Fire Table / Column stored away from direct sunlight.• If storing this unit inside, disconnect the Propane Gas tank from the Gas Valve (22) . Leave the gas tank outside of your premises.• Not using manufacturer approved or supplied parts/accessories may result in a defective condition and shall void the warranty of this Fire Table / Column.• Before performing any maintenance work, always: 1) ensure Control Knob (13) is in 'OFF' position 2) disconnect Propane Gas tank• Keep the Fire Table / Column free and clear from all combustible materials.• Visually inspect Burner (08) for obstructions and keep tank enclosure free and clear from debris.• Place Lid (if applicable) and Protective Cover (E) on the Fire Table / Column when not in use.	

Part N.	MAINTENANCE : FIRE TABLE / COLUMN SURFACE CARE
<ul style="list-style-type: none">• Our Table / Column Fire Table material has been sealed with a treatment that prevents staining and moisture absorption, and for product longevity this Fire Table / Column would still require proper care and maintenance to ensure the integrity of the surface.	
<ul style="list-style-type: none">• Please see below for recommendations on maintaining your Fire Table / Column surface for years of extended use:	
<ul style="list-style-type: none">• Clean any spills immediately to prevent permanent surface(s) staining or damage to your Fire Table / Column. <p>Blot any liquid spills with a clean, dry cloth to avoid spreading of the spill to the rest of the table.</p> <p>Immediate cleaning of stains / blotting of spills also prevents absorption of such stains / spills into the surfaces, compared to if such stains / spills are left for extended periods on these surfaces.</p>	
<ul style="list-style-type: none">• How to Clean your Fire Table / Column surface(s) : <p>Mix a mild dish soap into warm clean water, use a soft, clean cloth or sponge.. Then proceed to remove surface dirt, stains or mild spills. Rinse all soap solution off from the surfaces with a damp cloth. Dry off completely with a dry cloth to avoid water spots / water marks. Regularly cleaning the Fire Table / Column surface will aid in a longer lasting product.</p>	
<ul style="list-style-type: none">• DO NOT use petroleum-based or abrasive cleaning products. <p>DO NOT use any harsh brushes / rough sponges when cleaning the Fire Table / Column surface(s).</p>	
<ul style="list-style-type: none">• DO NOT slide products across the Fire Table / Column surface(s) to avoid permanent scratching and or damage(s).	
<ul style="list-style-type: none">• DO NOT place any food on the surface(s) of the Fire Table / Column. <p>DO NOT eat from the surface(s) of the Fire Table / Column surface.</p>	
<ul style="list-style-type: none">• Fire Table / Column surface must be covered at all times when not in use. <p>Cover your product with an outdoor Protective Cover(E) when not in use to protect it from the elements.</p> <p>Store your product indoors during winter months, leave the gas tank outside.</p> <p>Avoiding extreme cold temperatures, as extreme cold temperatures may cause cracking of the tabletop.</p>	

Part O.	TROUBLE SHOOTING	
Herebelow is a simple guide on frequently asked questions / frequently occurring issues.		
Read through carefully and execute accordingly and adequately.		
Whenever you are uncertain, please contact Qualified Technician Services and/or Fire Department.		
Problem	Cause	Solution
Fire Pit / Fire Table / Column DOES NOT light up.	Ignitor pin (04) and Burner (08) are wet	Dry off with a soft cloth
	Ignitor Battery (B) is incorrectly inserted	Check which direction the battery is inserted OR battery needs to be replaced
	Ignitor Pin (04) is broken	Contact Manufacturer for a replacement part
	Ground Wire (03) is loose or disconnected	Reconnect wire to the ignitor box located inside the table behind the ignitor box
	Ground Wire (03) is shorting between Valve and Ignitor Pin(04)	Contact Manufacturer for a replacement part
Burner DOES NOT light while using a match	No Gas flow	Check that the Gas tank isn't empty
	Regulator(12/19) isn't connected securely to the tank	Tighten Regulator connection to the Gas tank
	Gas flow is obstructed	Check all hoses (12) for kinks and bends.
	Burner holes are clogged	Turn all gas flow connections OFF. Insert an opened paperclip (or similar item) into each of the burner ports to clear them out.
Heater unit emits a lot of black smoke	Flame is obstructed at burner holes	Check that all Burner holes are free of any small lava rocks.
	Regulator(12) hose is kinked	Straighten Hose (12) of all bends or kinks.
Sudden drop in gas flow	No Gas flow	Check that the Gas tank isn't empty.
	Excess flow Safety Valve(11) has been activated	Turn the Control Knob(13) to the 'OFF' position. Close the Tank Valve and disconnect Propane gas tank. Turn the Control Knob(13) to 'HIGH'; wait 1 minute. Turn the Control Knob (13) back to the 'OFF' position. Reconnect Propane gas tank. Light the fire unit as indicated in the 'To Light' section of this manual.
Flame blows out easily	High or gusting winds	Increase flame to 'HIGH'
	No gas flow	Check that the gas tank isn't empty
	Excess flow safety valve has been activated	See 'Sudden drop in gas flow' above

Part P.	WARRANTY
<p>The manufacturer warranty shall be voided, and manufacturer disclaims any responsibility for the following actions whereby the Customer / Consumer / Owner has :</p> <ul style="list-style-type: none">• Made modification(s) to the unit and / or components including the Gas Valve assembly. The Owner shall contact the Local Supplier and Quaified Service Person to repair these parts.• Use any component part / change to parts that are NOT manufactured or approved by manufacturer• Use and installation other than what is listed in this Owner's Manual. <p>Please contact the manufacturer for replacement parts.</p>	
Part Q.	CONTACT
<p>If you have any questions or concerns, our Trained Staff are ready to assist you. Contact: 1-818-435-3985 Monday-Friday 8 a.m. to 5 p.m. PST</p>	