



ASSEMBLY INSTRUCTIONS

60" DINING TABLE


- | | | |
|--------------------|--------------------|---------------------------------------|
| A Table Top | B Table Leg | C Flat Washer
Ø5/16" x 3/4" |
|--------------------|--------------------|---------------------------------------|



1 pc




4 pcs




8 pcs

- | |
|--|
| D Lock Washer
Ø5/16" x 9/16" |
|--|




8 pcs

- | |
|-----------------------------------|
| E Hex Nut
Ø5/16" x 1/2" |
|-----------------------------------|




8 pcs

- | |
|-------------------------|
| F Wrench
1/2" |
|-------------------------|




1 pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

- 1** Remove the protective panels from the Table Top (A) using a screwdriver (not provided).



- 2** Place the Table Top (A) upside down on a floor with a piece of cloth or carpet underneath to prevent from scratching. Attach the Table Leg (B) to the Table Top (A) using Flat Washer (C), Lock Washer (D) and Hex Nut (E) with the Wrench (F). Do not fully tighten until all hardware is attached.






Cleaning & Care :

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTION

PARSON CHAIR

A Chair Back	B Seat	C Front Leg	D Lock Washer M8x13mm
			
1pc	1pc	2pcs	9pcs
E Flat Washer M8x19mm	F Bolt M8x80mm	G Bolt M8x60mm	H Bolt M8x45mm
			
9pcs	4pcs	4pcs	1pc
I Allen Key M5	J Wood Dowel Ø10x30mm		
			
1pc	2pcs		






This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

ASSEMBLY INSTRUCTIONS

47"W BENCH

- | | | |
|--------------------|--------------------|---------------------------------------|
| A Bench Top | B Bench Leg | C Flat Washer
Ø5/16" x 3/4" |
|--------------------|--------------------|---------------------------------------|



1 pc




4 pcs

8 pcs

- | |
|--|
| D Lock Washer
Ø5/16" x 9/16" |
|--|

- | |
|-----------------------------------|
| E Hex Nut
Ø5/16" x 1/2" |
|-----------------------------------|


- | |
|-------------------------|
| F Wrench
1/2" |
|-------------------------|



8 pcs

8 pcs


1 pc



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

1

Place the Bench Top (A) upside down on a floor with a piece of cloth or carpet underneath to prevent from scratching. Attach the Bench Leg (B) to the Bench Top (A) using Flat Washer (C), Lock Washer (D) and Hex Nut (E) with the Wrench (F). Do not fully tighten until all hardware is attached.



Cleaning & Care :

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.