

迷你款说明书数量10000PCS

65MM

Alarm clock Operation Instructions

I. Brief Introduction to Functions

1. Normal time mode

Under normal mode, time, date(from 2000 to 2099), week, temperature can be displayed and 12-hour system can be mutual-shifted to 24-hour system. The default time is January 1, 2008 after startup.

2. Daily alarm clock and snooze mode

Under alarm clock mode, daily alarm time can be set and alarm music(a total of 9 songs) can be selected, meanwhile, snooze function can be opened.

3. Birthday reminder mode

The specific time and date of birthday reminder can be set. When the time is up, birthday songs will play to bless you.

4. Timer mode

Under timer mode, reverse-timing can be set: Timing range is between 23:59 and 00:00. When time is up, there will be alarm prompt.

5. Temperature mode

Environmental temperature can be detected automatically. Under normal state, centigrade can be mutual-shifted to fahrenheit by pressing Set key.

6. Music appreciation mode

Under normal state, the music appreciation log can be closed by pressing ▼ key.

7. Backlight mode

Under normal state, backlight can be opened for 5 seconds by pressing LIGHT key.

II. Description of key functions

Operate with 5 keys: MODE, SET, UP, DOWN, LIGHT

III. Operational approach

1. Start up to enter "normal display state" and play 1 song.

2. Under normal state, press the MODE key in the following order to enter its corresponding functional mode:

Normal state→12Hr/24Hr shift → alarm condition → birthday reminder state → timing state → normal state

3. Under normal state, when the alarm logo is opened, the snooze log can be open/closed by pressing ▲ key.

4. Under normal state, the music appreciation log can be open/closed by pressing ▼ key. When the logo is opened, 7 popular songs of different styles can be in loop playback.

5. Under normal state, centigrade can be mutual-shifted to fahrenheit by pressing SET key.

6. Under 12Hr/24Hr sate, 12-hour system can be mutual-shifted to 24-hour system by pressing ▲ and ▼ key.

7. Under alarm clock state, there will be alarm log displayed, and alarm time can be set by pressing SET key with ▲ and ▼ key, by which the alarm music can also be selected, there are a total of world-known classics and 2 different "beep" sound for your option; Alarm clock can be closed by pressing SET key again. When the alarm time you set is up, the alarm will ring for 1 minute. If the snooze function is opened, the alarm will ring once every 3 minutes for a total of 4 times.

8. Under birthday reminder state, there will be reminder logo displayed, the date and time of birthday reminder can be adjusted by pressing SET key with ▲ and ▼ key and the birthday reminder function can be closed by pressing SET key again. When the time of birthday reminder set is up, The birthday song will be played for 5 minutes to bless your birthday.

9. Under the timer state, there will be count down logo displayed, the reverse-timing time can be set by pressing SET key. The timing range is between 23:59 and 00:00 00. When the setting time of "0:00 00" is up, the alarm will ring for 1 minute while "0:00 00" will flash constantly.

10. Under normal state, backlight can be opened for 5 seconds by pressing LIGHT key.

11. For above various state, if the key was not pressed for continuous 1 minute, normal display state will be returned.

IV. Mode introduction

1. Normal time mod

During startup, the normal time display is 12:00.

1.1 12Hr / 24Hr mode conversion:

Under normal state, press MODE key for one or enter shift mode between 12Hr System and 24Hr system, and revision can be made by ▲ and ▼ key.

1.2 Time setting:

Under normal state, press Mode key for one to enter 12Hr/24Hr state, press SET key to set time and date and set hour, minute, year, month, day and so on respectively according to following order, and complete the setup in combination with pressing UP/DOWN key.

Hour → Minute → Year → Month → Day → Exit

◆ Setting range: Year ranges from 2000 to 2099, month ranges from January to December, day ranges from 1 to 31, hour ranges from 1 to 12 or from 0-23, minute ranges from 0 to 59.

◆When adjusting hour or minutes, seconds will be automatically reset.
◆While setting date, week(from Monday to Sunday) will automatically changed correspondingly.
◆When setting state, if the key is not pressed for continuous 1 minute, the setting will be automatically exited, and the time and date set currently will be displayed.

2. Alarm clock and snooze mode

Under normal state, press MODE key for twice to enter alarm mode:

2.1 Alarm clock setting:

Under clock mode, press SET key to enter alarm setting and set hour, minute, music according to following order and complete setup in combination with pressing ▲ and ▼ key.

Hour → Minute → Music → Exit → Close

◆If only the alarm is opened while snooze is not opened, when the setting time is up, the alarm will ring for 1 minute. The ring can be stopped by pressing any key. If snooze is opened, the alarm will ring for once every 3 minutes, 1 minute every time for a total of 4 times.

◆During snooze and alarm, press any key to stop ringing but the snooze logo still flashes, until the forth time, the ring will stop or be canceled.

◆During alarm without snooze, press MODE key to cancel this snooze function(i.e. the logo stops flashing.); And the snooze log can be closed by pressing ▲ key.

◆When both the alarm and snooze logo were not opened, the alarm and snooze function can be closed simultaneously. Only when the alarm logo is opened, the snooze function will work.

3. Birthday reminder mode

Under normal state,press MODE key for three to enter birthday reminder mode .

3.1 Birthday reminder setting:

Under birthday reminder state, press SET key to set date and time, and complete the setting in combination with pressing ▲ and ▼ key and set respectively according to the following order:

Hour → Minute → Year → Month → Exit → Close

When the time of birthday reminder set is up, the birthday song will be played for 5 minutes to bless your birthday.

◆Under setting state, if the key is not pressed for continuous 1 minute, the setting will be automatically exited, and the time and date set currently will be displayed.

4. Timer mode

Under normal state, press MODE key for four to enter timer mode .

4.1 Timer setting:

Under timer state, press SET key to enter setting and set hour, minute respectively according to following order and complete the setting in combination with pressing ▲ and ▼ key.

Hour setting → Minute setting → Start counting → Close

◆Setting range: Hour range is between 0 to 23, minute range is between 0 and 59.

◆Start timing: In the position where "DATE" is displayed, the number of seconds varies from 00 to 59(in a cycled decrease), and the number of minutes set currently begins to decrease, and the number of hours set also begins to decrease.

◆Under the setting state, if the key is not pressed for continuous 1 minute, the setting will be exited automatically and timing begins.

◆When the alarm reaches 0: 00, the alarm will ring for 1 minute. If it is currently in the TIMER state, the 0:00 00 displayed on the screen will keep flashing when the alarm is ringing.

5. Temperature mode

Displaying temperature of current environment, under normal state, press SET key to mutual-shift from centigrade to fahrenheit.

6. Music appreciation mode

Under normal state, music logo can be opened or closed by pressing ▲ key. When the music logo is opened, 7 popular songs can be played in a loop playback.

7. Backlight mode

Under normal state, backlight can be opened for 5 seconds by pressing LIGHT key.

V. Product Parameters

品名:	闹钟	供电方式:	AAA*2
Product name:	Alarm clock	Power supply mode:	
型号:	BS-02	执行标准:	GB/T 22779-2017
Model:		Executive standard:	
专利号:	202030210859.1		
Patent No.:			

VII. Precautions:

- Open cell cover, put 2 AAA batteries correctly according to indications on the bottom of battery jar. Please note that new battery cannot be mixed with old batteries.
- If there are any abnormalities or faults in the machine, please re-install battery.
- Please do not place the product in a wet place.
- Soft cloth or paper can be used to clean alarm, please do not use corrosive liquid or liquid with chemical component to wipe the surface of the product.
- When the alarm is not in use, please do not install battery in it, and you need to pack it in a original packing box.
- Before discarding the product, the battery must be removed from the product. Open the back cover and then remove the battery.
- When taking out the battery, the product must be powered off.
- The battery should be disposed in a safe manner.

闹钟使用说明书

一、功能简介

1. 正常时间模式

正常时间模式显示时间、日期（2000 年至 2099 年）、星期、温度，并可实现 12/24 小时制的转换。开机默认时间为 2008 年 1 月 1 日。

2. 每日闹钟和贪睡模式

闹钟模式可设置日常闹钟时间和选取闹铃音乐（共 9 首），同时还可开启贪睡功能。

3. 生日提醒模式

可设置生日提醒的具体时间、日期,到点会有生日歌曲播出，以示祝福。

4. 计时器模式

计时器模式可设置反向计时;计时范围 23:59-00:00 小时，当时间到达时,会响闹提示。

5 温度模式

自动检测环境温度，在正常状态，按 Set 键可实现摄氏/华氏温度的转换。

6 音乐欣赏模式

在正常状态，按▼键可开启或关闭音乐欣赏。

7.背光模式

在正常状态，按 LIGHT 键可开启背光 5 秒钟。

二、按键功能说明

采用 5 个按键操作:MODE、SET、UP、DOWN、LIGHT

三、操作方法

1.开机，进入“正常显示状态”，并播放 1 首音乐。

2.在正常状态，按 MODE 键以下顺序进入其相应功能模式：

正常状态→12Hr/24Hr 转换→闹钟状态→生日提醒状态→计时状态→正常状态

3.在正常状态，当闹铃标志开启时，按▲键可开启/或关闭贪睡标志。

4.在正常状态，按▼键可开启或关闭音乐欣赏标志。当标志打开时则循环播放 7 首不同的流行歌曲。

5.在正常状态，按 SET 键可实现摄氏/华氏温度的转换。

6.在 12Hr/24Hr 状态,通过▲▼键可进行 12/24 小时制的转换。

7.在闹钟状态下,有闹铃标志显示，按 SET 键配合▲▼键可进行闹铃时间的设置，和闹铃音乐的选取，共有 7 首世界名曲及 2 个不同的“喵喵”声可供选择；再按 SET 键可关闭闹钟。

当设置的闹铃时间到达时，响闹 1 分钟。如有开启贪睡功能时，则每 3 分钟响闹 1 次，共响 4 次。

8.在生日提醒状态，有提醒标志显示，按 SET 键配合▲▼键可对生日提醒的日期、时间进行调整，再按 SET 键可以关闭生日提醒功能。当生日提醒所设置的时间到达时，播放生日歌曲 5 分钟以祝福生日 HAPPY！

9.在计时器状态，有倒计时标志显示，按 SET 键配合可设置反向计时的时间；计时范围 23:59-00: 00 小时。当设置时间到达“0：00 00”时,会响闹提示 1 分钟，同时“0：00 00”不停地闪烁。

10.在正常状态下，按 LIGHT 键可开启背光 5 秒钟。

11.在以上各种状态，如果无按键 1 分钟，则自动返回正常显示状态。

四、模式介绍

1、正常时间模式

开机时，正常时间显示为 12:00。

1.1 12/24 模式转换：

在正常状态，按 MODE 键1次 或进入 12Hr /24Hr 制的转换模式，通过▲▼键进行修改。

1.2 时间设置：

在正常状态，按 Mode 键1次进入 12Hr/24Hr 状态,按 SET 键进入时间、日期的设置，并以下列顺序分别设置小时、分钟、年、月、日等，通过 UP/DOWN 键配合来完成其设置。

时→分→年→月→日→退出

◆设定范围：年为 2000-2099、月为 1-12、日为 1-31、时为 1-12 或 0-23、分为 0-59。

◆在调整小时或分钟时，秒自动清零。

◆在日期设置的同时，星期（由 MON 至 SUN）相应地自动改变。

◆在设置状态，如果无按键 1 分钟则自动退出设置，并显示当前所设置的时间、日期。

2.闹钟和贪睡模式

在正常状态，按 MODE 键 2次，进入闹钟模式。

2.1 闹钟设置：

在闹钟模式，按 SET 键进入闹钟设置，并以下列顺序分别设置小时、分钟、音乐,通过▲▼键配合来完成其设置。

小时→分钟→音乐→退出→关闭

◆如果只开启闹钟，而未开启贪睡，则当市套到达设定时间时，响闹 1 分钟。按任意键停止响闹。如果已开启贪睡，则每 3 分钟响闹 1 次，每次 1 分钟，共响 4 次。

◆在贪睡响闹时，按任意键停止响闹，但贪睡标志仍然闪烁，直至 4 次响闹结束或被取消。

◆在非贪睡响闹时，按 MODE 键取消本次贪睡功能（即标志停止闪烁）；而按▲键则关闭贪睡标志。

◆当闹铃及贪睡的标志均未开启时，闹铃和贪睡同时关闭。只有在闹铃标志开启时，贪睡功能才有效。

3.生日提醒模式

在正常状态，按 MODE 键3次可进入生日提醒模式。

3.1 生日提醒设置：

在生日提醒状态，按 SET 键进入日期和时间的设置，通过▲▼键配合来完成其设置，并以下列顺序分别设置：

时→分→年→月→退出→关闭

当生日提醒所设置的时间到达时，播放生日歌曲 5 分钟以祝福生日 HAPPY！

◆在设置状态，如果无按键 1 分钟则自动退出设置，并显示当前所设置的时间、日期。

4.计时器模式

在正常状态，按 MODE 键4次可进入计时器模式。

4.1 计时器设置：

在计时器状态，按 SET 键进入设置,并以下列顺序分别设置小时、分钟，通过▲▼键配合来完成其设置。

时设置→分设置→开始计时→关闭

◆设定范围：小时为 0-23、分钟 0-59。

◆当开始倒计时时，原本显示“DATE”的位置会变为时间显示；秒数从59开始逐秒减少至00并循环，同时预设的分钟数会逐步递减；当分钟数减至0时，预设的小时数也会相应减少，形成完整的时间倒计时显示。

◆在设置状态，如果无按键 1 分钟则自动退出设置并回到时间显示状态，并开始计时。

◆当计时到达 0:00 时会响闹提示 1 分钟，如果当前在 TIMER 状态，响闹的时屏幕上显示的 0：00，00 会不停地闪烁。

5.温度模式

显示当前环境的温度，在正常状态，按 SET 键进行摄氏/华氏温度的转化。

6.音乐欣赏模式

在正常状态，按▲键可打开或关闭音乐标志。在音乐标志开启时，可循环播放 7 首不同的流行音乐。

7. 背光模式

在正常状态，按 LIGHT 键可开启背光 5 秒钟。

五、产品参数

品名:	闹钟	供电方式:	AAA*2
Product name:	Alarm clock	Power supply mode:	
型号:	BS-02	执行标准:	GB/T 22779-2017
Model:		Executive standard:	
专利号:	202030210859.1		
Patent No.:			

七、注意事项:

- 打开电池盖，按电池槽底部的标示正确的放入二节 AAA 电池，注意不要混装新旧电池。
- 如本机发生任何异常或故障，请重新安装电池。
- 请勿将本品置于潮湿的地方。
- 可用柔軟的布片或纸巾清洗闹钟，请勿使用具有腐蚀性或有化学成分液体擦洗本品表面。
- 当闹钟不使用时请不要装电池并用原始包装装好。
- 在废弃器具前，必须将电池从器具中取出。打开后盖，然后就可以取出电池。
- 在取出电池时，器具必须要断电。
- 电池应安全的处置。