

**Features:**

- Mirror LED alarm clock with colored display
- 12-hour or 24-hour time format
- Alarm with 5-minute snooze and adjustable alarm volume
- 3 brightness levels available
- 12 display colors available, along with rotating color display options
- Power options: 3 AAA batteries or 5.0V USB cable

**IMPORTANT OPERATIONAL NOTE:**

- This clock runs on three AAA batteries, but does require the USB to be plugged in AT ALL TIMES in order to permanently display the time.
- When the USB is not plugged in and the clock is solely relying on battery power, the display reading will disappear, requiring you to tap on the top of the clock or press any of the buttons on the back of the clock for the display to reappear.

**Setting the Date and Time:**

- Press and hold the MODE button
- When the display begins flashing, use the UP or DOWN button to select the current year
- Press MODE again to select the current month of the year using the UP or DOWN button
- Press MODE again to select the current day of the month using the UP or DOWN button
- Press MODE again to select between 12-hour and 24-hour format using the UP or DOWN button
- Press MODE again to select the hour using the UP or DOWN button
- Note that "PM" will appear on the display for PM hours; for AM hours continue to press the UP or DOWN button to reach the correct hour
- Press MODE again to select the minute using the UP or DOWN button
- Press MODE again to exit the time-setting function
- Once the correct date and time have been programmed, you can view the year by pressing MODE once. The year will display for 5 seconds and then return to the time.
- Once the correct date and time have been programmed, you can view the date by pressing MODE twice. The date will display for 5 seconds and then return to the time.

**Setting the Alarm Time:**

- Press and hold the ALARM button
- The display will begin to flash with the alarm hour, press UP or DOWN to adjust the alarm hour
- Press ALARM again to adjust the alarm minute, which you can adjust by pressing the UP or DOWN button
- Press ALARM again to exit the alarm-setting function

**Setting the Alarm Volume:**

- Press UP to adjust the alarm volume
- The display will show "01" for minimum volume
- Press UP again to adjust the volume to "02" (medium volume)
- Press UP again to adjust the volume to "03" (maximum volume)

**Turning on the Alarm:**

- Press the ALARM button once to turn ON the alarm, which will cause the alarm icon (🔔) to display on the front
- To turn OFF the alarm press the ALARM button again, which will cause the alarm icon (🔔) to disappear
- To snooze the alarm for 5 minutes, press the LIGHT/SNOOZE button once when the alarm goes off, which will activate the snooze function and cause the alarm icon (🔔) to flash
- To turn off snooze mode, press the ALARM button twice

**Setting the Brightness:**

- To adjust the display brightness, press the LIGHT/SNOOZE button to toggle between three brightness options

**Adjusting the Display Color:**

- To adjust the display color so the digits rotate between various colors from left to right, press the DOWN button twice (you will hear a beep)
- To adjust the display color so the digits rotate between various colors from top to bottom, press the DOWN button twice again (you will hear a beep)
- To adjust the display color so the digits all show the same color but also rotate between different colors, press the DOWN button twice again (you will hear a beep)
- To turn off the rotating colors, press the DOWN button again (you will hear a beep), and continue to press the DOWN button until you see the color you want displayed permanently without any rotating colors. There are eleven (11) different display color options to choose from.