

Product Instructions

Product Features

- Displays time, date and temperature alternately or permanent time only
- Sound activated display or permanent display (Highly recommended: When using AAA batteries to power the clock, keep the display setting on sound activated to conserve battery)
- 12 and 24 hour formats can be selected (Default mode: 24 hour)
- Weekday and weekend alarm settings
- Power source: DC 5V/ 500 MA power (USB cord included) or 3 x AAA batteries (not included). Sound Control is strongly recommended when using 3 x AAA batteries to preserve battery life.
- Default luminance: Half luminance between 6PM-7AM – 4 adjustable luminance settings.
- May set up to 3 different alarms. Each alarm lasts 1 Minute.

Contents

- 1 X Digital Bamboo Clock
- 1 X User Guide
- 1 X USB Charging Cable

Operating Button Instructions

SET UP DOWN RESET

Switch Temperature Format: To switch between F and C, press the “UP” button when in normal display to toggle between the temperature formats.

Switching Sound control: To switch between sound control on and off, press the “DOWN” button when in normal display to toggle between sound control on “ON:Sd” and off “--:Sd”. “ON:Sd” will place the clock in Sound Display mode. “--:Sd” will place the clock in permanent display.

Switching display format: To Switch Between Display Setting 1 “dp-1” (Time, Date and temperature showing together) and Display setting 2 “dp-2” (Time only), press the “SET” button when in normal display.

Resetting to factory settings: To reset factory settings, press “RESET”.

Note: when in 12H display mode, PM time will be denoted with a light in the upper corner.

Changing Luminance Setting: To Change the Luminance setting, press and hold “UP” for 3 seconds. Toggle between the 4 luminance settings using “UP” and “DOWN” to adjust between Luminance level 0 “L0” and Luminance level 4 “L3”. Wait 5 seconds and setting will automatically save

Change Settings: Press and hold "SET" button for 3 seconds to enter the settings menu. In the settings menu, you can change Year → Month → Date → 12H/24H mode → Hour → Minute → Alarm 1 → Alarm 2 → Alarm 3 → Alarm Mode (Work days/All Days)

When YEAR Symbol is flashing, you may adjust the year using the "UP" or "DOWN" Buttons accordingly. Press "SET" to confirm adjustment and move to the next item in the menu.

When MONTH symbol is flashing, you may adjust the month using the "UP" or "DOWN" Buttons accordingly. Press "SET" to confirm adjustment and move to the next item in the menu.

When Date (day) Symbol is flashing, you may adjust the day using the "UP" or "DOWN" buttons accordingly. Press "SET" to confirm adjustment and move to the next item in the menu.

When 12H/24H Symbols is flashing, you may adjust the hour setting using the "UP" button to switch between 12H or 24H format. Press "SET" to confirm adjustment and move to the next item in the menu.

When HOUR Symbol is flashing, you may adjust the Hour using the "UP" or "DOWN" buttons accordingly. Press "SET" to confirm adjustment and move to the next item in the menu.

When MINUTE Symbol is flashing, you may adjust the Minute using the "UP" or "DOWN" buttons accordingly. Press "SET" to confirm adjustment and move to the next item in the menu.

When Alarm Symbol (--:A1) is flashing, you can switch Alarm ON or OFF by pushing "SET" button. (--:A1) means the Alarm is off. (on:A1) means the alarm is on. When (on:A1) is flashing, you may adjust the alarm time Using "UP" and "DOWN". Adjust hour first, then push "SET". Now adjust Minute using "UP" and "DOWN" and press "SET". This will Set Alarm 1 and move on to Alarm 2. Alarm 2 and Alarm 3 may be set using the same Method.

When Alarm Mode Symbol (--:E) is flashing, you may switch between Week Days only Alarm or All Days Alarm setting. Week day only alarm is "--:E", all days alarm is "on:E". Press "SET" to toggle between the setting.

When you are done adjusting the desired settings, leave the clock for 5 seconds and the settings will save.

If settings need to be reset to default settings, press "RESET".