

INFLATABLE WATER SLIDE

INSTRUCTION MANUAL



Ages 3–10



Up to 6 Kids



Total Capacity
550 lbs

Thank you for choosing our inflatable water slide. Please read this manual carefully before use and keep it for future reference.



SAFETY WARNINGS

- Adult supervision is required at all times.
- Not suitable for children under 3 years. Small parts may be swallowed.
- Use only on a flat, level surface.
- Keep away from sharp objects, fire, and heat sources.
- Do not exceed the maximum weight capacity of 550 lbs.
- Do not allow rough play, flips, or somersaults.
- Keep the area around the product clear.

PACKAGE CONTENTS



Air Blower
x 1



Carry Bag
x 1



Ground Stakes
x 6



Repair Patches
x 3

SET-UP



- 1 Choose a flat, clear area at least 2 meters away from any structures or obstacles. Unfold the product and lay it flat.



- 2 Attach the inflation tube to the air blower. Secure the tube tightly.



- 3 Plug in the blower and turn it ON. The product will inflate in 2–3 minutes.



- 4 Secure the product with ground stakes through the anchor points. Ensure the blower is on continuously during use.

TAKE DOWN & STORAGE



Turn off and unplug the blower.



Open the air flap to deflate completely.



Fold the product in half, then fold again.



Roll it up tightly from the end opposite the air flap.



Place in the carry bag and store in a dry, cool place.

CARE & MAINTENANCE



Wipe the surface with a damp cloth and mild soap if needed. Do not use bleach or harsh chemicals.



Keep away from direct sunlight when not in use.



Make sure the product is completely dry before storage.



Regularly check for damage or loose stitching. Use the repair patches to fix small tears.



IMPORTANT

The blower must remain on and the air flap closed during use. Ensure the blower is placed on a dry surface and away from water.

Total Capacity
550 lbs
Ages 3–10