


This Chair has multiple parts and may require up to some 30 minutes to assemble.

To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective.


Please read through the instructions below to familiarise yourself with the parts and steps before assembly.



Then attach the Backrest Panel(A) to the top end of the Left Legs with Preattached Levellers(C)using Washers, Spring Washers and Nuts((1)) with Spanner((3)).

## Do not fully tighten .

# <u>Step 4</u>



Repeat the same assembly process for the Right Legs with Arm and Preattached Bolts for Seat Panel and Leveller(D) **DO NOT fully tighten at this stage.** 

# Step 5



Stand the chair rightside up.

Now, in a sequential manner, fully and securely tighten all bolts at all joints.

Then Add Rubber Caps(2) on 4 bolt ends on the back of the chair to protect skin or clothing from getting snagged.

Adjust the Pre-attached levellers at the bottoms of the chair legs until the chair is level with the ground.

Your chair is ready for use.

**Caution:** This Chair can only be used on a flat, level surface.

# Care & Maintenance Do not put hot items directly on furniture surface Do not clean furniture with harsh cleansers or polish. To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended. M Children should not climb or jump on the furniture. Do not write on furniture without a padded barrier to protect the surface. To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings. Not for commercial use. For residential use only . Stains may be removed with mild soap solution and damp cloth.

Dust and pick-up spills using a clean, non-colored, lint-free cloth.

## What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and fumiture.

## Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our fumiture or packing materials. We risk large fines under this law, if we don't include this warning. Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

## Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

