Folding Stool Instruction Manual



HOW TO OPEN STOOL



Hold the stool at the top of the seat while in its closed position.



2

With two hands on either side of the seat, press down on the top edge of the stool while pulling up with your other hand.





As you apply pressure to the seat, the legs will begin to glide open. Continue this until they are fully open and into place. Before sitting, ensure the legs are locked using the hinge lock on the bottom of the seat.

USE & CARE TIPS

- ► Always inspect each stool upon receiving it and before use. Never sit on a damaged, bent, or broken stool.
- ▶ Place on a solid, flat surface that is non-slippery.
- When using the stool, sit in the center and always keep two feet on the ground.
- Check for missing or damaged parts before use.
- Store in a safe, dry place to avoid damage.
- Keep stool clean and free of debris for long-lasting use.



HOW TO CLOSE STOOL



Pull out the hinge lock underneath the stool and begin to separate the legs from the top seat.





With two hands, lift one side of the seat up while pressing down on the other side until the legs are closed and the stool is flat.





Once the stool is flat, it can be stored until further use.



IMPORTANT: To avoid tipping or falling do NOT stand on the stool. Be sure you are sitting in the center of the stool with the bottom double bars facing front & back and both feet firmly on the ground.

Weight capacity: 225lbs.



