


Wardrobe



IMPORTANT INFORMATION!

- please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.

AVOID SCRATCHES!

- In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.

IMPROVE EFFICIENCY !

- Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.

IMPORTANT !


- It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

- For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.





- Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.

ANTI-TOPPLE WARNING !

Overtured furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.



Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 51




CRA0635A

B x 51



CRB1595A

C x 50



CRF0830A

D x 28




CRD0440A

E x 8



CRD0430A

F x 8



DGA861A

G x 8



DGA861B

H x 104



CRD3514A

J x 8




Ø20*23

K x 8



CRE0418A

L x 2




HG-12-4512

M x 16



CRD3512A

N x26



14x13x10mm

P x 26



CRD0316A

Q x 4



47 x 18 x 12mm


R x 2



770mm

S x 2







Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.


Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.




STEP 1: Extend Slide
Extender la diapositiva
Extendre la diapositive



STEP 2: Push Lever UP
Empujar hacia arriba
Lever le levier



STEP 3: Remove Runner
Quitar el corredor
Enlever le coureur



1

A x 4



CRA0635A

H x 4






CRD3514A

Q x 2



47x18x12mm



2

B x 4






CRB1595A

C x 4



CRF0830A



3

H x 2





CRD3514A

Q x 1



47x18x12mm



4

H x 2





CRD3514A

Q x 1




47x18x12mm



5

C x 6







CRF0830A


D x 10



CRD0440A



6






7

A x 9



CRA0635A




8

C x 6






CRF0830A

D x 10



CRD0440A






9

A x 4



CRA0635A






x2

10

B x 4



CRB1595A






11

A x 10



CRA0635A



12

B x 10






CRB1595A

C x 4



CRF0830A






13

A x 4



CRA0635A



14

A x 4



CRA0635A

L x 2






HG-12-4512

M x 8



CRD3512A






15

B x 4



CRB1595A



16

B x 2






CRB1595A

C x 2



CRF0830A




17

B x 2






CRB1595A

C x 2




CRF0830A




18

C x 6






CRF0830A

D x 8



CRD0440A






19

A x 8



CRA0635A



20

B x 4






CRB1595A

C x 4



CRF0830A




21

B x 4






CRB1595A


C x 4



CRF0830A



22




23

B x 9






CRB1595A

C x 12



CRF0830A



24

L x 2






HG-12-4512

M x 8



CRD3512A





x2

25

E x 8




CRD0430A



x2

26






x2

27

A x 8



CRA0635A






28


B x 8



CRB1595A



29




30




R x 2





770mm



31




32



33

F x 4



DGA861A

G x 4





DGA861B

H x 16



CRD3514A



34

H x 32



CRD3514A

J x 4





Ø20*23





K x 4








CRE0418A





35





36





Up & Down Adjustment



Left & Right Adjustment



Forward & Back Adjustment



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please consult our FAQ section at feedbackstation@163.com as there may be a simple solution to the issue.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
- In all circumstances please save all packaging material and paperwork for the order.
- Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.