
RÍSE UP Electric Adjustable Height Standing Desk



Safety Tips



Make sure pets, children, and unwanted objects are away from the desk before use. Unplug during thunderstorms and when not in use for long periods.



Before use, ensure the desktop is not touching any walls.



Remove obstacles taller than 19" from underneath the desk.



Do not operate in temperatures below 0° F or above 98°F. Keep away from gas, liquids, and dust.



Never disassemble the sealed components or parts. This product conducts electricity which may cause serious injury or death.



To avoid injury, do not place hands, feet, other body parts, or other objects under the desk when adjusting.




Read and thoroughly understand this manual plus how to adjust and use this product before use.




Reset the desk after first assembly and after power outages.

DISCLAIMER: Buyer accepts full liability for any injury or loss to themselves, their property, and anyone else at any time and from any cause while using this product. Buyer expressly releases Uncaged Ergonomics and its agents from any liability for such loss or injury. In no event shall Uncaged Ergonomics or its agents be liable for any direct, indirect, punitive, incidental, damages or injury whatsoever arising out of or connected with the use or misuse of its products.

Parts




INSTALLATION GUIDE




SCREWS AND TOOLS

A O	B	©		E	F	G
M6X10 Machine	M6X14 Machine	M6X35 Machine	ST5X20 Wood	ST5X16 Wood	M4 Wrench	Cable Clip
Screw 16PCS	Screw 4PCS	Screw 8PCS	Screw 16PCS	Screw 6PCS	1PCS	10 PCS


INSTALLATION GUIDE



INSTALLATION GUIDE



Usage and Setting



Reset Instructions


Problem

The display shows an error code such as: E07, E08, E09.




Press and hold the "**down**" button for about 5 seconds. The display will show **RST**. Release the down button, and press the down button again to reset.

Memory Settings



Usage and Setting




Switch Units From CM to IN

Press the down button for 5 seconds until the display flashes "**RST**". Press "**2**" for 5 seconds to change the display unit:

- "10.3" means height is in cm
- "10.4" means height is in in

Press the "down" button to finish the reset process.




Press 5 Sec

Switch Between "1-Touch" and "Constant Touch" Memory Adjustments

Hold the "**down**" button for 5 seconds until the display flashes "**RST**". Press button "**1**" for 5 seconds to switch memory settings:

- "10.1" means 1-Touch Memory Adjustment
- "10.2" means Constant-Touch Memory Adjustment




Lock Your Desk

Press "M" until the display shows "S-". Keep pressing "M" for 5 seconds until the display returns the number. Continue to hold "M" for about 3 seconds until the display shows "LOC". The desk is locked.

Unlock Your Desk

In the "LOC" status, press "M" for 8 seconds until the screen shows the height. The desk is unlocked.




Anti-Collision Sensitivity Setting

Press and hold the down arrow for about 5 seconds until the display flashes "RST".

Press "up" arrow for 5 seconds to change the anti-collision sensitivity:

- "10.5" = not sensitive
- "10.6" = moderate sensitivity
- "10.7" = very sensitive



Set The Highest Limit

Press and hold "M" until the display shows "**S**-". Release "M". Press the "**up**" arrow. After the display flashes, release the "**up**" arrow. Press "M" for 2 seconds. When the display shows "**999**", the setting is complete.

Set The Lowest Limit

Press "M" until the display shows "**S-**", then release "M". Press "M" again for 2 seconds. When the display shows "**000**", the setting is complete.

Cancel Limits

Press "M" until the display shows "S-", then release "M". Press "M" again for 2 seconds until the display shows "555". The high and low limits will be canceled.

Adjust The Minimum Height

With the display flashing "**RST**", press "**M**" for 5 seconds. The display will show the height and keep flashing.

Press the "**up**" or "**down**" arrow to adjust the minimum height reading. Once released, the display will show "**RST**" flashing. Press the down button to complete the setting.

When to Reset Your Desk:

RST

3

۵

2

Press 5 Sec

Resetting your desk is a common step to help the operation run smoothly and is not indicative of a defective product. Reset your desk when:

1. It has abnormal function

2. The display shows RST (reset)

3. The display shows error codes (E01-E13)

It's common to reset the desk after initial assembly and when the desk is unplugged/plugged in.

If the display shows "HOT", turn off power to the desk and let it rest for 20 minutes before use.

