

TIPS FOR USING THE FUNCTION



C Height Adjustment

- To raise the seat, lift "C" gently while lifting your body.
- To lower the seat, lift "C" gently when sitting down.

F Angle Adjustment

- Turning "F" to the left will increase the tilt angle, and turning it to the right will decrease the tilt angle.



D Tilt and Sway

- After sitting down, pull out "D" and the seat can sway back and forth about 100-125 degrees. However, the seat cannot be locked in a backward tilt angle.
- To lock the seat: When it returns to its original position, push "D" inward and the seat will be locked.