

INSTALLATION

Product Manual

Version: 020469US-01-25A-AA



IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 112



Ø 6 x 35 mm

B x 115




Ø 15 x 10 mm

C x 118



Ø 6 x 30 mm

D x 48



Ø 5 x 40 mm

E x 156




Ø 3.5 x 12 mm

G x 3



Ø 9 x 10 mm

H x 3




Ø 6 x 48 mm

I x 54




Ø 3.5 x 14 mm

J x 12



K x 2




L x 4



Ø 3.5 x 35 mm


N x 4




O x 4



P x 12




CL x 6




350mm

CR x 6




350mm

DL x 6




350mm

DR x 6










350mm


Q x 12



R x 112








⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:



- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*




ASSEMBLED BY 2 ADULTS



1




As shown in the figure, first install the component (R) onto panel 5 and panel 14, then screw the self-tapping rod (A) into panel 5 and panel 14.





2





Connect board 7 and 6 to board 14 and 5 respectively using wooden dowel(C), add cam lock(B) into board 6,7 and turn clockwise to tighten as shown.





3





Connect board 1 and 8 to board 5 using wooden dowel(C), and fix with screw(D) as shown.





4






As shown in the figure, first install the component (R) onto panel 3, then screw the self-tapping rod (A) into panel 3.





5






Attach board 3 to board 1, 6, 8 and 9 using wooden dowel(C), add cam lock(B) into board 1, 6, 8, 9 and turn clockwise to tighten as shown.






6






Attach board 13 to board 14 using wooden dowel(C), and fix with screw(D) as shown.





7







As shown in the figure, first install the component (R) onto panel 11, then screw the self-tapping rod (A) into panel 11.





8






Attach board 11 to board 7, 13 and 9 using wooden dowel(C), add cam lock(B) into board 7,13,9 and turn clockwise to tighten as shown.





9





Attach board 10 to board 11 using wooden dowel(C), add cam lock(B) into board 10 and turn clockwise to tighten as shown.





10





Attach board 2 to board 11 and 14 using wooden dowel(C), and fix with screw(D) as shown.






11





As shown in the figure, first install the component (R) onto panel 4, then screw the self-tapping rod (A) into panel 4.





12



Attach board 4 to board 10 and 2 using wooden dowel(C), add cam lock(B) into board 10 and turn clockwise to tighten as shown.



Fix board 4 to board 2 with screw(D) as shown.




13



A x 8



R x 8



As shown in the figure, first install the component (R) onto panel 12, then screw the self-tapping rod (A) into panel 12.





14



B x 8



C x 8



Attach board 12 to board 2, 6, 9 and 13, add cam lock(B) and turn clockwise to tighten as shown.



15

B x 8







Ø 15 x 10 mm



C x 8





Ø 6 x 30 mm



Connect the two components using wooden dowel(C),
add cam lock(B) into and turn clockwise to tighten as shown.





16



B x 3  Ø 15 x 10 mm	C x 2  Ø 6 x 30 mm	G x 3  Ø 9 x 10 mm	H x 3  Ø 6 x 48 mm	
--	---	---	--	---

Add nut(G) and screw eccentric rod(H) into board 17 at first.



Connect board 17 and 18 using wooden dowel(C), add cam lock(B) into board 18 and turn clockwise to tighten as shown.



17

A x 12  Ø 6 x 35 mm	E x 16  Ø 3.5 x 12 mm	K x 2 	R x 12 	
--	--	--	--	---


As shown in the figure, first install the component (R) onto panels 17 and 18, then screw the self-tapping rod (A) into panels 17 and 18.



As shown in the figure, use screw (E) to mount component (K) to panel 17 and panel 18.


18

C x 8






Ø6 x 30 mm


D x 8



Ø5 x 40 mm



Attach board 17 and 18 to board 3, 4, 11 and 12 using wooden dowel(C), and fix with screw(D) as shown.



19

E x 8




Ø3.5 x 12 mm

I x 40






Ø3.5 x 14 mm

J x 12



N x 4




Q x 12





As shown in the figure, use component (J) to connect panels 39, 40, and 41, and use component (I) to secure the assembly to the main body.

As shown in the figure, use screws (E) to mount component (N) to panel 1 and panel 2.





As shown in the figure, use screws (I) to connect panels 39, 40, and 41 to the main body.

20




As shown in the figure, first install the component (R) onto panels 19, 20, 21, and 22. Then screw the self-tapping rod into panels 19, 20, 21, and 22.




21



E x 36












CL x 6



CR x 6






Ø 3.5 x 12 mm





Fix rail(CL) to board 21 with screw(E) at first, flip to back, fix rail(CR) as shown.

Fix rail(CR) to board 22 with screw(E) at first, flip to back, fix rail(CL) as shown.




22





Attach board 23 and 24 to board 22 using wooden dowel(C), add cam lock(B) into and turn clockwise to tighten as shown.






23






Attach board 21 to board 23 and 24 using wooden dowel(C), add cam lock(B) into and turn clockwise to tighten as shown.






24






As shown in the figure, connect panel 26 to panel 21 using a wooden dowel (C), and tighten by rotating clockwise with the eccentric wheel (B).



25






As shown in the figure, connect panel 25 to panel 21 using a wooden dowel (C), then insert the eccentric wheel (B) and tighten it by turning clockwise.






As shown in the figure, connect panel 19 to panels 25 and 26 using a wooden dowel (C), then insert the eccentric wheel (B) and tighten it by turning clockwise.




26






As shown in the figure, connect panel 26 to panel 22 using a wooden dowel (C), and tighten by rotating clockwise with the eccentric wheel (B).



27



As shown in the figure, connect panel 25 to panel 22 using a wooden dowel (C), and tighten by rotating clockwise with the eccentric wheel (B).



As shown in the figure, connect panel 20 to panels 25 and 26 using wooden dowels (C), and tighten by rotating clockwise with the eccentric wheel (B).


28

B x 12




Ø 15 x 10 mm




C x 12



Ø 6 x 30 mm




Connect the two components using wooden dowel(C), add cam lock(B) into and turn clockwise to tighten as shown.




29



Ø3.5 x 14 mm




Fix back board 38 to the unit with screw(I) as shown.



30




Fix board 27 and 28 to board 29 with screw(D) as shown.
Fix board 27, 35 and 28 to board 33 with screw(D) as shown.




31

Insert bottom board 30 and 34 along available grooves as shown.







32

A x 28






Ø6 x 35 mm

R x 28




As shown in the figure, first install the component (R) onto panels 31, 32, 36, and 37. Then screw the self-tapping rod (A) into panels 31, 32, 36, and 37.

33




Attach board 31 and 32 to board 27 and 28, add cam lock(B) into and turn clockwise to tighten as shown.

Attach board 36 and 37 to board 27, 35 and 28, add cam lock(B) into and turn clockwise to tighten as shown.




34



E x 24










DL x 6



DR x 6




Ø 3.5 x 12 mm



Fix runner(DL) and (DR) to board 27 and 28 respectively with screw(E) as shown.

35

Align rails, insert drawers into corresponding positions.





36

E x 72




Ø3.5 x 12 mm

P x 12







Fix hinge(P) to board 15 and 16 with screw(E) as shown.



Assemble door 15 and 16 to the item by fixing hinge with screw(E) as shown.




37




Install anti-tipping device as shown.




1.




2.




3.



4.

















If there is misalignment after you install,
adjust the screw to the best condition.

If doors are still not aligned if the hinges
are properly correctly, please watch the video.

<https://youtu.be/n0Lb36SoODM>



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT



01203 300000 01203 300000 0



01203 300000 01203 300000