

# ASSEMBLY AND INSTRUCTION GUIDE FOR INDUSTRIAL SEATING INC. STOOLS



Your Industrial Seating Stool should have the following parts in the box:

- Five Star Aluminum or Plastic Base with Casters or Glides (**A**).
- Footring on Bench Height Models, Optional on Desk Height Models (**B**).
- Pneumatic Cylinder (**C**).
- Seat Cushion with Adjustable Height Single Lever Control (**D**).

## HOW TO ASSEMBLE YOUR STOOL

1. Remove all the parts from the box,
2. If the Stool has an Adjustable Footring (**B**) slip it onto the Pneumatic Cylinder (**C**) Check that the Tubular Ring faces upward. Firmly tighten the Footring to the desired Height.
3. Insert the Pneumatic Cylinder (**C**) onto the base hole (**A**) Check that it fits correctly.
4. Insert the Seat Cushion Control unit hole (**D**) into the top of the Pneumatic Cylinder (**C**) Apply pressure on the seat to adjust the desired Height.



## TO ADJUST YOUR STOOL

- To Raise the seat hold the Lever up, release the Lever when it reach the desired Height.
- To Lower the seat apply pressure on it and pull the Lever up, release the Lever when it reach the desired Height.

## \*\* ATTENTION \*\*

ALL SHIPPING DAMAGES, MISSING PARTS OR RETURNS OF THE PRODUCTS MUST BE REPORTED TO US WITHIN 7 DAYS AFTER RECIEVEING THE PACKAGES.

## \*\* IMPORTANT \*\*

IF YOU NOTICE BAD FUNCTIONING AFTER THE ASSEMBLY STOP THE USE AND CALL INDUSTRIAL SEATING INC. FOR ASSISTANCE (619) 478-2100 OR CONTACT THE DISTRIBUTOR.



At Industrial Seating Inc. we value your opinion. We would love to hear your thoughts, suggestions, concerns or problems with anything to improve the quality of our services.

Visit [www.industrialseat.com](http://www.industrialseat.com) for more information.