




COMPUTER DESK WITH PRINTER SHELF & 2 DRAWERS




USER MANUAL

Safety Instructions

Thank You For Choosing Our Product

Before assembly, please read this USER MANUAL first, and check according to Parts List to make sure all parts are included. Feel free to contact us if you have any concerns or questions about your product, we are always ready to help. Your satisfaction is our first priority!


Precautions



- Avoid long-term direct sunlight exposure.



- Keep away from sharp objects.




- Keep away from heat.



- Keep infants/children away from assembly parts to avoid choking and suffocation.




- Keep away from corrosive substances.




- Pay attention to avoid over-tightening fasteners, or they may induce cracking within the board.




















Disassembly Diagram












Parts List

For ease and safety, we recommend two people for assembly.



A x1 	B x1 	C x1 	D x1 
E x1 	F x1 	G x2 	H x1 
I x1 	J x2 	K x1 	L x2 
M x1 	N x1 	O x1 	P x2 
Q x2 	R x2 	S x1 	T x1 

Parts List

U x1 	V x1 		
1 x7  M6x10 1 Spare	2 x36  M6x28 3 Spares	3 x14  M5x40 2 Spares	4 x3  1 Spare
5 x5  1 Spare	6 x2 	7 x7  1 Spare	8 x1 
9 x2  #4 1 Spare	10 x2  M4	11 x2  #3 1 Spare	


Assembly Instructions



Attention: The shelves can be installed on either side, you can choose one instruction as you prefer.


For the right-side Storage Shelves model:

See pages 06 to 23 (look for "R" marked pages).






For the left-side Storage Shelves model:

See pages 25 to 42 (look for "L" marked pages).




R-1





F x1		K x1		O x1		7 x6	
---------	--	---------	--	---------	--	---------	--

R-2







D		G		2		3		9		11	
x1		x2		x4		x4		x1		x1	

R-3




R-4



Assembly Instructions

R-5

During installation, ensure Part E is oriented toward accessory ⑩ on Part K.



Assembly Instructions

R-6

During installation, ensure the notch on Part O faces Part K.


2

x2




9

x1








Assembly Instructions




R-7 During installation, ensure the notch on Part N faces Part O.



R-8



R-9




Assembly Instructions

R-10


Ensure the arrow-marked hole is oriented correctly during installation.

H	
x1	
I	
x1	
2	
x4	
9	
x1	








R-11

A	
x1	
2	
x8	
9	
x1	





R-12





Assembly Instructions

R-13

Use screws of the correct specification when installing Component S. Incorrect-specification screws may cause tabletop damage.






R-14




Assembly Instructions


R-15



Step 1: Place the hook of the slide rail at an Angle into the steel frame slot .




Step 2: Install the entire rail hook into the steel frame slot.




Step 3: Press the slide rail down so that the hook fasteners the steel frame.


R-16



x2




T/U




T/U

R-17



R-18




Assembly Instructions



Attention: The shelves can be installed on either side, you can choose one instruction as you prefer.


For the right-side Storage Shelves model:

See pages 06 to 23 (look for "R" marked pages).






For the left-side Storage Shelves model:

See pages 25 to 42 (look for "L" marked pages).




L-1



F		K		O		7	
x1		x1		x1		x6	

L-2




D		G		2		3		9		11	
x1		x2		x4		x4		x1		x1	

Assembly Instructions


L-3

10
x2



L-4



P x2	
E x1	
3 x4	
11 x1	



Assembly Instructions

L-5


During installation, ensure Part E is oriented toward accessory ⑩ on Part K.



Assembly Instructions

L-6



During installation, ensure the notch on Part O faces Part K.



Assembly Instructions




L-7

During installation, ensure the notch on Part N faces Part O.




N x1	
2 x2	
9 x1	

L-8



L-9


M	
x1	
2	
x2	
9	
x1	



Assembly Instructions


L-10

Ensure the arrow-marked hole is oriented correctly during installation.




H x1	
I x1	
2 x4	
9 x1	

L-11



A	
x1	
2	
x8	
9	
x1	

L-12






J x2		1 x4	
V x1		8 x1	
4 x2		9 x1	



Assembly Instructions

L-13




Use screws of the correct specification when installing Component S. Incorrect-specification screws may cause tabletop damage.




L-14




L-15



Step 1: Place the hook of the slide rail at an Angle into the steel frame slot .




Step 2: Install the entire rail hook into the steel frame slot.





Step 3: Press the slide rail down so that the hook fasteners the steel frame.


L-16




x2



L-17



L-18





30 DAY Return Policy

If you're not completely satisfied with your purchase, please return the merchandise via our Official Customer Support. Unused merchandise can be refunded or exchanged within 30 days of purchase.



1-Year Warranty

We guarantee your product is free from defects in product material and workmanship for one (1) year starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new one. Replacement is free and all shipping costs are covered.



Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

Problems You May Encounter

PART	PROBLEM	SOLUTION
Whole Product	Parts are missing, defective or having wrong parts in package.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	Having issue(s) while reading the instruction or completing the assembly.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	Encountering non - human caused damage during use.	If the product is damaged due to non - human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Furniture Surface	Surface is broken, scratched or lack of some screw holes.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	The screw holes that on the board and the frame don't line up.	1. Tighten the screws only 70% of the way. Do not fully tighten the screws until all parts are aligned. 2. Adjust the board and frame until the holes align, then fully tighten all screws.
	Surface is uneven or not tight that has gaps after being assembled.	1. Loosen the screws in the uneven or gap positions; adjust until the surface is flat and tight, and then tighten the screws. 2. If your problem still can't be solved, please feel free to contact us.
Structure Frame	Components are bent, broken, chipped, rusted, or damaged.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	The furniture is unstable after being assembled.	1. Check if all screws are fully tightened. 2. Read through the manual and check if any parts are installed incorrectly or missing. 3. If the problem persists, please contact us.
	Encountering non - human caused damage during use.	If the product is damaged due to non - human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.

We are committed to providing our customers with premium quality products and convenient customer service.

MADE IN CHINA