

Assembly Instructions

Step 1 — Unpack and Identify Every Panel

1. Carefully remove all panels and hardware from the packaging.
2. Place the panels on a blanket, cardboard, or another soft surface.
3. Keep hardware bags separated according to their labels or numbers.
4. Inspect the panels for damage before beginning.
5. Identify the finished/fluted surfaces and make sure you know which direction each panel should face.

TIP: Keeping all hardware organized will make assembly much easier.

Step 2 — Build the Main Cabinet Frame

1. Begin by attaching the **bottom/base components** to the side panels.
2. Install the **center/divider panels** according to their designated positions.
3. Attach the **upper/top frame**.
4. Make sure all finished and fluted surfaces face **outward**.
5. Check that the panels are properly seated and aligned.
6. Leave the screws slightly loose while assembling the frame.
7. Once the complete frame is assembled, check that it is square and properly aligned.
8. **Tighten the frame hardware only after alignment is confirmed.**

IMPORTANT: Do not force panels together if they do not align. Recheck the orientation and hardware before tightening.

Step 3 — Install the Back Panels

1. Position the rear/back panels against the assembled cabinet.
2. Make sure the edges are properly aligned with the cabinet frame.
3. Fasten the back panels using the supplied hardware.
4. Check that the cabinet remains square as you secure the panels.
5. Tighten the fasteners evenly.

IMPORTANT: The back panels help maintain the cabinet's overall shape and stability. Do not leave them loosely attached or omit them.

Step 4 — Install the Adjustable Shelves

1. Locate the shelf-support pins.
2. Insert the pins into matching holes at the desired shelf height.
3. Make sure all support pins for each shelf are installed at the **same height**.
4. Carefully place each adjustable shelf onto its supports.
5. Check that each shelf is fully seated and stable.
6. Repeat for all three adjustable shelves.

Adjusting Shelf Height

The shelves can be repositioned later.

To change the height:

1. Remove the items from the shelf.
 2. Carefully lift the shelf from its supports.
 3. Move the support pins to the desired holes.
 4. Ensure the pins are level with one another.
 5. Replace the shelf.
-

Step 5 — Attach the Four Doors

1. Identify the four fluted cabinet doors.
2. Install the supplied hinge hardware according to the numbered hardware provided with the cabinet.
3. Attach the hinges to the appropriate cabinet panels and doors.
4. Have a second adult support each door while attaching it to the cabinet.
5. Initially leave the hinge screws slightly loose enough to permit adjustment.
6. Check that each door opens and closes freely.

TIP: It is normal for the doors to require adjustment after installation.

Step 6 — Install the Gold Handles

1. Locate the four gold handles and their mounting hardware.
2. Align each handle with the pre-drilled holes in its door.
3. Insert the mounting screws from the **inside of the door**.
4. Thread the screws into the handle.
5. Tighten the screws firmly.

6. Repeat for all four doors.

CAUTION: Do not overtighten the handle screws.

Step 7 — Align the Doors

After all four doors are installed:

1. Slowly close all four doors.
2. Inspect the gaps between the doors.
3. Check that the top and bottom edges are aligned.
4. Check that the doors do not overlap or interfere with one another.
5. Adjust the hinges as necessary.

Common Door Problems

Door is too high or too low

Adjust the hinge position to raise or lower the door.

Gap between doors is uneven

Use the hinge adjustment to move the door sideways.

Door sits too far inward or outward

Adjust the hinge depth.

Doors overlap

Make a small side-to-side hinge adjustment.

Door does not close tightly

Adjust the hinge position/depth until the door sits correctly.