

Installation manual

Tools: Cross/flathead screwdriver.

It is strictly forbidden to use power tools to forcefully tighten components.

1. Remove the seat surface and the two legs. Align the threads/holes on the legs with the pre-drilled holes at the bottom of the seat surface. Position them first without tightening.
2. Install the horizontal seat surface and connect the two legs that are adjacent to each other, ensuring that the frame is square.
3. Tighten all screws in a diagonal sequence to avoid over-tightening on one side, which could cause deformation.