


OPERATION INSTRUCTIONS

TABLE

WF321707, N719P240575

Please do not assemble until receiving the complete 4 package. If you have not received the complete 4 package, please be sure to contact us.




Caution: You must read this before you proceed

Care & Maintenance

-  ● Not for commercial use. For residential use only.
-  ● Do not put hot items directly on furniture surface.
-  ● Do not clean furniture with harsh cleansers or polish.
-  ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
-  ● Children should not climb or jump on the furniture.
-  ● Do not write on furniture without a padded barrier to protect the surface.
-  ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
-  ● Stains may be removed with mild soap solution and damp cloth.
-  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.

ASSEMBLY INSTRUCTIONS




GENERAL ASSEMBLY INFORMATION GUIDE

Please read the following instructions prior to assembling this product:

1. To avoid damage, assemble this product on a non-abrasive surface such as carpet.
2. Make sure all bolts are tightly fastened before use.
3. For home use or light commercial use only.
4. Please make sure you have all parts before assembly.

PARTS LIST

A



QTY 1 pc

B




QTY 2 pcs

C




QTY 2 pcs

1 Bolt M6x35



QTY 8 pcs

2 Crew M6x75





QTY 4 pcs

3



QTY 1 pc

STEP 1



STEP 2

