



Instructions

1. Fix the closer vertically to jamb on hinged side of door.
2. To set tension turn the center of the closer opposite to the arrow.
3. Place arm into nearest hole to door.
4. Fix slide plate into position to protect door.

Tension Adjustment

Turn the center boss away from the door with the steel bar supplied and screw the arm into the hole nearest the door. To increase tension, repeat the operation one hole at a time and **not more than four holes**.

To protect the door from marking, fix the slide plate supplied into position. Once the closer has been properly installed at the proper tension, fill open holes with the plugs provided.

Warning: Do not over tension closer **more than four holes**. Over tensioning will cause spring(s) to buckle and the door to slam. **Springs cannot be repaired or replaced.**