


## Smart Toilet (DV-1S0160-V3)



**NOTE:** Drawings may not exactly define contour of the product.

# TABLE OF CONTENTS

|                                                             |    |
|-------------------------------------------------------------|----|
| ● Safety Precautions .....                                  | 02 |
| ● Technical Specifications .....                            | 05 |
| ● Pre-installation .....                                    | 06 |
| ● Installation .....                                        | 08 |
| ● Remote Control Installation and Battery Replacement ..... | 11 |
| ● Side Rotated Knob Operation .....                         | 12 |
| ● Remote Control Instructions .....                         | 13 |
| ● Automatic Fuction .....                                   | 17 |
| ● Daily Maintenance .....                                   | 18 |
| ● Troubleshooting .....                                     | 20 |



## Prior to Installation:

- Inspect toilet to ensure no damages have occurred while in shipping.
- Observe all plumbing and building codes in accordance with your state and local requirements.
- Remove old toilet.
- Make sure mounting surface is CLEAN and LEVEL.

### General Recommendations:

Please read installation and maintenance instructions thoroughly before installing the toilet.

Be sure to use proper tools and always wear proper personal safety accessories for your protection.

**If you have any questions or concerns  
please contact us:**

(+1) 312-626-9466  
[service@deervalleybath.com](mailto:service@deervalleybath.com)

## ● Safety Precautions

Before installation, please read this manual carefully and install it in strict accordance with the instructions. After reading, please put this manual in a prominent position. Keep the place properly. In order to avoid injury and property damage to users and others, please strictly observe the safety warnings and precautions.

| SIGN                                                                                             | MEANING                                                                                                                            |
|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
|  <b>Warning</b> | It means that if the regulations in this warning are not observed and misoperation is made, serious injury or death may be caused. |
|  <b>Danger</b>  | It means that if the regulations in this warning are not observed and misoperation is made, serious injury or death may be caused. |

The following signs are used to indicate important safety precautions when using the product.

| SIGN                                                                              | MEANING                                                         |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------|
|  | This figure indicates that it is not feasible and [prohibited]. |
|  | This figure shows the content that must be enforced.            |

 **WARNING**

Do not install and use this product in damp places. This product must be reliably grounded, and the reliable connection of AC socket ground wire to the ground should be ensured. The grounding wire should use a tripod socket. If you are not sure whether it has been reliably grounded, please ask a qualified electrician or maintenance personnel to check and confirm. Please ensure that the wiring of the power socket conforms to the national standard (zero on the left and fire on the right) and cannot be reversed.



This product must be connected to a special standard socket and wiring with a 120V~/60Hz load current of at least 10A, and the socket must be equipped with earth fault circuit breaker or earth leakage protector or similar high sensitive and fast leakage switch (rated sensitive current below 10mA).



It is forbidden to use the power extension cord or loose and unstable power socket, otherwise it may cause fire or electric shock.



Do not touch the product that has fallen into water or soaked in water, and immediately unplug the power plug.



The lit cigarettes and other combustibles cannot be put into the toilet cover, otherwise it may cause fire. It is forbidden to disassemble, repair or modify the product by yourself, otherwise it may cause fire or electric shock.



If the power cord is damaged, in order to avoid danger, it must be replaced by professionals from the manufacturer, its maintenance department or similar departments.



NOTE: Specialized tools may be necessary to install DeerValley Smart Toilet, plumbing not included.

# Installation and Owner's Manual

|  <b>WARNING</b>                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                   |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Please pull out the power plug when it thunders.</p>                                                                                                                                                                                                                                                 | <p>Do not use water other than tap water, otherwise it may cause skin inflammation and other problems.</p>                                                                                                                                     |
| <p>If the product function is abnormal or fails, please stop using it immediately and cut off the power supply, and contact the service provider in time.</p>                                                                                                                                           | <p>Do not stand on the ceramic toilet, and do not hit the ceramic with gravity to prevent damage and water leakage.</p>                                                                                                                        |
| <p>When used by people (including children) with physical, cognitive and intellectual disabilities or lack of experience and common sense, it is necessary to use this product under supervision, patients with heart disease should use it carefully. Do not let children play with this product.</p>  | <p>Do not put fingers or other objects into or block the drying air outlet, otherwise it may cause scald, electric shock or burn.</p>                                                                                                          |
| <p>If it is not used for a long time, the power supply and water supply must be cut off.</p>                                                                                                                                                                                                            | <p>It is forbidden to use other electrical appliances on the same socket.</p>                                                                                                                                                                  |
| <p>It is forbidden to disassemble, repair or modify the product by yourself, otherwise it may cause fire or electric shock.</p>                                                                                                                                                                       | <p>The socket shall be installed in a place that is not easy to be soaked by water. It is recommended to use waterproof socket.</p>                                                                                                           |
| <p>Banana water, gasoline, liquid medicine, detergent, insecticide, toilet cleaner and hard brush are prohibited to clean this product.</p>                                                                                                                                                           | <p>The new hose assembly and other attached or designated parts attached with the appliance shall be used for installation. The old hose assembly cannot be reused, otherwise, it may cause water leakage, fire or electric shock.</p>       |
| <p>Do not pour water or detergent on the machine body or power plug, otherwise it may cause fire or electric shock.</p>                                                                                                                                                                               | <p>When the product is moved indoors from a cold or wet place, it should be stored for 2 hours to fully volatilize the condensed water in the machine, and then it can be started for use, to avoid short circuit of products.</p>           |
| <p>This product is an electrical product. It is forbidden to put it in a place that is easy to be soaked by water. Do not pour</p>                                                                                                                                                                    | <p>Do not connect the water pipe with the outlet pipe of the water heater. The water inlet temperature is 41°F~104°F(5°C~40°C). If it exceeds the specified range, it may cause internal heating. The component does not work properly.</p>  |
| <p>Do not place the product where it may fall or be pulled into the bathtub or sink.</p>                                                                                                                                                                                                              | <p>Do not put this product in water or other liquids.</p>                                                                                                                                                                                      |
| <p>Do not put this product in water or other liquids.</p>                                                                                                                                                                                                                                             | <p>When using this product, do not lean back on the toilet cover to avoid damaging the product.</p>                                                                                                                                          |

**NOTE:** Drawings may not exactly define contour of the product.

# Installation and Owner's Manual

|  <b>WARNING</b>                                                                                                                                                                                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                     |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Do not place the product where it may fall or be pulled into the bathtub or sink.                                                                                                                                                                                                                                 | Please do not flush newsprint, paper urinal pads, women's sanitary napkins and other easily clogged items into the toilet.                                                                                                                                                       |
| Do not put this product in water or other liquids.                                                                                                                                                                                                                                                                | Do not use the product in an environment below 32°F(0°C). If the room temperature is lower than 32°F(0°C), the water in the water supply line of the product must be drained. Prevent the water way from freezing and cracking, causing water leakage or fire during later use.  |
| Do not touch the product that has fallen into water or soaked in water, and immediately unplug the power plug.                                                                                                                                                                                                    | To prevent damage caused by freezing, please take measures to keep warm and increase the temperature of the toilet.                                                                                                                                                              |
| It is forbidden to embed cementitious materials (cement mortar) into the base of the ceramic toilet, otherwise the ceramic toilet may be cracked due to expansion.                                                                                                                                                | When installing, disassembling, repairing and maintaining the product, you must unplug the power plug and close the water supply valve.                                                                                                                                          |
| Do not exert strong force or impact, do not stand on the seat ring, toilet cover or this product, and do not place heavy objects.                                                                                                                                                                                | Cleaning and user maintenance shall not be made by children without supervision.                                                                                                                                                                                               |
| Do not let the sun shine directly on the product to avoid discoloration and affect the reception effect of the remote control.                                                                                                                                                                                  | If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.                                                                                                                           |
| This appliance can be used by children aged from 3 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.  | The seat ring and toilet lid of this product would lower slowly. Do not press hard to avoid damaging it.                                                                                                                                                                       |

**NOTE:** Drawings may not exactly define contour of the product.

## ● Technical Specifications

|                             |                        |                                                                                                                  |
|-----------------------------|------------------------|------------------------------------------------------------------------------------------------------------------|
| Rated voltage               |                        | 120V~                                                                                                            |
| Rated frequency             |                        | 60Hz                                                                                                             |
| Rated power                 |                        | 950W                                                                                                             |
| Pressure of water supply    |                        | 20.31psi (minimum necessary water pressure) - 116.03psi (static pressure); Flow of water supply at least 7.93gpm |
| Ambient temperature         |                        | 32°F -104°F                                                                                                      |
| Temperature of water supply |                        | 41°F -104°F                                                                                                      |
| Toilet Flushing             | Flushing type          | Jet Siphon                                                                                                       |
|                             | Rough in               | 12in                                                                                                             |
| Cleansing                   | Water heating type     | Instant heating                                                                                                  |
|                             | Water heating power    | 1300W                                                                                                            |
|                             | Warm water temperature | Off, 86°F -102.2°F                                                                                               |
|                             | Safety device          | Temperature fuse, water temperature sensor, grounding protection, over-temp protection                           |
| Dryer                       | Min air volume         | ≥ 0.2m³/ min                                                                                                     |
|                             | Air heating power      | 250W                                                                                                             |
|                             | Dryer temperature      | Off, 86°F -122°F                                                                                                 |
|                             | Safety device          | Temperature controller, temperature fuse, leakage protection plug                                                |
| Heating seat                | Seat heating power     | 40W                                                                                                              |
|                             | Seat temperature       | 86°F -100.4°F                                                                                                    |
|                             | Safety device          | Temperature sensor, temperature fuse, temperature controller, grounding protection                               |
| Water proof rate            |                        | IPX4                                                                                                             |


### Note:

Rated Power: To determine the rated power of the product, it undergoes testing under specific conditions. These conditions include an ambient temperature of 73.4°F, static water inlet pressure of 26.1psi+/-2.9psi, and water inlet temperature of 59°F. During the testing, the water pressure, seat temperature, and water temperature are sequentially set to the highest level. The product then immediately initiates the rear wash function and continues to operate steadily for the duration of an average cleaning cycle. The power consumption during this cycle is measured to obtain the rated power value.

NOTE: Drawings may not exactly define contour of the product.


## ● Pre-installation

### Parts diagram




### Tools required

Please prepare the following required tools before installation.



Electric Drill



Caulk Gun



Teflon Tape



Knife



Spanner



Assorted  
Screwdrivers



Steel Tape




Measuring Glass


**NOTE:** Drawings may not exactly define contour of the product.

# Installation and Owner's Manual


## Hardware Included




Main unit




Remote control & Holder  
& Expansion screw set




Spare battery box




Wax ring




Angle valve



Installation accessories



User manual





Installation cardboard

**NOTE:** Drawings may not exactly define contour of the product.


## ● Installation

**Technical drawing** (unit: in)



### 1. Install the offered angle valve


Mark the center line of the drain outlet on the ground, and install the water inlet angle valve at a suitable position on the wall according to the size of the toilet. After installing the angle valve, open the valve to discharge the sewage.




### 2. Mark the drain with a cross line

#### Cardboard installation


- Align the cardboard with the center line of the drain ;
- Draw contour lines from cardboard.



### 3. Install the flange plate




### 4. Position correctly the two fixing bolts of the flange.




**NOTE:** Drawings may not exactly define contour of the product.

# Installation and Owner's Manual


**5. Assemble the mounting bracket with bolts and then install them to the pre-installed flange plate on the ground and lock tight with nuts.**




**6. Insert the wax ring under the toilet.**



**7. Install waxing ring into drain outlet; Install ceramic toilet on corresponding position according to contour line.**




**8. Put the screw through the fixing sleeve and then install it through the holes (on both sides of the toilet ceramic) to the mounting bracket on the ground, and lock tight with a tool, put the decorative cap on the fixing sleeve.**



## **9. Connect hose and angle valve**


As illustrated below, connect and securely tighten the inlet hose to the angle valve.



**NOTE:** Drawings may not exactly define contour of the product.


## 10. Install the battery box

1. Put battery (10pcs, 1.5V AA dry batteries, not included) in the battery box.
2. Connect the cable



## 11. Open the angle valve

Check the tightness of the threaded connection to make sure there is no water leakage. Turn the angle valve counterclockwise and adjust the opening to the maximum.



### REMINDER

When opening the angle valve for the first time, it may be a bit tight.

## 12. Power on

Plug the leakage protection plug into the power socket, press the reset switch, and the plug indicator light will be on, indicating that it is powered on.

\*It is applicable to the model with leakage protection plug.



### REMINDER

\*Press the leakage test key before use, the reset switch pops up, indicating leakage protection. The protection function is normal.

\*Press the TEST button (then RESET button) every month to assure proper operation.



The leakage protection plug is subject to the actual object.

## 13. Safety self-inspection

Upon power-up, the machine will automatically open the lid and seat, extend and retract the cleaning nozzle. Subsequently, the lid and seat will close, accompanied by a one-tone beep, signifying the completion of the self-inspection process.


NOTE: Drawings may not exactly define contour of the product.

## • Remote Control Installation and Battery Replacement


### Install remote control

#### 1. Install the remote control holder

(1) Stick the remote control rack horizontally to the pre-installation area on the wall, and mark the position of two installation holes on the wall with a marker. Use a drill bit with a diameter of 6mm to drill holes at the marked positions on the wall, with a depth of 1.4in.




(2) Install the expansion pipe into the wall hole, attach the hanger to the wall, align the hole on the hanger with the expansion pipe, and place the screw to lock it.




#### 2. Install the remote control holder (only for the hanger with fixed plate and foam rubber pad)


(1) Clean and dry the pre-installed area of the remote control rack on the wall.



(2) Tear off the double-sided adhesive sticker on the back of the hanger and stick it horizontally to the wall.




#### 3. Install the battery into the remote control, and place it on the rack



#### 4. Use and replacement of remote control battery

· The remote control uses 2 AAA alkaline batteries.




#### Attention

1. The positive and negative electrodes of the battery must match those on the remote control.
2. New and old batteries cannot be mixed.
3. Please use alkaline battery.

**NOTE:** Drawings may not exactly define contour of the product.

## • Side Rotated Knob Operation



### **Flush/Stop**

Under non-functional status, press this button to perform flushing function.

While machine is running functions, press this button to stop on-going procedure.

Note: Under non-seated situation, long press this button to enter standby mode, in which mode the night light automatically off. Press any button to quit standby mode.

### **Rear wash**


Press this button to perform rear wash. Press twice to perform oscillating massage.

### **Front wash**

Press this button to perform front wash. Press twice to perform oscillating massage.

**NOTE:** Drawings may not exactly define contour of the product.

## • Remote Control Instructions



### Stop

1. Short press stop button to cease on-going functions halfway.
2. Long press stop button for 5 seconds to enter ECO mode.
3. Long press stop button for 5 seconds to exit ECO mode.



### Flush

Short press this button to perform the half flush function. Long press this button to perform a full flush function.



### Rear Wash

Press this button to start the rear wash function. Press this button again to perform an oscillating massage. If you press the Stop key halfway, you can stop it immediately. Note: Under the oscillating massage procedure, the nozzle will extend and retract repeatedly to achieve the massage effect.



### Front Wash

Press this button to start the front wash function. Press this button again to perform an oscillating massage. If you press the Stop key halfway, you can stop it immediately. Note: Under the oscillating massage procedure, the nozzle will extend and retract repeatedly to achieve the massage effect.



### Dryer

Press this button to perform warm air drying. The air temperature can be adjusted. If it is pressed to the "stop" button on the way, the air drying can be stopped immediately.



### Water Pressure

When cleaning, press this button to adjust the water pressure in 5 different gears. Press the "+" key once to raise one level, and press the "-" key, once to decrease one level. The indicator light will display accordingly.



### Nozzle Position

The nozzle position can be adjusted with 5 gears. Press the nozzle adjustment ^ key to extend the nozzle forward, press the nozzle adjustment v key to retract the nozzle backwards.

**NOTE:** Drawings may not exactly define contour of the product.



## Water Temp

When cleaning, the water temperature is adjustable with 6 gears. When in off gear, the water flows in ambient temperature and the indicator light is off.



## Air Temp

When drying, the air temperature is adjustable with 6 gears. When in off gear, it blows in ambient temperature and the indicator light is off.



## Seat Temp

The seat temperature is adjustable with 6 gears. Please do not cover the seat sensor in case of sensing failure. The seat temperature will switch to 1st gear after long time sitting in case of low-temperature burns.

## Top view of remote control



## Massage

When performing rear washing and front washing functions, press the massage button on the remote control to enter the pulse massage mode.



## Night Light

Press this button to switch the night light to three modes: auto sensing mode, and on, off mode.

Note: under the auto mode, the night light will turn automatically on when the lid is opened. And the night light will automatically off when the lid is closed.



## Open/Close S&C

1. When the lid and seat are closed, press this button to open lid and seat.
2. When the lid is open and seat is closed, press this button to open seat.
3. When the lid and seat are open, press this button to close seat.

**NOTE:** Drawings may not exactly define contour of the product.

## Control function setting

### 1. Night Light

Short press the "Night Light" button to toggle between auto-sensing ,on,off model.

Note: Under auto-sensing mode, the night light will automatically turn on when the lid is opened.It will also turn off automatically when the lid is closed.So auto-sensing mode need opting for an electronic toilet with the automatic open/close lid function.

Long-press "Night Light" button to turn on or off the display and ambient lights.

(Applicable for models with this function)

### 2. Nozzle manual cleaning function

·Long-press the "Stop" button and "Rear Wash" button on the remote control at the same time to enter the manual cleaning procedure.

·During the manual cleaning process, press the "Stop" button on the remote control or knob to exit the manual cleaning mode and the nozzle will retract;

### 3. Nozzle automatic cleaning function

- Long-press the "Stop" button and "Front Wash" button on the remote control at the same time to enter the nozzle automatic cleaning mode

- During the automatic cleaning process, once human seated, it will exit the automatic cleaning mode.

### 4. Mute function

- Long-press the "Stop" button and "Dryer" button on the remote control at the same time to enter the mute mode.

- The buzzer function is off in mute mode.

### 5. Remote control match code

Long-press the "Front Wash" button on the remote until five indicator lights flash simultaneously

Before the device is powered on.After powering on and sucessfully pairing,exit the mode by pressing "stop" button on the remote control waiting for 10 seconds.The 5 indicators stop flashing.

### 6. Auto-temperature adjustment

① Long-press the "Seat Temp" button to turn on/off smart temperature sensing function.

② The temperature sensor detects the actual ambient temperature and automatically ajusts the seat, wind,water temp to optimal temperature.Or use the remote control to set your preferred temperature while seated.

**NOTE:** Drawings may not exactly define contour of the product.

## 7. Automatic flush after leaving the seat

Long-press the "Flush (or Half Flush)" button and "Rear Wash" button on the remote control to turn on or off "auto-flush upon leaving" the function.

## 8. Automatic flush after closing the seat

Long-press the "Water Pressure +" button and "Nozzle Position ^" button to turn on or off the "auto-flush after closing the seat" function.

## 9. Switch to temperature unit

Long-press the "Water Temp" button and "Wind Temp" button to switch the temperature unit on display. (Available for °F and °C)

## 10. Pre-wetting function

Long-press the "Rear Wash" button to turn on/off the pre-wetting function.

## 11. ECO mode

① Long-press the "Stop" button on the remote control to enter or exit the ECO mode.

(The ECO mode is default off)

② In ECO mode, the seat temp drops to level 1, It will exit the ECO mode when someone sits down, all function are in normal; It will enter the ECO mode when leaving the seat.

## 12. Automatic open/close lid function

Long-press the "Night Light" button and "Open/Close Seat" button on the remote control at the same time, hear one beeps to confirm the auto-open lid function is on, two beeps to confirm the auto-open lid function is off.

## 13. Adjust microwave sensing distance

Long-press the "Stop" button and "Seat Temp" button on remote control, the beeper will beep to indicate the active mode:

① one beep: short-distance mode (approximately 19.69 in)

② two beeps: mid-distance mode (approximately 27.56 in)

③ three beeps: long-distance mode (approximately 39.37 in)

PS: Set to mid-distance by default.

## 14. Flushing interval


After flushing, it will take a while (more than 45 seconds) before flushing again (due to water tank refilling). During the flushing process and the interval, the flushing command will not be responded to, and the buzzer will sound an invalid tone.

**NOTE:** Drawings may not exactly define contour of the product.

## ● Automatic Function


### 1. AUTOMATIC OPEN/CLOSE LID FUNCTION (Suitable for models equipped with this feature)

When opting for an electronic toilet with the automatic open/close lid function, experience the ease of hands-free operation for both the toilet lid and seat.



#### 1. Auto Open


As soon as the toilet senses the proximity of a person, the lid will automatically open following the detection of human movement.



#### 2. Auto Close


If the toilet remains unused for more than 60 seconds after the last use, the toilet lid and seat will close automatically.

### 2. Automatic flush after leaving the seat



Under the automatic flush mode, when the user is detected staying on the seat for 10-30 seconds, it will perform half flush function after user leaving seat; when the user is detected staying on the seat for  $\geq 30$  seconds, after the user leave the seat for  $5 \pm 1$  seconds, it will perform the full flush function automatically.


### 3. Foot Sensor Operation (Applicable for models with this function)



1. When both the lid & seat are closed, foot closes sensor to flip the lid, then activate the foot sensor again to flip the seat. After toileting, activate the foot sensor to close the seat and lid, and execute the bowl flushing.
2. When only lid is open, activate the foot sensor to flip the seat. After toileting, activate the foot sensor to close the seat and lid, and execute the bowl flushing.
3. When both the lid & seat are open, activate the foot sensor to close the seat and lid, and execute the bowl flushing.
4. When opting for an electronic toilet without the automatic open/close lid function, after toileting, activate the foot sensor to execute the bowl flushing.

**NOTE:** Drawings may not exactly define contour of the product.

## ● Daily Maintenance



### Maintenance of body

#### 1. Cut off the power supply

Please cut off the power supply before maintenance.

#### 2. Wipe with soft cloth

Please wipe the dirty parts with a soft damp cloth and then let it dry.

#### 3. Safety self-inspection

Please reconnect the power supply after cleaning.

### Nozzle maintenance

#### 1. Nozzle extends


Press and hold the "Stop" button and "Rear wash" button on the remote control for 3 seconds at the same time to enter the manual cleaning procedure.

#### 2. Nozzle cleaning


Please wipe with a soft cloth or soft brush.

#### 3. Cleaning is completed

Press the "Stop" button to exit the manual cleaning mode and the nozzle will retract automatically.



### Filter screen cleaning



**NOTE:** Drawings may not exactly define contour of the product.

## Drain the water in the pipeline when not in use for a long time

1. Pull out the power plug to cut off the power.
2. Close the inlet angle valve, unscrew the hose from the angle valve, drain the water in the pipeline and reinstall it.

For safety, it is recommended to put antifreeze into the accumulated water in the toilet.




### TIPS

Before opening the angle valve, the power must be cut off! When using the toilet again, be sure to connect water supply first, then plug in.




## When water and electricity are cut off

1. Flushing during power outage (under the condition that the spare battery box is connected and has filled battery). Long press the side button to flush.



2. Flushing during water outage

Flush the toilet with external water (pour approx. 2 gallons water into the bowl). Beware of overflow.



**NOTE:** Drawings may not exactly define contour of the product.

## ● Troubleshooting

| Product part or function | Phenomenon                         | Cause                                                | Solutions                                                                 |
|--------------------------|------------------------------------|------------------------------------------------------|---------------------------------------------------------------------------|
| Complete machine         | Not working                        | Whether the power supply is off                      | Power on                                                                  |
|                          |                                    | Whether the leakage protector is off                 | Press the leakage switch again                                            |
|                          |                                    | Power failure or not                                 | Wait for power supply                                                     |
| Rear wash / Front wash   | Not working                        | Whether the water supply switch is on                | Turn on the water supply switch                                           |
|                          |                                    | Whether the water supply is cut off                  | Wait for water supply to recover                                          |
|                          |                                    | Whether the nozzle is blocked by foreign matters     | Remove foreign matters and manually clean the nozzle                      |
|                          |                                    | No skin contact with seat sensor                     | Re-adjust sitting position to ensure skin contact with sensor             |
|                          | Low water pressure                 | Is the water pressure gear set to low gear           | Reset the water pressure gear                                             |
|                          |                                    | Whether the water supply channel is normal           | Clean the filter screen at the water supply outlet and supply water again |
|                          | Water temperature is low           | Whether the water temperature is set to low gear     | Reset the water temperature gear                                          |
|                          | Stop water halfway                 | Whether the automatic stop time is exceeded          | Re-execute the function                                                   |
|                          |                                    | No skin contact with seat sensor                     | Re-adjust sitting position to ensure skin contact with sensor             |
| Warm air drying          | Low heating temperature            | Whether the wind temperature gear is set to low gear | Reset the water temperature gear                                          |
|                          | Half-way stop                      | Whether the automatic stop time is exceeded          | Re-execute the function                                                   |
|                          |                                    | No skin contact with seat sensor                     | Re-adjust sitting position to ensure skin contact with sensor             |
| Seat ring heating        | Insufficient seat ring temperature | Is the seat temperature gear set to low gear         | Reset the seat temperature gear                                           |
| Deodorization            | Not working                        | No skin contact with seat sensor                     | Re-adjust sitting position to ensure skin contact with sensor             |
| Remote control           | No reaction                        | Objects cover the sensing window                     | Remove the objects                                                        |
|                          |                                    | Incorrect use angle and sensing distance             | Adjust angle and distance                                                 |
|                          |                                    | Batteries run out                                    | Replace with new batteries                                                |

**NOTE:** Drawings may not exactly define contour of the product.

## LIMITED WARRANTY COVERAGE

### 1 YEAR LIMITED WARRANTY

DeerValley products are made with quality materials and excellent craftsmanship to provide the customers a long-lasting product. In the case of any defects in materials or craftsmanship under regular use were inspected in the first one year of delivery, DeerValley will provide replacement parts at no charge, or at its option, replace any product or part of the product that is deemed defective, under normal installation, use, service and maintenance. This warranty applies only to the original purchaser. Proof of purchase will be required in the case of a claim. **SCRATCHES ARE NOT COVERED UNDER WARRANTY.**

The manufacturer warrants this product to be free of manufacture defects during the above mentioned warranty time. Please keep a copy of the original invoice as proof of purchase.

DeerValley will, as its option, (1) repair or replace the defective part(s) or product(s) at no charge; (2) issue a refund of the original purchase price of the product(s) (Valid within 30 days from the date of delivery); or (3) issue a credit to be applied toward the purchase of a new DeerValley product shipping/delivery charges may apply and are in DeerValley sole discretion.

DeerValley recommends the installations to be made by a licensed, professional plumber. DeerValley will not be held responsible for any damage or product failure due to improper installation, misuse, or failure to use a licensed professional. DeerValley is not responsible for any removal or installation cost.

This limited warranty shall not apply to goods which have been subject to accident, negligence, improper installation, product abuse, product misuse, or use of cleaners containing abrasives, alcohol or other organic solvents, whether performed by a contractor, service company, or yourself, are excluded from this warranty.

DeerValley responsibility under this limited warranty is limited to only to replacement parts and no other costs. DeerValley will not be responsible for labor charges and/or damage incurred by installation, repair or replacement, nor for any indirect incidental or consequential damages, losses, injury or costs of any nature relating to this product Except as provided by law, this limited warranty is in lieu of and excludes all other warranties, conditions, and guarantees, whether expressed or implied, statutory or otherwise, including without restriction those merchantability of fitness for use.

### RESPONSIBILITIES OF OTHERS

Inspecting the unit prior to installation is the responsibility of the installer or building contractor who acts on behalf of the user. They are responsible for ensuring the unit is free of defect or damage.

Notices are placed on and in the unit and on the shipping carton advising the installer of this responsibility.

In the event of a problem, the unit must not be installed. DeerValley is not responsible for failures or damage that could have been discovered, repaired, or avoided by proper inspection and testing prior to installation.

Damage occurring in transit is the responsibility of the carrier. The user or installer **MUST** open the crate and inspect the unit for damage when it is delivered. If damage is discovered, it must be reported immediately to the seller and the carrier in writing, and an inspection requested. Failure of the carrier to respond should be reported to the seller and the carrier. Your freight claims should be filed promptly thereafter.

### LIMITATIONS AND EXCLUSIONS

This warranty does not cover instances of negligence, misuse, abuse, improper installation, carelessness, accident, hard water or mineral deposits, exposure to corrosive materials, misapplication, damages caused by improper maintenance, alteration of the product, or failure to follow care or installation instructions enclosed with your product. This warranty is void if the DeerValley is subject to alteration, or if repairs are attempted by anyone other than an authorized agent of DeerValley. This warranty does not extend to plumbing or components installed by dealers, installers or by any party other DeerValley.

DeerValley will not be liable for loss of use of the DeerValley inconvenience, or any other incidental or consequential costs, expense or damages. Please note that some states do not allow the exclusion or limitation of incidental damages.

### DISCLAIMER

Except as expressly provided, there shall be no warranty or obligation, express or implied, oral or statutory. No dealer or other person has the authority to make any warranties or representations concerning DeerValley or its products. In no event shall DeerValley be held responsible for any such warranties or representations.

### WARRANTY SERVICE

NOTE: When requesting warranty, be sure to have the following:

- Copy of original invoice
- Date of installation
- Description and pictures of defect
- Model number or description of model

To obtain warranty service and replacement part, please contact DeerValley Customer Service. DeerValley will determine whether to repair or replace your product, issue a refund, or issue a credit.