


The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.

Components Name




When door is crooked




Please take the following steps to adjust first.

- 1 Rotate the "front and rear screws" to the left




※ After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right slightly.


- 2 Push the door to the cabinet




- 3 Rotate the "front and rear screws" to the right



When door is leaning




- 1 Turn "internal & external screw" to the left can make the top of the door tilted outward.




Protruding to the upside






- 1 Turn "internal & external screw" to the left can make the bottom of the door tilted outward.



When 2 doors are not tight




- 1 Turn "internal & external screw" to the right can make the door approach inside. Please adjust the doors little by little.




※ If the 2 doors are overlap, please turn the "internal & external screw" to the left.


When the door is higher on top




- 1 Turn "up & down screw" to the left



- 2 Lower the door's height so that 2 doors are of the same height.



- 3 Turn "up & down screw" to the right



※ If the door is lower on bottom, please lift up the left door slightly on step 2