




INSTRUCTION



Single Handle Pull out Kitchen Faucet
Model no: UF1200X

Tools:


- Adjustable Wrench
- Pliers
- Pipe Wrench
- Screwdriver
- Teflon Tape




Maintenance:

Your new Kitchen faucet is designed for years of trouble-free performance. Keep it looking new by cleaning it periodically with a soft cloth. Avoid abrasive cleaners, steel wool and harsh chemicals as these will dull the finish and void your warranty.


Preparation / Assembly




Shut off water supplies. Remove old faucet. Clean sink surface in preparation for new faucet.



Place Escutcheon (1) or Flange (2) on bottom of new faucet (Optional). Position Faucet through mounting hole .




Assemble Washer(1),and thread Mounting Nut(2) onto Shank(3) from underside of sink.Handtighten.Secure Locking Screws(4) on Mounting Nut(2) and tighten Locking Screws(4) using screw driver.




Install Weights(1) onto spray hose (2).Connect hose to outlet tube(3) and tighten. Do not overtighten.


WARNING: BE SURE TO INSTALL THE WASHER(4).



(A) Stainless Steel Braided Faucet Supply Tubes: This is the simplest of all installations. If you are using stainless steel braided faucet supply tubes, this faucet requires one end of the supply tube to have a 1/2" female IPS connection. The other end of this supply tube must match the thread on the water supply fittings or shut off valve under your sink. Once you have identified the required tube, carefully follow the manufacturer's installations instructions for each tube




(B) Ball Nose Flexible Supplies: If you are using ball-nose flexible supplies to connect the faucet to water supply lines: Slip coupling nut behind ball-nose of flexible supply tube. Ball nose coupling will go partially into IPS shank or fitting. Tighten coupling nut (DO NOT OVER TIGHTEN). Install opposite end according to manufacturer's instructions for both tubes.



Important: After installation is completed. Turn on water supply and allow both hot and cold water to run for at least one minute each. Check all connections for leaks. Re-tighten if necessary, but do not overtighten.Reinstall Spray head. Your new faucet is now ready to use.

Exploded Drawing RP(Replacement Parts)



Limited Lifetime Warranty

Ultra Faucets warrants to the original purchaser that its products will be free from defects in workmanship and materials. All Ultra Faucets are provided with a life time limited warranty. This warranty does not cover any other labor or service charges associated with the removal, repair, or reinstallation of Ultra Faucets products. This express warranty does not apply to products that have been damaged as a result of misuse, abuse, negligence, accident, faulty installation or maintenance practices and/or used in any manner contrary to those recommended by the manufacturer.