



3-LIGHT VANITY BAR




PACKAGE CONTENTS



PART	DESCRIPTION	QUANTITY
A	Fixture	1
B	Socket ring (preassembled to Fixture (A))	3
C	Backplate (preassembled to Fixture (A))	1
D	Glass shade	3

HARDWARE CONTENTS (shown actual size)



! SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

! WARNING

- TURN OFF ELECTRICITY at main fuse box (or circuit breaker box) before beginning installation by removing fuse (or switching off circuit breaker).
- MINIMUM 90°C SUPPLY CONDUCTORS.

CAUTION

- CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.
- If in doubt about electrical installation, consult a licensed electrician.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 25 minutes

Tools Required for Assembly (not included): Flathead screwdriver, Phillips screwdriver, Pliers, Electrical tape, Wire cutters, Safety glasses, Drill and 5/16 in. drill bit.


Helpful Tools (not included): Wire strippers.

ASSEMBLY INSTRUCTIONS



1. Remove the backplate (C) from the fixture (A) and then hold it against the wall and mark the position of the holes through the backplate (C). **Note:** Make sure fixture (A) is being mounted to a secure surface.




2. Using a 5/16 in. drill bit (not included), drill pilot holes at marked locations. For masonry installations, insert wall anchors (EE) into the holes. Otherwise, attach backplate (C) to wall using machine screws (DD) and use mounting screws (CC) to secure it to the outlet box. **Note:** Make sure the narrow end of the keyhole slots on backplate (C) slide down over the screw heads.



Hardware Used

- CC** Mounting screw  x 2
- DD** Machine screw  x 4
- EE** Wall anchor  x 4


3. Strip 3/4 in. of insulation from wire ends. Twist stripped ends together with pliers (not included), black to black (power) and white to white (neutral). Attach copper wire to ground wire. **Helpful hint:** If necessary, attach copper ground wire to grounded outlet box.




ASSEMBLY INSTRUCTIONS

4. Attach wire nuts (BB). Tape wire nuts (BB) and wires together.

Hardware Used


- BB** Wire nut  x 3



5. Place the fixture (A) onto the backplate (C), and secure with cap nuts (AA). **Note:** The fixture (A) can be installed with the sockets facing up or down.


Hardware Used


- AA** Cap nut  x 2



6. Remove socket rings (B) from sockets of fixture (A) with tool (FF). Install glass shades (D) over sockets, securing with socket rings (B). Tighten socket rings (B) with tool (FF).


Hardware Used

- FF** Tool  x 1



ASSEMBLY INSTRUCTIONS

7. Install light bulbs (not included). Use 60-watt max. standard-base incandescent bulbs or halogen/ CFL/LED equivalents.



CARE AND MAINTENANCE

- Shut off main power supply before wiping product with damp cloth or window cleaner. Do not use abrasives.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Bulb won't light.	1. Bulb is burned out. 2. Power is off. 3. Faulty wire connection. 4. Faulty switch.	1. Replace light bulb. 2. Make sure power supply is on. 3. Check wiring. 4. Test or replace switch.
Fuse blows or circuit breaker trips when light is turned on.	Crossed wires or power wire is grounding out.	Check wire connections.

WARRANTY

The manufacturer warrants all of its lighting fixtures against defects in materials and workmanship for one (1) year from the date of purchase. If within this period the product is found to be defective in material or workmanship, the product must be returned, with a copy of the original sales receipt as proof of purchase in the original carton, to the place of purchase. The manufacturer will, at its option, repair, replace or refund the original purchase price to the consumer. This warranty does not cover fixtures becoming defective due to misuse, accidental damage, improper handling and/or installation and specifically excludes liability for direct, incidental or consequential damages. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state.

PART	DESCRIPTION
AA	Cap nut
BB	Wire nut
CC	Mounting screw
DD	Machine screw
EE	Wall anchor
FF	Tool

