


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY





DIFFICULT

Tools Required For Assembly:

Allen Wrench



Phillips Screwdriver



2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.

BASIC ASSEMBLY TECHNIQUES



When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.



Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.












FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List



	#1 x 1pc Headboard
	#2 x 2pcs Headboard Legs (L&R)
	#3 x 1pc Footboard
	#4 x 2pcs Footboard Legs
	#5 x 3pcs Ø1/4" Drawer Support Leg 32 x 32 x 150mm
	#6 x 2pcs Side Rails
	#7 x 1set Slat Kit (13pcs)
	#8 x 1pc Support Rail
	#9 x 3pcs Ø1/4" Support Leg 32x32x357mm


Hardware List

	#A x 6pcs Bolt Ø5/16" x 1-3/4"
	#B x 6pcs Lock Washer Ø5/16"
	#C x 6pcs Flat Washer Ø5/16"
	#D x 1pc Allen Wrench M4
	#E x 2pcs Bolt Ø1/4" x 1-1/4"
	#F x 2pcs Lock Washer Ø1/4"
	#G x 2pcs Flat Washer Ø1/4"
	#H x 8pcs Wood Screw #8 x 1-3/16"
	#I x 2pcs Wood Dowel



#A x 6pcs
#B x 6pcs
#C x 6pcs
#I x 2pcs







Attach support legs (#5) to the holes at the bottom of the footboard (#3).
Adjust adjustable foot according to the ground level.



Hook the side rails (#6) to the latch of the headboard (#1) and footboard (#3).
Make sure it is firmly in place.






Attach support legs (#9) to the holes of the support rails (#8).
Adjust adjustable foot according to ground level.



Prepare 2 bolts assembly by inserting lock washer (#F), then flat washer (#G) onto bolts (#E).
Align slats (#7) to the holes of the support rail (#8). Secure with bolts (#E).

#E x 2pcs
#F x 2pcs
#G x 2pcs








#7

Secure slats (#7) to the side rails (#6) with screws (#H).

#H x 8pcs



#8



ASSEMBLY IS COMPLETED