

29" Folding Fire Pit



WARNING



FOR YOUR SAFETY

**For Outdoor Use Only
(outside any enclosure)**

WARNING



FOR YOUR SAFETY:

1. Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage.
2. Read the installation, operation, and maintenance instructions thoroughly before installing or servicing this equipment.
3. Failure to follow these instructions could result in fire or explosion, which could cause property damage, personal injury, or death.

****Save these instructions for future reference.****

Before You Begin



Check to make sure you have the following:

Parts List

1. Handle
2. Fire Screen
3. Cooking Grill
4. Wood Grate
5. Bottom Bowl with Leg Assembly
6. Fire Pit Lift Tool
7. Carry Bag

Hardware

A. Nut (M6 Black Nickel Plated Hex Nut)



Preparation

- Remove all parts from packing and check to make sure you have all parts described in “Before You Begin” section above.
- Spread out parts on a soft, level surface to avoid scratching parts.

Assembly Instructions

1. Pull on ring attached to pin on leg assembly of bottom bowl (5) and fold leg down until end of pin slides into hole on bottom bowl. Release ring and leg should be fully extended and locked in place. Repeat with other 3 legs.
2. Attach handle (1) to fire screen (2) using nut (A).
3. Place wood grate (4) into bottom bowl (5).
4. Place cooking grill (3) into bottom bowl (5).
5. Place fire screen onto the bottom bowl.
6. To fold up fire pit, wait until fire is out and fire pit has completely cooled. Remove ashes and all grills/grates and fire screen. Pull on ring until pin slides out of hole and then fold leg up against bottom bowl. Repeat with other 3 legs.

Warning

1. This appliance is for outdoor use only, and shall NOT be used in a building, garage or any other enclosed area.
 2. Do NOT use this fire pit for indoor heating. TOXIC carbon monoxide fumes can accumulate and cause asphyxiation.
 3. This fire pit is NOT for commercial use.
 4. This fire pit is NOT to be operated by children.
 5. This fire pit is NOT to be used in or on boats or recreational vehicles.
 6. Always use in accordance with all applicable local, state and national codes. Contact your local fire department for details on outdoor burning.
 7. When using this fire pit, exercise the same precautions you would with any open fire.
 8. The use of alcohol, prescription or non-prescription drugs may impair the consumer's ability to properly assemble or safely operate this fire pit.
 9. Do NOT use this fire pit without reading the entire "Owner's Manual".
 10. This fire pit is for use with dry, seasonal hardwood. It will burn hotter, more completely and create less smoke.
 11. Do NOT burn charcoal briquets, lump charcoal, manufactured logs, driftwood, trash, leaves, paper, cardboard, plywood, painted or stained or pressure treated wood. Avoid using softwoods such as pine or cedar that can throw sparks.
 12. Do NOT alter this fire pit in any manner.
 13. Do NOT use this fire pit until it is COMPLETELY assembled and all parts are securely fastened and tightened.
 14. Do NOT store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other appliance.
 15. Do NOT store or use an LP gas cylinder within 10 feet (3.05m) of this fire pit while it is in operation.
 16. Do NOT use this fire pit near automobiles, trucks, vans or recreational vehicles.
 17. Do NOT use in an explosive atmosphere. Keep outdoor area clean and free from combustible materials, gasoline and other flammable liquids.
 18. Do NOT use this fire pit under any overhead or near any unprotected combustible constructions. Avoid using near or under overhanging trees and shrubs.
 19. Always use this fire pit on a hard, level non-combustible surface such as concrete, rock or stone. An asphalt or blacktop surface may not be acceptable for this purpose. Do NOT use on wooden decks.
 20. Always empty this fire pit before each use.
 21. Do NOT wear flammable or loose clothing when operating this fire pit.
 22. Do NOT use in windy conditions.
 23. Do NOT use this fire pit unless fire screen is securely in place.
 24. Do NOT use gasoline, kerosene, diesel fuel, lighter fluid or alcohol to light or relight fires.
 25. Keep all electrical cords away from a hot fire pit.
 26. All surfaces of this fire pit are hot when in operation. To avoid burns, do NOT touch fire pit until it has completely cooled unless you are wearing protective gear (Potholders, gloves, BBQ mittens, hot pads & etc.). Never touch ashes or coals to see if they are hot.
 27. Do NOT leave a lit fire pit unattended, especially around children and pets.
 28. Do NOT attempt to move or store this fire pit until all ashes and coals are completely extinguished.
 29. Do NOT remove ashes or coals until they are completely and fully extinguished.
 30. Use heat-resistant gloves or hot pads when contacting handles.
 31. Use long, sturdy firepit tools when adding or moving logs.
 32. Do NOT place wood directly into bottom of the fire pit. Place wood only on the wood grid.
 33. Do NOT overload the fire pit. Do not add additional firewood until the fire burns down. NOTICE: If any portion of the bowl lid or spark guards of this fire pit are glowing red it is overloaded.
 34. Do NOT lean over this fire pit when lighting or when in use.
 35. Do NOT place a hot fire screen or hot fire pit tools onto combustible surfaces such as grass, wooden deck or furniture.
 36. Avoid breathing smoke from the fire and avoid getting it into your eyes.
 37. This fire pit should be thoroughly inspected and cleaned on a regular basis.
 38. After a period of storage and/or non-use, check for signs of damage and creosote build-up. Do NOT operate until necessary repairs and/or cleanup are executed.
 39. Deaths, serious injury or damage to property may occur if the above is not followed exactly.
- CAUTION:** It is not recommended to use this fire pit (fire place) on a wooden or other combustible surface or any surface that is not entirely resistant to high heat. However, if you intend to use this item on a wooden deck or other combustible surface or any surface that is not entirely resistant to high heat, you must use a non-flammable and heat resistant material such as concrete pavers, brick or stone between the fire pit (fire place) and the surface.

Cleaning and Care

Inspecting:

This outdoor fire pit should be inspected on a regular basis to ensure product safety and longer product life.

Do NOT attempt to inspect this outdoor fire pit until the fire is COMPLETELY out and fire pit is COOLED COMPLETELY.

1. Check handle on Spark Guard/Firescreen to make sure it is secure.
2. Check all parts for signs of damage or rust.
3. If you find any damaged parts, do NOT operate until repairs and/or replacement has been done.

Cleaning

This outdoor fire pit should be cleaned on a regular basis to promote a safer experience and longer product life.

NOTE: After repeated use, a slight discoloration of the finish may occur.

Do NOT attempt to clean this outdoor fire pit until the fire is COMPLETELY out and the fire pit has cooled completely.

Do NOT use oven cleaner or abrasive cleaners as they will damage this product.

Do NOT clean any part of this outdoor fire pit in a self cleaning oven as it may damage the finish.

1. Wipe exterior surfaces with a mild dishwashing detergent or baking soda.
2. For stubborn surfaces, use a citrus based degreaser and a nylon scrubbing brush.
3. Rinse with clean water.
4. Remove built-up creosote from components with a chimney cleaning product.

Storage

Do NOT move or store this outdoor fire pit until the fire is COMPLETELY out and the fire pit has cooled COMPLETELY.

1. Once the fire is out, coals are cold and outdoor fire pit is cool to the touch, remove ashes and dispose of properly.
2. **It is best to cover the outdoor fire pit with a protective vinyl cover.**
3. Store assembled in a location away from children and pets.

NOTE: If you do not use a protective cover for your fire pit, then store this outdoor fire pit in a dry location to maximize product life.