

Thank you for choosing this product.

Your complete satisfaction is our top priority.

Customer Service and Warranty Information

- **For Warranty Assistance:**

If you experience any issues or require additional information regarding your warranty, please do not contact the place of purchase. Instead, reach out directly to our Customer Service Team or visit our website for prompt support.

- **Warranty Coverage:**

We warrant its products to the original purchaser against defects in materials or workmanship. A defect is defined as any flaw that impairs the normal use of the product. This warranty is limited to the replacement of defective parts or components and is valid for one (1) year from the date of purchase.

- **Warranty Limitations:**

This warranty covers products used under normal household conditions. It does not apply to furniture used outdoors or damage resulting from improper assembly or disassembly, product modification, intentional damage, accidents, misuse, exposure to elements, or any labor or assembly costs.

- **Additional Terms:**





We reserve the right to require proof of purchase to process any warranty claim. We are not liable for any incidental or consequential damages arising from the misuse of our products.

ASSEMBLY GUIDE

2 SHAKER DOORS, 2 SOLID WOOD DOORS, 2 CLEAR GLASS DOORS, 2 FROSTED GLASS DOORS


White
Mocha
Gray
Black
Teal
Yellow

Aqua
Green
Sage
Beige
Navy Blue
Antique Blue



REV - 09/2025

PH #2



page 2/9


Before You Begin Assembly

- Carefully inspect the package contents. A complete parts checklist is provided below.
- If any parts are missing or damaged, please contact us for assistance.





Assembly Tips

- Assemble the item on a flat, smooth surface. We recommend placing a blanket or protective covering underneath to prevent scratches.
- Use a power drill **only at a low-speed setting** to avoid damaging components.
- Assemble the product as close as possible to its final location to minimize the need for moving it later.
- Important: The hardware pack contains small parts that may pose a choking hazard.
Keep all small items out of reach of young children.

PARTS LAYOUT



Screws Are Illustrated at Actual Size for Accurate Reference

A44	 3,5x14	16+1
A25	 M4x25	02+1
F10		04
H4		02




WARNING:
CHOKING HAZARD


Contains small parts - choking hazard.
Adult supervision is required during assembly.
Not suitable for children under 3 years of age.

01)

If the hinge (F10) is detached, attach it to the hinge plate by aligning and pushing it in until it clicks securely into place.






F10





click!




Set the adjustment screw to the midpoint height position before installing the hinges



02)



A44



3,5x14




08

F10




04

03)



You may need to adjust the hinges (F10)
before installing the door



A44




3,5x14

04


04)



You may need to adjust the hinges (F10)
before installing the door




A44



3,5x14

04


05)







A25		02	H4		02
-----	---	----	----	---	----

M4x25


06) Adjusting Misaligned Doors




07) Aligning Doors with Side Panels



Loosen
rear screw







Move Forward
or Backward




Re-tighten
rear screw


08) Aligning Doors with the Top



Loosen top and bottom
screw on all hinges.



Adjust Height:
Move Up or Down



Re-tighten screws
on all hinges.