


PRESTO®

Tilt'nDrain™ BigGriddle® *cool-touch griddle*



- Huge cooking surface—cooks up to 50% more than other jumbo griddles.
- Easily adjusts from a level grilling surface for eggs and pancakes to a tilted surface for meats.
- Cool-touch base surrounds the grilling surface on the front and both sides.

Estas instrucciones también están disponibles en español. Para obtener una copia impresa:

- Descargue en formato PDF en www.GoPresto.com/espanol.
- Envíe un correo electrónico a contact@GoPresto.com.
- Llame al 1-800-877-0441, oprima 2 y deje un mensaje.

Visit us on the web at www.GoPresto.com

©2018 National Presto Industries, Inc.

INSTRUCTIONS

This is a  Listed appliance. The following important safeguards are recommended by most portable appliance manufacturers.

IMPORTANT SAFEGUARDS

To reduce the risk of personal injury or property damage when using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse the heat control, cord, or plug in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from the outlet when not in use and before cleaning. Allow the griddle to cool before putting on or taking off parts, and before cleaning.
6. Do not operate any appliance with a damaged cord or plug or in the event the appliance malfunctions or has been damaged in any manner. Do not operate if the legs and/or cool-touch base become cracked or damaged. Return the appliance to the Presto Factory Service Department for examination, repair, or electrical or mechanical adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries. Use only genuine Presto™ accessory attachments or replacement parts.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner or in a heated oven.
11. It is recommended that this appliance not be moved when it contains hot oil or other hot liquid. If it must be moved when it contains hot oil or other hot liquid, use extreme caution.
12. Always attach the heat control to the appliance first, then plug cord into the wall outlet. To disconnect, turn the control to OFF, and then remove the plug from the outlet.
13. Do not use this appliance for other than intended use.

SAVE THESE INSTRUCTIONS

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY.

Important Cord Information

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

A short, detachable power supply cord is provided to reduce the risk of becoming entangled in or tripping over a longer cord. Extension cords may be used if care is properly exercised in their use. If an extension cord is used, the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance. The extension cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

Connect the power supply cord to a 120VAC electrical outlet only.

How to Use

NOTICE: This griddle is not intended to be used as a warming tray, hot plate, or for heating any cookware. Using this griddle for purposes different from those specified in the instruction manual may cause damage to the griddle and will void the product warranty.

Before using for the first time, become familiar with the griddle features. Wash griddle in warm, soapy water, rinse, and dry. **Do not immerse Control Master® heat control in water or let it come in contact with any liquid.**

1. Place the assembled griddle on a dry, level, heat-resistant surface away from walls, cabinets, and other objects.


NOTICE: To prevent possible heat damage to your countertop, place a heat-resistant counter protector, such as aluminum foil, under the griddle. Take care not to place the foil under the griddle's legs.

2. Insert the Control Master® heat control probe into the griddle so the two electrical pins on the griddle are fully inserted into the heat control. Connect the cord to a 120VAC electrical wall outlet only.
3. When cooking meats, pull out on the handles to tilt the grilling surface. This allows excess grease to drain into the drip tray. When cooking other foods, such as eggs and pancakes, be sure the handles are pushed in so the griddle is level.
4. Turn the heat control to the temperature recommended in the temperature-timetable on page 3 and preheat the griddle. The pilot light will go off when the selected temperature is reached, in about 5 to 10 minutes.

NOTE: Occasionally you may hear a pop or clicking sound while the griddle is preheating. This is due to the expansion of the metal as it heats and is normal. You may also hear this sound as the griddle cools down.
5. Prepare food for cooking. Because the griddle features a nonstick finish, food may be prepared with little or no oil.

NOTICE: Avoid using no-stick cooking sprays as they may cause the cooking surface to become tacky.
6. Place food on the griddle and cook according to the temperature-timetable on page 3. Adjust the heat according to personal preference and the particular food being cooked. During cooking, the pilot light will go on and off indicating the desired temperature is being maintained.

For best results use heat-resistant nylon, plastic, rubber, or wooden utensils. Do not use metal utensils as they may scratch the non-stick surface. Do not cut foods on the cooking surface.
7. Turn the heat control to OFF when cooking is complete. Unplug the heat control from the wall outlet then from the griddle. Allow the griddle to cool before removing the drip tray and before cleaning.



*Scotch-Brite and Dobie are registered trademarks of 3M Company.
Presto is not affiliated with this company.

Care and Cleaning

Do not immerse the Control Master® heat control in water or let it come in contact with any liquid.

After each use, remove the heat control and wash the griddle in warm, soapy water. Rinse and dry thoroughly. Also clean the underside of the griddle. Clean the nonstick surface with a non-metal cleaning pad, such as Scotch-Brite® Multi-Purpose Scrub Sponge* or Scotch-Brite® Dobie® Cleaning Pad. Firm pressure can be applied, if necessary. **Do not use steel wool or abrasive kitchen cleaners.**

Soaking the griddle to loosen food residue is not necessary. However, if soaking is desired, do not soak for more than two hours. Soaking for more than two hours may damage the nonstick finish on the griddle.

NOTICE: To maintain the appearance of the griddle, do not wash it in the dishwasher. The bottom of the griddle will likely discolor due to the caustic nature of the dishwasher detergent. In addition, a gray residue may form on the bottom of the griddle which may transfer onto towels and/or skin.

In time, the nonstick finish may darken over the heating element due to a buildup of grease residue. This discoloration can be removed by using a solution of one tablespoon of powdered automatic dishwasher detergent per one cup of hot water. Slide the drip tray into place. Preheat griddle to 225°. Wearing rubber gloves, dip a non-metal cleaning pad into cleaning solution and rub over the cooking surface; do not come touch the hot cooking surface with the gloves. Continue cleaning until the solution is gone. Turn the griddle off and allow to cool. Wash the griddle in warm, soapy water and dry. After treating the griddle it is recommended that the cooking surface be wiped lightly with vegetable oil before using.

Some discoloration may occur inside the griddle drip tray. This is normal. The amount of discoloration will vary depending on the foods cooked and the temperature setting used. This discoloration is only visible from the inside of the drip tray and will not affect the performance of the griddle.

The cool-touch base on the griddle is easy to keep attractive and looking new. Simply wipe away spills and drips as they occur. Any food residue remaining can be removed with warm, soapy water and a non-metal cleaning pad. Rinse and wipe dry.

Periodically check the screws on the griddle frames and legs for looseness. Retighten, if necessary, with a standard slotted screwdriver.

NOTICE: Overtightening can result in the stripping of screws or the cracking of frames and legs.

IMPORTANT: To ensure continued accuracy of the Control Master® heat control, avoid rough handling in use and storage.

Temperature–Timetable

Food	Temperature	Cooking Time	Food	Temperature	Cooking Time
Bacon	325°–350°	5–8 minutes	Pork Chops, ¾ inch thick	325°–375°	20–25 minutes
Canadian bacon	325°–350°	3–4 minutes	Potatoes, cottage fried	300°–350°	10–12 minutes
Eggs, fried	275°–300°	3–5 minutes	Sausage, link	325°–350°	20–30 minutes
Fish	325°–375°	5–10 minutes	Sausage, precooked	325°–350°	10–12 minutes
French toast	325°–350°	4–6 minutes	Sandwiches, grilled	325°–350°	5–10 minutes
Ham, ½ inch thick	325°–350°	10–12 minutes	Steak, beef		
Ham, ¾ inch thick	325°–350°	14–16 minutes	1 inch thick, rare	350°–400°	6–7 minutes
Hamburgers, ½ inch thick	325°–375°	8–12 minutes	1 inch thick, medium	350°–400°	10–12 minutes
Minute steak	375°–400°	4–5 minutes	1½ inch thick, rare	350°–400°	8–10 minutes
Pancakes	375°–400°	2–3 minutes	1½ inch thick, medium	350°–400°	18–20 minutes
Pork Chops, ½ inch thick	325°–375°	15–20 minutes			

Consumer Service Information

If you have any questions regarding the operation of your Presto® appliance or need parts for your appliance, please contact us by any of these methods:

- Call 1-800-877-0441 weekdays 8:00 AM to 4:00 PM (Central Time)
- Email us through our website at www.GoPresto.com/contact
- Write: National Presto Industries, Inc.
Consumer Service Department
3925 North Hastings Way
Eau Claire, WI 54703-3703

Inquiries will be answered promptly by telephone, email, or letter. When emailing or writing, please include a phone number and a time when you can be reached weekdays, if possible.

When contacting the Consumer Service Department, please indicate the model and series numbers for the griddle. The model number can be found on the bottom of the plug guard and the series number can be found stamped in the bottom center of the griddle. Please record this information:

Model _____ Series _____ Date Purchased _____

The Presto Factory Service Department is equipped to service Presto® appliances and supply genuine Presto™ replacement parts. Genuine Presto™ replacement parts are manufactured to the same exacting quality standards as Presto® appliances and are engineered specifically to function properly with its appliances.

Presto can only guarantee the quality and performance of genuine Presto™ replacement parts. “Look-alikes” might not be of the same quality or function in the same manner. To ensure that you are buying genuine Presto™ replacement parts, look for the Presto® trademark.

Canton Sales and Storage Company, Presto Factory Service Department
555 Matthews Drive, Canton, MS 39046-3251

Presto® Limited Warranty

(Applies only in the United States)

This quality Presto® appliance is designed and built to provide many years of satisfactory performance under normal household use. Presto pledges to the original owner that should there be any defects in material or workmanship during the first year after purchase, we will repair or replace it at our option. Our pledge does not apply to damage caused by shipping. ***Outside the United States, this limited warranty does not apply.***

To obtain service under the warranty, please call our Consumer Service Department at 1-800-877-0441. If unable to resolve the problem, you will be instructed to send your Presto® appliance to the Presto Factory Service Department for a quality inspection; shipping costs will be your responsibility. When returning an appliance, please include your name, address, phone number, and the date you purchased the appliance, as well as a description of the problem you are encountering with the appliance.

We want you to obtain maximum enjoyment from using this Presto® appliance and ask that you read and follow the instructions enclosed. Failure to follow instructions, damage caused by improper replacement parts, abuse, misuse, disassembly, alterations, or neglect will void this pledge. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This is Presto's personal pledge to you and is being made in place of all other express warranties.

National Presto Industries, Inc., Eau Claire, WI 54703-3703

Form 72-653D