







TV stand


Installation Instructions






A 50PCS  ø6*35mm	B 50PCS  ø15*10mm	C 20PCS  ø8*30mm	D 8PCS  M6	E 58PCS  ø3.5*14mm	F 8PCS  ø5*15mm
G 4PCS 	H 4PCS 	I 10PCS 			

1




2PCS

2




4PCS

3




1PC

4




2PCS

5




2PCS

6




2PCS

7




1PC

8




1PC

9




1PC

10




2PCS

11




1PC

12




1PC

13



1PC


14



1PC


"A" Hardware installation example

I




This part cannot be separated ,
please install in strict
accordance with the assembly
requirements


II




III



IV



Step 1




Mark the rubber particle with an X, twist it left, and insert it into the eye position.

A 50PCS



Ø6*35mm



Step 2

B 8PCS




Ø15*10mm

D 8PCS




M6




Step 3

B	10PCS
	
ø15*10mm	



Step 4


B	12PCS
	
ø15*10mm	
C	4PCS
	
ø8*30mm	




Step 5

Panel 6 has shelf mounting holes—please note the orientation as shown in the diagram. Please refer to Step 8.

B	6PCS
	
ø15*10mm	
C	6PCS
	
ø8*30mm	




Step 6




Step 7

B	12PCS
	
ø15*10mm	
C	10PCS
	
ø8*30mm	




Step 8





F	8PCS
	
ø5*15mm	





Step 9



Step 10




E	16PCS
	
Ø3.5*14	
G	4PCS
	
H	4PCS
	

Step 11

Cabinet Door Adjustment Instructions


Height adjustment:

- Locate the height adjustment screws on the hinge.
- Use the Phillips screwdriver to either tighten or loosen the screws to raise or lower the cabinet door as desired.




Side-to-side adjustment:

- If the cabinet door needs to be moved closer to or away from the cabinet frame, locate the side-to-side adjustment screws on the hinge.
- Use the Phillips screwdriver to adjust these screws and gradually move the door in the desired direction.




Depth adjustment (if applicable):

- Check if the cabinet door needs to be brought closer to or further away from the cabinet frame.
- For-depth adjustment, locate the depth adjustment screws on the hinge.
- Use the Phillips screwdriver to turn these screws clockwise or counterclockwise accordingly.




Step 12

E	8PCS
	
Ø3.5*14	




Step 13

E	8PCS
	
Ø3.5*14	




Step 14

E	8PCS
	
ø3.5*14	






Step 15


E	8PCS
	
ø3.5*14	




Step 16

E	10PCS
	
Ø3.5*14	
I	10PCS
	

- 1
- 2
- 3



Step 17



OK