


Wardrobe



IMPORTANT INFORMATION!

- please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.

AVOID SCRATCHES!

- In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.

IMPROVE EFFICIENCY!

- Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.

IMPORTANT!


- It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months -in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.
for glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.





- Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.

ANTI-TOPPLE WARNING!

Overtumed furniture can cause serious or fatal crush injuries. to prevent tipping over, be sure to use the wall attachment, if not included with this product. please purchase the wall attachment that fit your wall. if unsure, seek professional advice. please read and follow each step of the instructions carefully.



Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 53




Ø6 x 34mm

B x 53



Ø15 x 10mm

C x 48



Ø8 x 30mm

D x 16




Ø4 x 40mm

E x 8




Ø4 x 30mm

F x 8



Ø35mm

G x 2




Ø35mm

H x 64



Ø3.5 x 14mm

J x 2




350mm

K x 16



Ø3.5 x 12mm

L x 7



128mm

M x 14



Ø4 x 22mm

N x 2




47 x 18 x 12mm

P x 1



770mm

Q x 48



14x13x10mm


R x 48



Ø3 x 16mm

S x 2






Slides Must be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.

Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.






1

A x 4



Ø6 x 34mm




2

B x 4






Ø15 x 10mm

C x 4



Ø8 x 30mm






3

A x 4



Ø6 x 34mm




4

B x 4






Ø15 x 10mm

C x 4



Ø8 x 30mm



5

H x 2





Ø3.5 x 14mm

N x 1




47x18x12mm



6

C x 4





Ø8 x 30mm

D x 4



Ø4 x 40mm





7

D x 2



Ø4 x 40mm



8

H x 2





Ø3.5 x 14mm

N x 1




47x18x12mm



9

C x 2





Ø8 x 30mm


D x 2



Ø4 x 40mm



10






11

A x 8



Ø6 x 34mm



12

C x 8





Ø8 x 30mm

D x 8



Ø4 x 40mm






13

A x 5



Ø6 x 34mm






14

B x 5



Ø15 x 10mm






15

A x 2



Ø6 x 34mm




16

B x 2






Ø15 x 10mm

C x 2



Ø8 x 30mm






17

A x 14



Ø6 x 34mm




18

B x 10






Ø15 x 10mm

C x 6



Ø8 x 30mm



19

J x 2






350mm

K x 8



Ø3.5 x 12mm




20

B x 4






Ø15 x 10mm

C x 4



Ø8 x 30mm






21

A x 8



Ø6 x 34mm




22

B x 4






Ø15 x 10mm

C x 4



Ø8 x 30mm




23

B x 4






Ø15 x 10mm


C x 4



Ø8 x 30mm



24




25

B x 8






Ø15 x 10mm

C x 8



Ø8 x 30mm







26

P x 1



770mm



27

J x 2






350mm

K x 8



Ø3.5 x 12mm





x2

28

E x 8




Ø4 x 30mm



x2

29






x2

30

A x 8

 Ø6 x 34mm






x2

31

B x 8



Ø15 x 10mm



x2

32

L x 2





128mm

M x 4




Ø4X22mm




x2

33



34





Ø35mm

H x 16






Ø3.5 x 14mm








x2

35



36



37

H x 16



Ø3.5 x 14mm

L x 2





128mm

M x 4



Ø4 x 22mm



38

H x 8



Ø3.5 x 14mm

L x 1





128mm

M x 2



Ø4 x 22mm



39

Q x 48





14x13x10mm

R x 48







Ø3 x 16mm




40

S x 2





Adjust & Align Door HingeS



Up & Down Adjustment



Left & Right Adjustment



Forward & Back Adjustment



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly.the warranty will start from the date of purchase which must be verified by proof of purchase.
- The product must be used in accordance with the instructions provided.for health reasons.
- For other reasons,if the furniture needs to be returned,it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty.attention please.
- Does not include damage during installation,but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and /or loss of parts during the installation of furniture.
- After using,the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All bought in The us and Covers The Following areas

- Sheet parts:1 month from the date of purchase.
- Electrical parts:1 month from the date of purchase.