


014-HG-41802
Norrell TV Stand



Belleze®

Instruction
Manual






Scan to view
online tutorial
or visit
www.belleze.com

Read Before Assembly

The instruction booklet contains **IMPORTANT** safety information. Please read it in full and keep it for future reference.





WARNING!



- Serious or fatal crushing injuries may occur if the furniture tip-over. Furniture must permanently affixed to the wall with anti-tipping device(s) in order to prevent the furniture from tipping over.
- Different wall materials requires different type of wall anchors or screws. Use a suitable wall anchors or screws for your specific wall in order to secure the stability and load bearing capacity of the furniture. If you are uncertain about which type of device to use, please contact us or local hardware store and seek professional advice.
- Only place items that is within the recommended size and weight limit of the furniture.
- Items placed onto the furniture must be resting on a support surface without hanging over the edges.
- Climbing on, stepping on, or placing overweighted objects on the product may cause property damage and / or injuries.



CAUTION!



- Assemble the furniture on an empty carton, carpet, or rug to prevent scratches or damage.
- When assembling the furniture, keep pets and children away from the assembly area.
- Ensure the product is fully assembled before use. If you are missing any hardware or parts, do not use it until you have restored the missing parts.
- This furniture requires 2 people for assembly.
- Lay out all components and hardware separately on a flat surface and make sure that no parts are missing or damaged before assembly. Do not destroy or discard any packaging until you are certain that you have all the necessary parts for assembly.
- There are small components used in the construction of the furnitures. Loose items, plastic bags, and packaging films should be kept away from pets or children to avoid choking hazard or suffocations.
- Read this instruction manual prior to assembly and familiarize yourself with the various steps.
- Install all hardware perpendicular to the opening unless otherwise specified.
- Hand tight all hardware and careful not to over-tighten to avoid damaging the product.

Assembly Symbols



- Follow sequential order.



- Build specified number of parts.



- Flip part as indicated.



- Rotate part as indicated.



- Choose your own assembly options.



- Pay attention to the part orientation.



- Leave bolts or screws partially tighten.



- Fully tighten bolts or screws.



- Level the furniture on the ground.




Estimated Time for Assembly


120 mins




Weight Capacity Limitations are as Follows:




Tools Needed



• Philips Screwdriver




• Rubber Mallet Hammer



• Electric Drill









Package Contents



Package Contents

CODE	DESCRIPTION	QTY
1	Top Panel	1
2	Upper Lateral Panel	2
3	Divider Panel	1
4	Center Panel	1
5	Upper Back Panel	1
6	Side Back Panel	2
7	Top Surround Panel	1
8	Cabinet Door	2
9	Left Lateral Panel	1
10	Left Medial Panel	1
11	Right Medial Panel	1
12	Right Lateral Panel	1
13	Right Surround Panel	1
14	Left Surround Panel	1
15	Small Storage Shelf Panel	2
16	Base	1
17	Large Storage Shelf Panel	1
18	Center Back Panel	1
19	Top Garnishing Strip	1

Package Contents




01

Base



A 8x




02

Base




B 8x



03 Surround Panels




A 4x



04 Surround Panels



B 4x






05 Attaching surround panels



C 4x



M 4x




06 Attaching lateral panels and medial panels



C 8x




M 8x



07 Prepping lateral and medial panels




B 8x



08 Center panel



A 8x




09 Attaching top surround panel



B 2x



G 2x



10


Attaching center panel



C 8x



M 8x




11

Prepping center panel



A 6x




12

Prepping center panel



B 4x



13


Attaching upper lateral panels and divider panel



C 6x



M 6x




14

Prepping upper lateral panels



B 4x




15

Top panel



A 6x



16



Attaching top panel





C 6x





M 6x



A TV Stand




B Fireplace




17

Installing back panels



J 49x

★ Warning label should be facing outward.



18


Attaching door hinges



E 4x



K 8x



19


Attaching door handles



F 2x



H 4x




20


Attaching cabinet doors



K 16x







i





Adjust the door hinge if there is excessive gaps or height difference between the cabinet doors and/or the cabinet. Adjust both the top and bottom hinge on the same door for best result.





i



Loosen the screws on the mounting plate to adjust the door **up and down**.



Adjust the screw on the hinge to micro-adjust the door from **side to side**.




Loosen the screws on the hinge arm to adjust the door **in and out**.

21

Inserting shelf pegs and putting on shelf panels



I 12x



22


Attaching anti-tipping straps



O 2x



Q 2x



23



Affixing the TV stand to a wall



N 2x



P 2x



- Serious or fatal crushing injuries may occur if the furniture tip-over. Furniture must permanently affixed to the wall with anti-tipping device(s) in order to prevent the furniture from tipping over.

1. Mark the drilling positions on the wall.
2. Drill pilot holes at the marked locations.
3. Insert wall anchors into the pilot holes.
4. Secure the anti-tipping strap to the wall with provided screws.

*Assembly symbols


1

2

Follow sequential order


24 Attaching garnishing strip

★ TV or other objects should be placed behind the wood trim to prevent them from falling off.




17

Installing back panels



J 37x

★ Warning label should be facing outward.



⚠ WARNING

Risk of death or serious injury.
This surface must be placed
against a fixed in place all at
least as tall as the television.

18


Attaching door hinges



E 4x



K 8x



19


Attaching door handles



F 2x



H 4x




20


Attaching cabinet doors



K 16x







i





Adjust the door hinge if there is excessive gaps or height difference between the cabinet doors and/or the cabinet. Adjust both the top and bottom hinge on the same door for best result.





i



Loosen the screws on the mounting plate to adjust the door up and down.



Adjust the screw on the hinge to micro-adjust the door from side to side.




Loosen the screws on the hinge arm to adjust the door in and out.

21 Inserting shelf pegs and putting on shelf panels



I 8x




22 Attaching anti-tipping straps



O 2x



Q 2x




23 Installing fireplace heater

★ Do not attempt to install the fireplace unit from the front of the mantel. It will not fit.

★ The heater has a glass front panel. Careful when handling glass to prevent injury or damage. Set the unit from the back of the fireplace mantel and center it in the opening. For the exact instruction, please refer to the user's manual provided with the fireplace.

★ The screws for installation are in the packing case of the fireplace.



24



Affixing the TV stand to a wall



N 2x



P 2x




- Serious or fatal crushing injuries may occur if the furniture tip-over. Furniture must permanently affixed to the wall with anti-tipping device(s) in order to prevent the furniture from tipping over.

1. Mark the drilling positions on the wall.
2. Drill pilot holes at the marked locations.
3. Insert wall anchors into the pilot holes.
4. Secure the anti-tipping strap to the wall with provided screws.

25 Attaching top garnishing strip

★ TV or other objects should be placed behind the wood trim to prevent them from falling off.





WARNING

For use with televisions weighing 70lbs (31.8kg) or less. Use with heavier televisions may result in instability, causing tip over resulting in death or serious injury.

Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over on to the child.

Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to the furnishing collapsing or over turning onto a child.



NOTICE

The recommended maximum width of the television is 50 inches. Do not exceed the maximum load capacity.

This product is designed for flat panel TVs only.

Care and Maintenance

Thank you for your purchase. We want your item to last as long as possible.

To ensure the product gives you years of longevity, please follow the recommendations in this care and maintenance guide.



Maintenance

- Tighten all bolts and crews again within the first 2 weeks of assembly.
- Check the tightness of all bolts every 2 months and re-tighten them if they come loose.



Cleaning

- Clean the surface of the MDF (medium density fiberboard) with a lightly dampened cloth.
- A small amount of mild soap can be used if necessary.
- Dry the surface immediately after cleaning.



Attention

DO NOT use bleach or alcohol based cleaner to clean the surface.

DO NOT apply wood treatment on parts made with MDF.

MDF will swell and distort when exposed to water damage.

Make sure to dry the furniture immediately after cleaning.



Attention

The manufacturer and seller are not responsible for any and all liability relating to personal injury, property damage or losses, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification or neglect of the product.

Warranty

BELLEZE products comes with a 1-year warranty from the date of delivery.
Register your product on our website to enjoy out limited lifetime warranty!

After-Sale Service



Encounter any difficulties or missing parts?



Contact us at **1-800-682-6376** or email us at **support@belleze.com**



We will send you replacement.



Hassle free!
No need to worry about repackaging and sending your item back.

Contact Us



support@belleze.com



1-800-682-6376