




PERFORMANCE DATA

To Obtain Performance Data:

- Press and hold the **Down** button for two seconds.
- While holding the **Down** button, press and hold the **Indirect Tank** button (hold both buttons at the same time).
- Use the **Up** and **Down** buttons to scroll to the desired information described in the **Performance Data Table**.
- The data for the performance number automatically appears in the display.
- To exit performance data, repeat step 2 above.



Performance Data Table

#	Data	Unit
01	Water Pressure	PSI/bar*
02	Supply Temperature	F/°C*
03	Return Temperature	F/°C*
04	Freeze Protection Temperature	F/°C*
05	Exhaust Temperature	F/°C*
06	Fan Frequency	Hz
07	Venturi Position	0=Closed, 1=Open
08	Venturi Cycles	<100
09	Pump Cycles	<100
10	Pump Hours	<10
11	Pump for Boiler	0=OFF, 1=ON
12	Pump for System (Pump 1)	0=OFF, 1=ON

#	Data	Unit
13	Pump for Indirect Tank (Pump 2)	0=OFF, 1=ON
14	Indirect Tank Thermistor Temperature	F/°C*
15	Outdoor Temperature	F/°C*
16	Operational Hours	<100
17	Combustion Hours	<10
18	Combustion Cycles	<100
19	Commissioning Cycles	<1

*Units of Measurement

- Press the **Mode** button.
- Press the **Up** or **Down** arrows to select a unit.

Controller Model	Temp.	Water Flow	Press.
1: F	*F	gal/min	psi
1: C	*C	L/min	bar

ELECTRICAL DIAGNOSTICS

COMPONENT	WIRE COLOR	VOLTAGE *When the unit is operating	RESISTANCE	PCB	
				Connector	PIN
Power Supply	Black-White	AC108-132V	N/A	CN24	1-3
Flame Rod	Yellow-Body	more than 2VAC*	N/A	CN1	2
Spark Electrode	Red-Black	11-14VDC*	N/A	CN1	11-22
Combustion Fan	Red-Black	7-8VDC*	N/A	CN1	3-5
	White-Black	2-14VDC*	N/A	CN1	5-9
	Yellow-Black	11-14VDC	N/A	CN1	5-7
Venturi Control Device	Blue-White	N/A	33-43Ω	CN1	17-19
	Yellow-Red(No.9)	N/A	N/A	CN1	13-15
	Black-Red(No.3)	11-14VDC	N/A	CN1	11-29
	Black-Brown	Close Position: less than 1VDC Open Position: 4-6VDC	N/A	CN1	26-29
Gas Solenoid Valve	Black-Grey	Close Position: less than 1VDC Open Position: 4-6VDC	N/A	CN1	24-29
	Yellow-Black	11-14VDC*	15-25Ω	CN1	28-30
Exhaust Thermistor	White-White	N/A	59°F: 11.4-14kΩ 86°F: 6.4-7.8kΩ 113°F: 3.6-4.5kΩ 140°F: 2.2-2.7kΩ 221°F: 0.6-0.8kΩ	CN11	16-19
Supply Thermistor	White-White	N/A	N/A	CN11	12-19
Return Thermistor	White-White	N/A	N/A	CN11	10-20
Freeze Protection Thermistor	Black-Black	N/A	*Disconnect the connector and measure at thermistor side. 32°F: 38k-43k; 50°F: 22k-26k; 68°F: 14k-17k *Disconnect the connector and measure at thermistor side.	CN11	10-14
Transformer	White-Grey	AC108-132V	N/A	CN18	1-2
Overheat Switch	Red-Red	AC20-30V (possible to measure at Output terminal as substitute position) less than 1VDC	N/A	CN18	3-4
Water Pressure Sensor	Red-Black	11-14VDC	less than 1Ω	7(CN11)-27(CN1)	
	Yellow-Black	0kPa: 655-745mV; 200kPa: 2155-2245mV; 400kPa: 3655-3745mV	N/A	CN1	11-29
Water Level Electrode	White-White	11-14VDC	N/A	6(CN11)-29(CN11)	
Air Handler	Red-Black	11-14VDC	N/A	8(CN11)-29(CN1)	
Control Panel	Black-Black	11-14VDC	N/A	CN8	1-2
			N/A	CN2	1-4

Important Safety Notes

There are a number of (live) tests required when performing electrical diagnostics on this product. Proceed with caution at all times to avoid contact with energized components inside the boiler. Only trained and qualified service technicians should attempt to repair this product. Before checking for resistance readings, disconnect the power source to the unit and isolate the item from the circuit (unplug it).

Electrical Diagram

Refer to the Wiring Diagram attached to the back of the front cover.


Flame Rod

Place one lead of your meter to the flame rod and the other to ground. When the unit is attempting to ignite, you should read more than 2VAC.

Amp Fuses

This unit has two (10) amp glass fuses located on the PCB board. Remove the fuses and check continuity through it. If you have continuity through each fuse then it is functioning. Otherwise, the fuse is blown and must be replaced.

DIP Switches




#	DIP Switch Function
1	Outdoor Temperature Sensor: Enables or disables outdoor temperature sensor. OFF (Default): Outdoor Temperature Sensor in Use ON: Outdoor Temperature Sensor Not in Use
2	Thermostat Usage: Changes mode between Thermostat and CH Button. OFF (Default): Thermostat Used ON: CH button used. Boiler fires based on return water temperature
3	Indirect Tank: Enables the Indirect Tank Function for Pump 2. OFF (Default): On ON: Off (Pump 2 Operates at a CH Zone Pump)
4	Indirect Tank Thermistor/Thermostat Selection: Selects the method of controlling the indirect tank. OFF (Default): Thermistor; ON: Thermostat
5	Gas Valve Solenoid: Manually shuts down the integrated solenoid gas valve. OFF (Default): Normal Operation; ON: Fixed Closed
6, 7	Altitude Setting: Sets the appropriate elevation of the boiler installation. (OFF/ON: Depends on Altitude)
8	Vent Type Selection: Selects the venting material used. The boiler is set from the factory to be installed in a PVC venting system. If CPVC, PP, or other approved venting is used, this setting may be adjusted. See Section 5 in Manual for more information. OFF (Default): PVC; ON: Other

High Altitude DIP Switch Table


ALTITUDE	DIP Switch 6	DIP Switch 7
0-2,000 ft (0-610 m) (Default)	OFF	OFF
2,001-5,400 ft (610-1,646 m)	ON	OFF
5,401-7,700 ft (1,646-2,374 m)	OFF	ON
7,701-10,200 ft (2,347-3,109 m)	ON	ON

PARAMETER SETTINGS


- To access the Parameter Settings, press and hold the red button on the PC Board for five seconds.



- Press the **Mode** button on the controller.
- Press the **Up** or **Down** arrows to select a parameter setting. Press the **Select** button.



- Press the **Up** or **Down** arrows to change the selection for the setting number (such as 30-A or 30-b). Then, press the **Select** button.



- To exit parameter settings and enter normal operation mode, press either the red button on the PC Board or the **Mode** button on the controller.

Parameter Number	Setting Description	Selection				Parameter Value	Date Adjusted	Parameter Value	Date Adjusted
		A	b	C	d				
00	Pressure Indication on the Control Panel The current pressure will cycle on the controller display.	Yes	No						
01	Outdoor Reset Curve This parameter is available when Dip Switch 1 is in the OFF (default) position. Select the proper curve from below. Curve 1: Standard baseboard, high efficiency air handler, cast iron or panel radiators. Curve 2: Staple up radiators. Curve 3: High temperature air handler or undersized baseboard. Curve 4: Custom curve based on Maximum Outdoor Temperature the Boiler will Fire in CH Mode	Curve 1	Curve 2	Curve 3	Curve 4				
02	Boost This parameter is available when Dip Switch 1 is in the OFF (default) position.	No	30 Minutes	60 Minutes					
03	Maximum Outdoor Temperature the Boiler will Fire in CH Mode This parameter is available when Dip switch 1 is in the OFF (default) position. This sets the maximum outdoor temperature the boiler will fire in CH mode. Indirect Tank Supply Temperature with Thermostat Control Indirect Tank Supply Temperature with Thermostat Control *This parameter is available when Indirect Tank "In Use" is selected on Dip switch 3 and when Indirect Tank Control "Thermostat" selected on Dip switch 4.	No Maximum	77°F (25°C)						
30	Indirect Tank Supply Temperature with Thermostat Control *This parameter is available when Indirect Tank "In Use" is selected on Dip switch 3 and when Indirect Tank Control "Thermostat" selected on Dip switch 4.	180°F (82°C)	160°F (71°C)	140°F (60°C)					
31	Indirect Tank Supply Temperature with Thermostat Control *This parameter is available when Indirect Tank "In Use" is selected on Dip switch 3 and when Indirect Tank Control "Thermostat" selected on Dip switch 4.	180°F (82°C)	Setting Temperature +18°F (+10°C)	Setting Temperature +27°F (+15°C)					
32	Allowed Indirect Tank Temperature Drop before Firing (with Thermostat) *This parameter is available when Indirect Tank "In Use" is selected on Dip switch 3 and when Indirect Tank Control "Thermostat" selected on Dip switch 4.	5.4°F (3°C)	10.8°F (6°C)	16.2°F(9°C)	21.6°F(12°C)				
33	*This parameter is available when Indirect Tank "In Use" is selected on Dip switch 3. When a 3 Way Valve and the boiler pump are to be used for recovering the indirect tank select "b". Indirect Tank Simultaneous Heating	Use Pump	Use 3-Way Valve						
34	*This parameter is available when Indirect Tank "In Use" is selected on Dip switch 3 and when "Use Pump" is selected in Parameter 32. Indirect Tank Priority Time	Indirect Tank Priority	Simultaneous Heating with Indirect Tank and CH						
35	*This parameter is available when Indirect Tank "In Use" is selected on Dip switch 3. CH Temperature Limitation to Allow Simultaneous Operation with Indirect Tank *This parameter is available when Indirect Tank "In Use" is selected on Dip switch 3 and when "Use Pump" is selected in Parameter 32 and also when selecting "Simultaneous Heating with Indirect Tank and CH" in Parameter 33.	60 minutes	40 minutes	90 minutes					
40	Linked Operation Between CH Pump 1 and 2 This parameter enables linked operation between the CH Pump 1 and 2. (default).	Yes	No						
41	Linked Operation Between Main Boiler Pump and CH Pump 1 This enables the linked operation between the main boiler pump and CH pump 1.	No	Yes (Linked Together)						
42	Main Pump Runs When the Target Temperature is Achieved This selects the mode of the main pump running when the target setpoint is achieved.	Continuously	Intervals						
43	External Pump Runs When the Setpoint Temperature is Achieved This selects the mode of the external pump(s) running when the target setpoint is achieved.	Same as Main Pump	Does Not Run						
44	External Pump Runs When Freeze Protection is in Operation This selects how the external pump operates when freeze protection is in operation.	Does Not Run	Same as Main Pump (if selected, hydraulic separation is needed)						
45	Freeze Protection Level This selects the freeze protection level. Selecting "b" will prevent the boiler from operating in freeze protection mode more than believed necessary. The Differential Temperature from Ceasing Fire to Firing Again How much temperature drop is permitted by the supply water thermistor before the boiler will fire again.	Default	When Boiler is Installed in a Warm Room						
46	CH Setting Temperature 168-182°F (75-82°C) 104-166°F (40-74°C)	Normal	Quick						
47	The Time Which the Boiler is Not Allowed to Fire Again for CH This selects the time which the boiler will not be able to fire again for CH after the burner has shutdown.	27°F (15°C) 15°F (8°C)	15°F (8°C) 9°F (5°C)						
48	Heating Eco Mode On Time The setting changes the on time of the heating Eco mode. Will the boiler shut down on a high return water temperature This setting is for whether the boiler will shut down at high return water temperatures.	Normal (3 Minutes)	Quick(10 Seconds)						
49	30 Minutes 15 Minutes	Yes	No						
50	Not Available	Not Available							
51	Gas Type For selecting gas type when conducting gas conversion.	Natural Gas	Liquid Propane						
52	Not Available	Not Available							
53	Vent Material Used This selects the venting material used. The boiler is set from the factory to be installed in a PVC venting system. If CPVC, PP, or other approved venting is used, this may be adjusted. See the section on PVC Safety Switch for more information.	PVC	Material other than PVC, CPVC/PP/Other						


NOTE
Record date and parameter when individual parameters have been adjusted from factory default.

For more information, refer to the Rinnai Boiler Installation and Operation Manual.

DIAGNOSTIC CODES

To display diagnostic codes:


- Press and hold the **Indirect Tank** button for two seconds and then the **Up** button simultaneously.
- The last nine maintenance codes display and flash one after the other.
- To exit diagnostic codes and return the boiler to normal operation, press and hold the **Indirect Tank** button for two seconds, and then the **Up** button simultaneously.



	Error Reset
Power Reset	Heat Exchanger Overheat (140), Venturi Control (150), High Exhaust Temperature (540), and Freeze Issue (890) can be reset by shutting down power to the boiler.
Interlock Reset	Venturi (170) and Solenoid Valve Circuit (520) can be reset by pushing and holding button SW1 and 2 for five seconds.
Other Reset	Other error can be reset by Indirect Tank On/Off button or Central Heating button.




100 Air Supply or Exhaust Blockage/Condensate Trap is Full	<ul style="list-style-type: none"> Fan current initial check error. Ensure condensate line and trap is not blocked. Ensure internal air filter is clean with no obstructions. Ensure high altitude setting is set properly (See High Altitude Setting). Ensure combustion air and exhaust vents are not blocked and the approved venting materials are being used. Ensure either the exhaust ring or intake cap is removed properly. Ensure vent length is within limits. Check fan for debris and ensure wheel turns freely. Verify fan check valve is not stuck between fan casing and burner body.
101 No Ignition (Unit Not Turning On)	<ul style="list-style-type: none"> Ignition Error. Check that the gas is turned on at the boiler, gas meter, and/or propane cylinder. If the unit is installed in a propane system, ensure that gas is in the tank. Bleed all air from the gas lines. Check the ground wire for the PC Board. Ensure the flame rod wire is connected. Ensure the system is plumbed properly. Ensure the venting is installed in accordance with the I-Series Boiler Installation and Operation Manual. Check that the surface of the electrode and flame rod are clean. Check gas solenoid valves for open or short circuits.* Verify gas orifice installed is correct for the gas system the unit is installed in. Check flame rod voltage to ground during ignition.
102 Flame Failure	<ul style="list-style-type: none"> Boiler has flame failure. Check that the gas is turned on at the boiler, gas meter, and/or propane cylinder. If the unit is installed in a propane system, ensure that gas is in the tank. Ensure the venting is installed in accordance with the I-Series Boiler Installation and Operation Manual. Ensure the flame rod wire is connected. Ensure the gas type and inlet gas pressure are correct. Bleed all air from the gas lines. Check the ground wire to the PC Board. Check flame rod voltage to ground during ignition.
140 Heat Exchanger Overheat	<ul style="list-style-type: none"> Overheat switch is tripped. Measure the resistance of the Overheat Switch.* Check the heat exchanger surface for hot spots which may indicate blockage due to scale buildup. Ensure the boiler pump is not locked up. Ensure that all of the valves in the CH circuit are open. Ensure the boiler and CH circuit does not have a freezing condition. The surface of the heat exchanger may turn to a black color as stainless steel is tempered even in normal conditions. This does not indicate an abnormal condition. Check for damage on the exhaust, seal, and venting.
150 Venturi Control	<ul style="list-style-type: none"> Venturi operation error. Ensure the venturi motor is operating correctly.* Replace the gas valve assembly.
170 Venturi Blockage	<ul style="list-style-type: none"> Check the venturi and silencer for blockage. Before resetting this error, check if the condensate drain is block and if the venting is connected properly.
18 Indirect Tank Temperature	<ul style="list-style-type: none"> Indirect tank runs for more than six hours without cycling off. Ensure the tank size is adequate. Check the thermistor location. Ensure the system is plumbed properly. Check the supply temperature for tank is higher than tank setting temperature (Parameter 30). Check sensor wiring for damage. Measure resistance of sensor.* Replace sensor if necessary.
190 Electrical Grounding	<ul style="list-style-type: none"> Secondary circuit ground fault. Check all electrical components for electrical short.
250 Condensate Pump (Accessory)	<ul style="list-style-type: none"> Boiler will operate for 60 seconds. Confirm wire connections and harnesses are good. Ensure the condensate reservoir is empty and condensate pump is operational.
300 Freeze Protection Thermistor	<ul style="list-style-type: none"> Check sensor wiring for damage. Measure the resistance of the sensor. Replace if necessary.
350 Supply Thermistor	<ul style="list-style-type: none"> Check sensor wiring for damage. Clean the surface of the sensor. Measure the resistance of the sensor. Check the return thermistor. Replace if necessary.
360 Return Thermistor	<ul style="list-style-type: none"> Check sensor wiring for damage. Measure the resistance of the sensor. Replace if necessary.
370 Indirect Tank Thermistor	<ul style="list-style-type: none"> Ensure DIP switch 4 is set to the appropriate setting. Check sensor wiring for damage. Measure the resistance of the sensor.
380 Exhaust Thermistor	<ul style="list-style-type: none"> Check sensor wiring for damage. Clean the surface of the sensor. Measure the resistance of the sensor. Check the return thermistor. Replace if necessary.
390 Outdoor Thermistor	<ul style="list-style-type: none"> Ensure that DIP switch 1 is set to the appropriate position. Check sensor wiring for damage. Measure the resistance of the sensor. Replace if necessary.

* See "Electrical Diagnostics" section of this document.



400 Pressure Sensor	<ul style="list-style-type: none"> Check sensor wiring for damage. Measure the voltage of the sensor. Replace if necessary.
450 High/Low Water Pressure	<ul style="list-style-type: none"> If the water pressure is too low, add water into the system until at least 13 PSI is observed. Ensure there are no leaking components in the CH system. If the pressure is too high, adjust the pressure to a maximum of 30 PSI. Ensure the pressure relief valve and water fill are working correctly.
460 Low Water Cut-Off (LWCO)	<ul style="list-style-type: none"> Ensure the LWCO device is working correctly. Ensure the LWCO jumper is connected properly when LWCO is not in use. Ensure the output is 24 VAC on the PCB. If it is not, check the transformer harness and output of transformer.
520 Solenoid Valve Circuit	<ul style="list-style-type: none"> Check the flame rod and wire for damage. Close the gas shut off valve installed near the boiler. Ensure the flame rod and wire are not wet. Check the output from the PC Board to the solenoid gas valve. If the output from the PC Board is abnormal, replace the PC Board. If the output from the PC Board is normal, replace the gas control.
540 High Exhaust Temperature	<ul style="list-style-type: none"> Check the exhaust thermistor wiring for damage. Clean the surface of the thermistor. Measure the resistance of the exhaust thermistor.* If the sensor has been replaced and the error still appears, check the return thermistor. Check the exhaust duct, seal, and venting for damage.
600 Combustion Fan	<ul style="list-style-type: none"> Check the motor wire harness for loose or damaged connections. Measure resistance and voltage of motor wire harness.* Ensure the combustion fan spins freely.
1000 PC Board	<ul style="list-style-type: none"> PC Board circuit error. Replace PC Board
10 Solenoid Valve Circuit	<ul style="list-style-type: none"> Ensure Dip switch 5 on the PC Board is in the OFF position (default). Ensure the gas control wire is not loose or damaged. Replace the PC Board.
100 Flame Rod	<ul style="list-style-type: none"> Check the flame rod and wire for damage. Ensure the flame rod and wire are not wet. If there is no issue with the flame rod or wiring, replace the PC Board.
800 Freeze Issue	<ul style="list-style-type: none"> The boiler checks the heat exchanger temperature at the time of operation. If the temperature is too low, an error will occur. Check if there is freezing in the boiler or CH system.
999 PC Board Mismatch	<ul style="list-style-type: none"> This code occurs when the PC Board and the internal logic do not match. Check if the software versions of the board and operation board do not match.
FFF Maintenance Indicator	<ul style="list-style-type: none"> This code is a placeholder in diagnostic code history indicating a service provider performed maintenance or service. Enter this code after performing service by pressing the following buttons at the same time: UP, DOWN, and Indirect Tank. FFF appears on the monitor.

Gas Conversion Kits		
Models	Gas Type	Kit Number
i150S	NG/LPG	803000040
i120S		
i090S		
i060S		



ITEM	DESCRIPTION	PART NUMBER	i150S	i120S	i090S	i060S	ITEM	DESCRIPTION	PART NUMBER	i150S	i120S	i090S	i060S
			1	1	1	1				1	1	1	1
003	Lower Wall Mount Bracket	109000281	1	1	1	1	215	Air supply pipe seal ring	108000017	1	1	1	1
004	Upper Wall Mount Bracket	109000594	1	1	1	1	220	Air supply box	108000085	1	1	1	1
007	Connection Reinforcement Plate	809000165	1	1	1	1	221	Air supply filter (set)	108000086	1	1	1	1
008	Rubber Bushing	CF79-41020-A	3	3	3	3	222	Air Supply Connection	108000087	1	1	1	1
010	Residential Screw and Washer	106000645	4	4	4	4	223	Air Supply Connection - 2 inch	109000624	1	1	1	1
012	Combustion chamber support plate	109000597	2	2	2	2	410	CH Outlet Connection	807000182	2	2	2	2
015	Igniter Bracket	109000599	1	1	1	1	413	Water Pressure Sensor Assembly	807000185	1	1	1	1
016	Igniter Assembly	105000230	1	1	1	1	416	Plate Heating Fittings Assy	807000209	1	1	1	1
040	Grounding Screw	CP-80452	1	1	1	1	422	CH Heating Return Pipe Assembly	807000208	1	1	1	1
040	Front panel Assy	809000167	1	1	1	1	423	Heating Fitting Assembly	807000210	1	1	1	1
044	Screw Cover	109000020	2	2	2	2	431	Heat Exchanger Pipe Connection Assy-Large	807000193	1	1	1	1
045	Front Panel Packing-Top	109000120	2	2	2	2	435	Trap Drain Plug Assy	807000195	1	1	1	1
046	Front Panel Packing-Side	109000608	2	2	2	2	440	HEX-CH Heating Connection Pipe	807000196	1	1	1	1
100	Burner Assembly-Large	806000049	1	1	1	1	441	Heat Exchanger Pipe Connection Assy-Medium	807000197	1	1	1	1
101	Burner Gasket-Large	109000069	1	1	1	1	442	Air vent	808000052	1	1	1	1
102	Burner Plate Assembly-Large	806000030	1	1	1	1	443	Secondary Heat Exchanger Outlet Fitting	807000198	1	1	1	1
103	Combustion Check valve Assembly	107000262	1	1	1	1	444	Secondary Heat Exchanger Inlet Fitting	807000199	1	1	1	1
105	Burner Assembly-medium	806000051	1	1	1	1	445	Primary-Secondary Pipe Assy-Large	807000200	1	1	1	1
106	Burner Gasket-medium	806000010	1	1	1	1	446	Primary-Secondary Pipe Assy-Medium	807000201	1	1	1	1
107	Burner Plate Assembly-medium	806000052	1	1	1	1	447	Primary-Secondary Connecting Fitting	807000202	1	1	1	1
110	Combustion Fan Assembly	108000081	1	1	1	1	451	Retention Clip	809000168	2	2	1	1
111	Fan mounting packing	109000611	1	1	1	1	452	Thermistor Sensor	809000170	1	1	1	1
112	O-ring	109000612	3	3	3	3	460	Thermistor Sensor	805000079	1	1	1	1
113	Hexagon Head Screw	ZQA40051.4UK	1	1	1	1	461	Thermistor Sensor	805000080	1	1	1	1
114	Gas Valve Assembly With Orifice	106000117	1	1	1	1	470	O-ring	807000202	2	2	2	2
115	O-ring	109000252	2	2	2	2	472	O-ring	807000204	11	11	10	10
116	Gas connection pipe Assy	806000034	1	1	1	1	480	O-ring	807000205	2	2	2	2
117	Gas tube Bracket	109000635	1	1	1	1	502	O-ring	807000207	1	1	1	1
118	Inlet Gas Supply Connection	106000119	1	1	1	1	504	Clip	809000174	2	2	2	2
119	Inlet Gas Test Port Screw	106000138	2	2	2	2	506	Clip	109000638	5	5	5	5
120	O-ring	M10B-13-4	1	1	1	1	705	Transformer	805000086	1	1	1	1
121	Noise filter	106000120	1	1	1	1	706	PC Board Assembly	805000092	1	1	1	1
130	Heat Exchanger Assembly-Large	807000173	1	1	1	1	707	PC Board Assembly	805000092	1	1	1	1
131	Heat Exchanger Assembly-medium	807000174	1	1	1	1	708	PC Board Cover	809000184	1	1	1	1
136	OHS Bracket	109000614	1	1	1	1	709	PC Board Assembly	805000093	1	1	1	1
145	Condensate Trap Assembly	807000175	1	1	1	1	718	Controller	805000094	1	1	1	1
146	Band RCG98HP/e, Cond drain tube, bottom KT	109000138	2	2	2	2	719	Power cord Assembly FF	105000238	1	1	1	1
147	Condensate Drain tube	807000176	1	1	1	1	719	Igniter Ground Harness	105000243	1	1	1	1
151	Electrode	105000233	1	1	1	1	800	Igniter Ground Seal	809000176	1	1	1	1
152	Flame Rod	105000234	1	1	1	1	801	Screw	109000746	4	4	4	4
153	Electrode packing	109000617	1	1	1	1	802	Screw	CP-30583	2	2	2	2
154	Electrode Plate	109000618	1	1	1	1	803	Screw	ZBA0408UK	3	3	3	3
156	Electrode sleeve	109000620	1	1	1	1	804	Screw	CP-30580	17	17	15	15
200	Exhaust duct Assy	808000050	1	1	1	1	805	Screw	109000648	3	3	3	3
202	O-ring	108000018	2	2	2	2	807	Screw	109000178	2	2	2	2
203	Exhaust Duct Packing	109000621	1	1	1	1	808	Screw	U217-449	2	2	2	2
204	Thermistor	105000235	1	1	1	1			109000641	3	3	3	3
205	O-ring	107000323	1	1	1	1							
206	Exhaust duct seal	808000051	1	1	1	1							
207	Thermistor Screw	109000622	1	1	1	1							
210	Flue Connection Assembly	108000083	1	1	1	1							
212	Exhaust pipe connection port - 2 inch	108000084	1	1	1	1							
213	Exhaust Gasket - 2 inch	109000623	1	1	1	1							