


TVS0043

Isaure Oak TV Stand 140

TOP0028

Isaure Top Ais 214 Stand 140




**(FR) Notice de Montage -
Utilisation - Entretien**

**(IT) Istruzioni per il Montaggio,
l'Uso e la Manutenzione**


**(DE) Montage - Verwendung -
Wartungshandbuch**


**(ES) Instrucciones de Montaje,
Utilización y Mantenimiento**


**(EN) Assembly - Use -
Maintenance Manual**




Screw installation








A x2 


B x2 

C x2 

D x1 




**NOT INCLUDED
NON FOURNIS**



+





(E) x 4







(F) x 4

1



2



A x 2



B x 2



C x 2



D x 1