

#### **TOOLS REQUIRED**



#### Phillips Screwdriver

(Not Included)



Hammer (Not Included)



2 - Persons Recommended

#### **ASSEMBLY RATING**



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

Thank you for your purchase!	
We hope you enjoy this new addition to your home for many years to come.	
Our commitment to providing quality pro our product. We fully stand behind our p	oducts does not simply end when you purchase products from start to finish.
CHECK BEFORE STARTING	
Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements?	Prep Time!
Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





#### **Teamwork**

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





#### **Suitable Location**

Assembling near the area of the intended location is highly recommended.





#### **Sufficient Space**

Make sure you have enough space to move around during the assembly.





#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





#### **Flat Surface**

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

## ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

## **CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS**


#### Note:

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.












Screw the cam bolt into panel.



Insert the cam bolt into the bolt hole of joint panel.



Align the cam lock with its side opening (or arrow) pointing to cam bolt.



Turn the cam lock clockwise gently until it will not turn any more.

## **COFFEE TABLE**





⑤ 8PCS

6 8PCS

0.75"


- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.







#### **GET READY**


Please group boards as below.









Part ① x1PC Part ⑥ x2PCS Hardware ② x2PCS 2 2 Front Top<sub>▼</sub> Please refer to page 5 for detailed instructions on how to fasten cam locks (#2) to cam bolts (#1). Part x1PC Part x1PC Hardware ② x3PCS **(3**) Front Top▼







9



10






## 13

Part N x1PC

Accessory A2 x4PCS





14

## ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the produst wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

