



## Classic Cascading Mantel Swag

**HDC18BLB**

**Indoor/Outdoor**

1. Place the mantel swag on a flat surface. Straighten and separate all branch tips. To achieve maximum fullness, tips should not touch one another.
2. From back of the mantel swag, find the battery box and open it. Insert 3 D batteries into the battery box then close it .
3. The battery box is featured with a 3-position switch: On – Off – Timer. The timer enables the LED lights to remain on for 6 hours, then off for the next 18 hours. This will repeat daily.
4. Arrange swag on the mantel as desired. Branches may be arranged to cascade off the mantel, or tucked on top of the mantel.

### **Battery Warning:**

Adult supervision is necessary when changing and disposing of batteries.

Slide switch to "OFF" position when changing batteries.

Confirm proper polarity when inserting batteries.

Do not attempt to charge non-rechargeable batteries. Only recharge rechargeable batteries and do it under adult supervision.

Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

Do not short circuit terminals under any circumstances.

Do not allow the bottom of the unit to come in contact with heat.

Never throw batteries in a fire or attempt to open batteries. Batteries may explode or leak.

Replace batteries when the light is faint.

Replace all batteries at the same time.

Remove exhausted/dead batteries from unit.

Remove all batteries from unit before storage.

Batteries are harmful if swallowed. Keep away from young children.

THANK YOU FOR YOUR PURCHASE

Comments or questions?

Call us at 1-877-359-0115 or

Contact us at [customerservice@haute-decor.com](mailto:customerservice@haute-decor.com)

Haute Decor  
PO Box 1594  
Allen, TX 75013

