


Intelligent Toilet Manual

CONTENT

List of Functions ---- 01
List of Configurations ---- 02
Safety ---- 02
Warning ---- 03
Using Notes ---- 07
Names of parts ---- 09
Side Knob operation ---- 09
Digital display ---- 10

Instructions

Check-lists before initial start-up ---- 10
Remote Control ---- 12
Detail of Remote Control ---- 13
Optional Featured Function ---- 15
Foam Shield ---- 16
Operating Note ---- 17

Thanks very much for using our products.

Please read and follow the instructions carefully before using.
Save the instructions in proper place and do not loss it.

There would be a little difference from each item.

The shape of item in the manual is for reference only.

The company will not notify you of functional differences due to product upgrades and other reasons.

If there are objections, our company reserves the final interpretation right of the manual.

Routine Maintenance

Daily cleaning ---- 19
Installation ---- 20
Not use in a long time ---- 22
Replacement of battery ---- 22

Freeze in Case ---- 23

Problem & Solution ---- 24

Specification ---- 25

Main Functions

Rear Cleaning		Rear cleaning by output water from nozzle
Bidet		Bidet cleaning for ladies
Moving Spray		More cleaning effective by moving nozzle
Water Pressure Massage		The pressure of the cleaning water alternates to achieve the effect of massage.
Children		Press one button to activate full functional auto wash without seated sense.
Nozzle Arm Position		Adjust the nozzle arm forward and backward to get the best washing position to fit the user.
Seat Heating		The cover can be kept in comfortable temp. by mico CPU control
Warm Wind Drying		Automatic drying after cleaning
Soft Close		Dampers cushion the toilet seat and lid noiselessly and slow down closing.
Auto-Sensor		The toilet will stand by while people seat on the inductive area
Smart Flushing		Auto flush will work after the user leaving the seat after sitting down for more than 10 sec, or in one-key mode or pressing the flush button.
Nozzle Self-cleaning		The spray arm and nozzle will be self-cleaned with fresh water.
Energy Saving		Set the Eco mode to save the energy.
Pressure Adjusting		Press the water pressure adjustment button to cyclically set the washing intensity.
Instant Heating		The washing water will be instantly heated to the set temperature.
Power-off Flushing		The flushing can still work while the power is off. (Optional function, subject to each model)
Auto Open		When Auto open is enabled, the lid and seat will automatically open when someone approaches about 30 CM close to the toilet (Optional function, subject to each model).
Temp. Protection		The nozzle washing will be deactivated in case that water is cut or off.
Foot Sensor Flushing		The flushing will work once time while the foot meeting the area of sensor at the bottom of right side (subject to product).
Foot Sensor		The lid will automatically open while the foot meeting the area of sensor at the bottom of right side (subject to product).
Foam Shield		Generates a foam layer with water-repellent properties. Also includes fragrance and deodorizing functions for improved cleanliness and freshness. (This feature is optional and may vary by model.)
UV Sterilization		the UV light will be activated to work for 1 min when the seat cover is close after a seated status for more than 1 min (optional function, subject to model)
Aromatherapy deodorization		Aromatherapy deodorization factor enter into air, encircle and exterminate peculiar smell molecule spontaneously, decompose and disorganize the peculiar smell molecule in the air, reduce the stink. (optional function, subject to model)
Ambient Light		Single-color ambient light can be switched on and off via the remote control.

Functions For Each Type

Function / Type	Rear	Bidet	Move	Spa	Position adjust	Warm seat	Warm wind	Deodori zation	Soft close	Power flush	Power saving	Nozzle clean	Smart flush	Press adjust	Night light	Instant heating	Seat sensor	Auto cover	Foot sensor	Foot sensor flush	Foam shield	UV Steril-zation
A	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	X	X	X	X	X	X
B	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	X	X	✓	X	X
C	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	X	X	X
H	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	X	✓	X
J	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	X	X	✓

This list consists the full functional features. For the model you choose, there will be optional function, subject to model.

Safety Notes

Please read and follow the instructions carefully before installation and using.

The instructions must be followed while using the product.

⚠ WARNING -Avoid accident of electric shock

1. Do not use the product in a wet environment.
2. Do not drop the remote control into bath tub or sink or any liquid.
3. Do not put water onto product or electric plug.

⚠ WARNING -Avoid accident of getting burnt, electric shock and fire

1. It requires someone to accompany while using the product for people who can not adjust the temperature correctly like children, elder, disabled, paraplegia, etc..
   And please set the temp. to lowest level or shut the function down.
2. The product includes functions showed in this manual only.
   Please do not use extra devices unless we recommend.
3. Do not replace the wire or electric plug yourself while it is broken or dropped into water. The correct way is to call the professional maintenance sta ffto handle it or send it to a maintenance center.
4. Please ensure the wire would not be burnt.
5. Please do not use the product if you take sleeping pills or are over drinking， or feel drowsiness.
6. Please do not put anything into the hole or water tube.
7. Please do not use the product outdoors.
8. Please do not allow children play the product as toy.
9. Please use the new fittings and hose we supply.
   The old fittings and hose can not be reused.

Please Keep The Manual in place

Safety Notes

Please do read and follow the instructions carefully before using. They are about safety of person.

Symbols and meanings	
Warning	Ignoring this tag may cause serious injury or death.
Caution	Ignoring this tag may cause injury or property loss.

Symbols and meanings	
	Dismantling is forbidden.
	Must follow.

Warning


No splash

It is forbidden to drop any water and detergent on the product or the electric plug.

- May cause fire or electric shock.
- May cause breakage or leaking.

The smart toilet is an electric product. Please avoid splash and use it in a wet environment. Maintain air circulation when the product is used in bathroom.

- May cause fire or electric shock.

Set the electric socket as below

- May cause fire or electric shock if not follow the instructions.

a. Please use a high-sensitivity and fast leakage switch for the circuit of the electric socket. Or to use insulated transformer (>1.5KVA, <3.0KVA).

b. The electric socket should be installed 0.3m at least up to ground and away from the bath tub.

Must install the ground wire

- May cause electric shock without ground wire.

Attn: The electric resistance should be 4Ω and the diameter of the copper wire should be 1.6mm or above.

Using the product in bathroom

Make sure the power plug has been waterproofed with silica gel.

- May cause fire or electric shock without waterproofing.

Warning


No wet

1) The user can't directly spray water on this toilet, can use a damp cloth to clean.

2) The plug and socket of this toilet can't directly touch with water, and it supports to be used in a humid environment such as a bathroom.


No disassemble

Dismantle, repair or remould the product are forbidden

- May cause fire or electric shock.


Forbidden

Stop using the product while it has malfunction

- Please pull out the plug and turn off the inlet valve.

Malfunction:
Leakage
Dehiscence
Abnormal sound & smell
Fuming & abnormal heating
Blocking

- Keep using the product while it has malfunction may cause fire or electric shock or leakage.


Forbidden

Do not use a unsteady socket

- May cause fire or electric shock.


Forbidden

Do not use water sources other than city water

- May cause dermatitis.


No wet hand

Do not touch the electric with wet hands.

- May cause electric shock.


Forbidden

Do not damage the electric wire/connected toilet

Do not pull,process,heat,forcefully bend the electric wire connected toilet.

Do not put heavy item onto the electric wire,connected toilet.

- Ignorieg the breakage and keep using product would cause fire, electric shock or short circuit.


Forbidden

Do not use the power socket with lots sockets

- Do not remould the wire we supply. That would cause fire or electric shock.


Forbidden

Do not use the AC except 110v

- May cause fire.

Warning


Must follow

PREVENT GETTING BURNT

- Please set the seat temp. to home temp. if seating in a long time.
- Please set the seat temp. to home temp. and set the drying temp. to the lowest level for special people.

Users people who can not adjust the temperature correctly like children, elder, disabled, paraplegia etc..

who take sleeping pills or over drinking or weary or drowsiness

Warning

No fire

Do not any fire thing get close to the product

- May cause fire.

Forbidden

Do not block the outlet of warm wind

- May cause fire, electric shock or breakage.
- Pay attention to children or the elder is using the product.



Forbidden

Do not tackle the product strongly
Do not stand on the product or put heavy items on it

- May cause breakage or injury.
- May cause leakage.

Forbidden

The surface can be cleaned with neutral detergent only
Do not use things as below

(Bath detergent, domiciliary detergent, petrol, thinner, cleaning powder, nylon brush, etc.)

- May cause breakage or injury.
- May cause leakage.

Forbidden


Do not dismantle the inlet fillter while the inlet valve is on

- May cause leakage.

Forbidden

Do not bend the tube

- May cause leakage.



Forbidden

Do not drop into the toilet bowl

- May cause block & leakage.

Must follow

Ture off the power if the product is not in use for a long time

- Pull out the plug for safety.
- May cause dermatitis by rancid water.

Must follow

Ture off the inlet valve while it is leaking

Must follow

Prevent the damage from being freezed

- The inlet device and part of prodcut would be damage by freezing and cause leakage.

Must follow

Solidly install the inlet valve

- May cause leakage if not to do.

Please keep proper home temp.

Must follow

Plug the electric plug well

- May cause fire if the plug is unsteady or not plugged well.
- Pull out the electric plug if the product not in use in a long time

Must follow


Please pull out the electric plug while the toilet is blocked Reuse untill the blockage is cleared

- May cause leakage while running the cleaning function if not pull out the electric plug.

Must follow

Do not expose the product in direct sunlight


- May cause damage of discoloration, aging and deformation.




Using Notes

Wrong cleaning manmers

Do not wipe the product with dry cloth or toilet paper.




Flushing directly is forbidden




Routine maintenance

Do not urinate on the nozzle or product.



Pull out the electric plug when it is thundering.



Attention of operation

Do not cover the sensor area, foot sensor, and the signal receiving and sending area of the remote control

Radio or similar products should stay away from the toilet.

- May cause much noise.

Do not lean your back on the cover


- May cause breakage.

Take the childen cover away after childen using the toilet fany.

- Not doing so may cause some functions can not run.


Using Notes

Please prevent the freezing in winter to avoid damage.




The heating apparatus should stay away from the product.

- Not doing so may cause discoloration or errors.




Please open the cover lid and cover seat gently.


- Not doing so may cause breakage or errors.



Name of Parts



Side Button Functions




When seated, press this button to start the rear wash. Press again to switch to moving wash, and repeat to alternate. Press the "Stop" button to end the operation.
The function will also stop automatically after the user leaves the seat.
When not seated, press this button to activate the nozzle self-cleaning function.

When seated, press this button to activate the feminine wash. Press again to switch to moving wash, and repeat as needed. Press the "Stop" button to end the operation.
When not seated, press this button to activate the nozzle self-cleaning function.

When seated, during washing or drying, press this button to stop the ongoing function. If no function is active, pressing once initiates flushing; long press to activate drying.
When not seated, press once to flush; long press to perform software shutdown. (In software shutdown mode, a single press can still flush. During power outages, flushing is available via battery backup.)

LED Display



(Top LED display on the smart toilet seat)

Indicates the current water temperature level of the washing nozzle.

ECO Indicates the smart toilet is currently in energy-saving mode.

Indicates the four wind levels for warm air drying. The more bars that are lit, the higher the temperature. No lit bars indicate room temperature.


Indicates the four levels of seat temperature. The more bars that are lit, the higher the seat temperature. No lit bars indicate room temperature.

Before Using

Please confirm things as below before using the product at first time.


Plug well

1. Plug in the Listed local voltage.



2. Please the inlet valve is opened or not.

Leakage Protected Plug



1. Please test once time each month
2. Press the "test" button
3. Confirm that the "pilot light" is off
4. Confirm that the product is out of work
5. Press the "reset" button to boot the the poduct if every steps as above are OK.


Warning

- Please make sure the gound wire.
- Please contact electrical installation company if your socket is without ground wire.
- The original electric plug is for triple electrode type. (with ground wire)
- There will be changer of the electric shock while the product is out of work.
- Ensure the proper installation of water pipe, tube and valve, otherwise that would cause leakage and loss.

Before Using

Confirm each function

1. The nozzle, water pipe and tube.
2. The light of “saving mode” on LED display should be o ffwhile the seat sensor area is covered.
3. Check the rear & bidet washing, defecation assist, deodorization and drying function is well or not.
4. Check the damping is well or not.



Confirm that the seat sensor is on working and the light of “saving mode” or the pilot light is o ffbefore checking the function of washing, drying and deodorization.

⚠Caution


1. The washing function is for instant heating type.
   The function would be out of work if the water inlet is error.
2. Ensure the inlet valve is open and the inlet tube is not bent after the product is booted.

⚠ Warning


Only the listed voltage is accepted(AC 110V 60Hz). Please follow the relevant regulations for wiring.

* Will cause fire if ignore this warning *


Remote Control



Top View



Front View



Rear View

Pair the remote control to toilet

Step1: Unplug the power cord from the socket to cut off the power supply.

Step 2: Keep pressing the “bidet/female” key on the remote control until all indicating lights are flashing, then plug the the power cord of the smart toilet to the working socket, and wait until all lights are off to complete the pairing.

Please make sure there is sufficient power supply for the remote control before pairing. Cut off the power of the intelligent toilet for 30 seconds and then apply the above steps for paring to remote control.

Operation

Power on/off

Press the "Power" button on the remote control to turn on the toilet, press the power button again to turn it off.

Seat Temp.

Press the "Seat Temp." button to set the seat to a level of high, medium, low, or room temperature.

Water Temp.

Press the "Water Temp." button to set the washing water to a level of high, medium, low, or room temperature.

Wind Temp.

Press the "Wind Temp." button to set the dryer wind to a level of high, medium, low, or room temperature.

Rear washing

Press the "Rear" button to activate the washing via the nozzle, press again to activate moving washing. (Rear washing can only be activated when a user is sitting on the toilet.)

Front washing

Press the "Front" 、 "Female" button to activate the front washing, press again to activate moving washing. (Front washing can only be activated when a user is sitting on the toilet.)

Children

Press the "Children" button will automatically run washing-dryer-flush step by step with medium temperature, press the "Stop" button to stop immediately. (This function can be activated with or without a user is sitting on the toilet.)

Massage

When the rear or feminine wash function is active, press the "" massage button to enable alternating strong and weak water pressure for a soothing cleanse.

Position

Press the "Position" button to adjust the nozzle forward or backward of moving washing while the rear, Children or bidet function is running. The nozzle will move forward and backward. Press the same button to stop moving.

Water Pressure Massage

Press the "Water Pressure" + − button to start with a switching high-low pressure of washing water while the rear or bidet washing is working.

Flush

Press the "Flush" button will start flushing for one time. When the toilet senses a user leaves after sitting on it for more than 10 sec, it will automatedly flush one time. And after the rear washing or bidet washing finishes working with a seated status, the toilet will automatedly flush one time.

Dryer

Press the "Dryer" button to start. Without manually stop, it will stop working after 3 mins.

Operation

Night lighting and ambient lighting

Press the "Light" button to turn on or turn off the night light and ambient lighting.

Stop/Reset

Press the "Stop/Reset" button to stop any running function like rear washing, dryer, etc.

Auto Open/Close (optional function, subject to model)

The seat cover will open itself when people get close to the toilet, and the seat cover will close itself after 30 sec if a user stays near the toilet and leaves after 5 sec. When it is with an open seat and seat cover, if a user stays near the toilet and leaves within 5 sec, the seat cover will close itself after 120 sec. When it is with an open seat and seat cover, if a user stays near the toilet and leaves after more than 5 sec, the seat cover will close itself after 30 sec. When it is with an open seat and seat cover, if a user stays near the toilet and leaves within 5 sec, the seat cover will close itself after 120 sec and flush one time with closed seat and seat cover. (optional function, subject to model)

Open Cover (optional function, subject to model)

Press the "Cover" button to open the cover when it is closed. Press the "Cover" button to close the cover when it is open. (This setting will not work with a seated status) (optional function, subject to model)

Open Seat Cover (optional function, subject to model)

Press the "Seat Cover" button to open the seat cover when it is closed. Press "Seat Cover" button to close the seat cover when it is open. (This setting will not work with a seated status) (optional function, subject to model)

Foot Sensor Function

For models equipped with an automatic seat ring (Models C, E, and H):When the user's foot touches the foot sensor located at the front bottom of the toilet, the seat ring will automatically open. Pressing the sensor again will close the seat ring. Model B does not support the automatic seat ring function; pressing the sensor once will trigger a single flush.

Energy−Saving Function

When the energy-saving mode is activated, if no operation occurs for over 12 hours, the seat temperature will automatically switch to the lowest setting; after 48 hours, the seat temperature will turn off completely.

Foam Shield Function (Optional Feature)

For models equipped with the foam shield function, when not seated, press the foam shield button "" on the remote control. Press and hold the "" button for 3 seconds to turn the auto foam shield mode on or off (foam shield automatically activates upon sitting). When seated, press the foam shield button "" to manually activate the foam shield function. In auto foam shield mode, the foam shield will only be reactivated automatically if you sit down again at least 1 minute after leaving the seat.

UV Sterilization Function (Optional Feature)

After a person has been seated for 60 seconds, and the lid is closed within 3 seconds of standing up, the UV light will activate to sterilize the bowl.

Low−Temperature Burn Protection

All models are equipped with low-temperature burn protection. When seated, the seat temperature will automatically lower to the minimum level. Once the user stands up, the previous temperature setting will be restored.

Operation

Fragrance & Deodorization Function

Press the fragrance button "" once on the remote control to activate the fragrance function. It will automatically turn off after 5 seconds. Press and hold the " " button for 3 seconds (a single beep will sound) to enable seat-activated automatic fragrance release. Press and hold the " " button again for 3 seconds (double beep) to disable the seat-activated automatic fragrance function.

Advanced Features

Microwave Sensor Switch (Optional Feature)

Press and hold the "Night Light Key" on the remote control, then use the water pressure "+, -" keys to adjust the setting level. At level 05, the sensing distance is at its maximum; at level 00, the microwave function is turned off.

Soft Power-Off

When the seat is unoccupied, press and hold the knob to toggle the "Stop" button for powering on/off.


⚠ **Note:** The drying and cleaning functions cannot be used when the seat is unoccupied.

Fragrance Refill Instructions


When the fragrance solution is used up, if you do not intend to continue using the fragrance function, please turn off the automatic fragrance mode to protect the atomizer.

Follow the steps below to refill the fragrance:


1.Open the rear trim cover and remove the rubber cap of the fragrance compartment.




2.Fill the provided small plastic bottle with water, then pour the water into the liquid compartment (maximum of two bottles per refill).



3.Use the provided dropper to add fragrance oil into the compartment (recommended: 2–3 drops).




4.Reinsert the rubber cap and reattach the trim cover.



Foam Shield

Adding Foaming Agent

After the foam solution is used up, open the rear trim cover and unplug the silicone tube connected to the foam bottle (see illustration below). Remove the bottle and open the cap, then fill it with the designated foam solution. After tightly closing the cap, place the bottle back in its original position. Reconnect the silicone tube to the bottle, ensuring the two tubes are not connected in reverse (the transparent tube must be connected to the nozzle with the silicone connector).



Note:
During initial use, air in the tube may prevent the foam solution from reaching the foamer. It may require activating the foam shield function 2–3 times before foam is dispensed normally.

Troubleshooting

Issue	Cause	Solution
No foam dispensed from the outlet	Foaming agent depleted	Add foaming agent solution
Poor foaming effect	Water inlet angle valve is closed	Open the water inlet angle valve
Foam Shield does not activate upon seating in Automatic Mode	Foam Shield function not set to Automatic Mode	Enable the Foam Shield Automatic function
	User not seated within the sensor range	Adjust seating position
Remote control cannot activate functions	Remote control battery is low	Replace the remote control battery

If the issue persists after following the above steps, please contact the dealer from whom you purchased the product or the company's after-sales department.

Water Temp.

Capacity

Due to the instant heating mode, the water temperature will not decrease during extended cleaning periods, although there may be some fluctuations that do not affect usage.

Water temp. base on levle setting


Normal: No heating
Low : About 34°C
Mid : About 37◦C
High : About 40°C

The effect of heating dependson the water temp.



Seat Sensor

The washing functions would not run by operation in error



The seat sensor would not work if:

※ No people the seat sensor area.

Energy Saving(ECO)


Would save energy as below

- Close the cover after using
- Do not set the high level for temp. every time
- Set the suitable temp. on seasons and air temperature
- Use the energy saving as much as possible
- The power if the product will not in use for a long time

※ Prevent the freezing


Close Cover Softly

The soft-close device would avoid the noise of cover colsing



Water flow out ?

That would be normal that some water flow of the nozzle before/after washing or while the water temp. setting is on.



Please close the inlet valve and pull out the plug if the water keep flowing out besides the situations as above. And you need to contact the agency.

Maintenance


⚠ Warning

Make sare to unplug pull out the electric plug and confirm the pilot light is off before maintenance.

Maintenance of Smart Toielt

Please use soft cloth with clean water

・Please wipe the product often with wet soft cloth in case of the dirt is too hard to clean out. In addition, the wet soft cloth can avoid the static to adsorb dust and cause the product dirty.




Maintenance of Nozzle

Please clean the nozzle with soft brush.

※ Turn the knob key until the nozzle is out after leaving the cover seat.

※ Do not pull out and bend the nozzle by force.



⚠ Warning

Must follow

Please clean the dust on the electric plug.
Clean the plug with dry cloth after pull it out of socket.

※ Poor insulation may cause fire.

Installation

INSTALLATION DRAWING PLAN & Names of Parts

As shown in Picture No.1, be the major component and construction points

Length Unit : mm




Fig1

Before Installation

Required tools may include Adjustable
Spanner, levelling instrument, cross screwdriver, glass cement, slotted screwdriver, measuring tape, knife, etc.

Installation Procedure

Please mark the center line of the drain outlet on the ground,then according to the size of the toilet, install the water inlet angle valve on the suitable point of the wall.

※ Please install the water inlet angle valve as Picture No.shown.

※ Contruction installation Instructions please find the following Pictures NO.2,3 and 4

A Please make sure the wall is aligned with the center line of the drain outlet (there are two pit distance options,305mm and 400mm)

B Please mark the location of the center hole (Use the right installed holes based on the real situation)

C Please roll over the toilet gently, make its side with accessary and seal ring be press firmly to the drain outlet of the toilet buttom.

D Please make sure the toilet drain outlet is aligned with vertical position of the outfall




Fig2




Fig3






Fig4

※Toilet Installation





Installation


Tips 1


1.Please make sure the pipes be cleaned ,then go to the installation.Becasue the hosue has just been renovated and may left less mud and sand,very easy to damage the toilet and bring something bad towards human' body.
2.Please ask the professional fixed workers to do this job,and make sure carefully every part is correct when done.Kindly please use it after 48 hours when the gule be set.

Tips 2

After Connecting the water pipe and turn on the angle vale, if the nozzle have the situation of water penetration,please be plugged in, it will automatic reset and stop water penetration.Pleae turn off the power supplies and thewater when you are going to take it apart.
1.During the using and cleanning,if power cut happened, please do not touch the nozzle. When the power on, the function will be back normal by self-test.
2.Please use the supplied special Water inlet angle valve and the related accessary strictly.

Cleanning the angle valve.





Turn off the angle valve, open the back side by flat screwdriver or coin tool, then remove the filter and cleaning

Warning

1.It is strictly prohibited to disassemble or disassemble privately becasue the accessary of intelligent toilet was turn up well when you buy it.
2.All content of this operating manual,are based on the latest situation of the product at the time of printing, the company reserves the right to change, No Further notice will be given.

1. Must pull out the plug
2. Must clean up the water in toilet
May cause electric shock if not to do
May cause the fittings damage by water if not to do
3. Do not extrud the wire and tube
May cause electric shock or leakage
4. Handle with care while dismantling the cover to cleanMay cause leakage and error
5. Do not put the cover upside down and put on the ground without pulling out the plug
May cause damage of surface and error
6. Before removing the toilet cover, be sure to completely empty the storage liquid in the aromatherapy box with polyester cotton. Otherwise, the storage liquid will leak into the base and a fault will occur.

Do not put the cover upside down.
Do not put the cover on the ground.



Not in use long term

Must clean up the water for situations as below

- The product will be not in use for a long time that would cause blockage by polluted water
- The water will be freezed and leakage cause by falling temperature in uninhabited house

Caution

Must the inlet valve before dismantling any inlet tube
Ensure correct installation of inlet tube
※ May cause leakage easily

Replacing Battery


The pilot light will be getting light or off and the signal can not be transmitted when the battery is almost done.

※ The service life of battery we supply will be very shot cause it is mainly for checking conditions of running in the installation.

- Ensure the position of positive pole and negative pole is correct
- The new and old batteries can not be mixed together
- Please use alkaline battery

Replacing battery of remote control

Open the back cover of remote control and replace two 1.5v AAA alkaline battery



Freezing Damage

The smart toilet will be damage and leakage cause by freezing water from toilet in winter.

Please follow the instructions as below to aovid it.

General Measures	
1. Keep power on	**No water out cause freezing** Please use the hot cloth cover on the inlet valve or connecting parts until the water is unfrozen when the water is frozen.
2. Set the water temp. and seat temp. to high level and close the cover	**Caution** Do not put the hot water on the tube and do not blow hot air on it. ※ May cause damage of tube
3. Turn on the heating in house · Please follow the ways as below to clean up the water from inlet tube if there is not heating. a. Close the inlet valve b. Run the rear washing until there is no water out after setting to normal level and put a hand on the seat sensor area.	

⚠ Caution

Must close the inlet valve before dismantling inlet tube.

Ensure correct installation of inlet tube.

※ May cause leakage easily



Error Recognition

There are some simple can be fixed easily.

Please confirm matters below before sending the product to a maintenance center.

Error	Reason	Method
No water out	power of socket is off	check if power failure
	power of product is off	press “start” button to boot the toilet
	no plug in socket	plug in socket well
	leakage of electric	pull out the plug and send the product to maintenance center
	inlet valve is closed	open the inlet valve
	the fillter is dirty	clean the fillter
	inlet tube is blocked	clean up the tube
	out of seat sensor area	adjust the seating position
	the nozzle is blocked	clean the nozzle
	low water pressure	increase water pressure
	water pipe or tube is frozen	Please use the hot cloth cover on the inlet valve or connecting parts until the water is unfrozen
Water not warm	not set the proper water temp. yet	presse water temp. button and set a proper level
	temp. of inlet water is too low	run washing for a while and check after a period of time
Cover not warm	not set the proper seat temp. yet	presse seat temp. button and set a proper level
Smell not well	blocked by dust	clean the part of deodorization

Please contact fora service if the faults still can not be fixed.

Specifications

Part			Spec.
Rated voltage			AC110V 60Hz
Power			1200W
Washing functions	Water flow	Rear	400-620 ml/min
		Bidet	450-640 ml/min
	Outlet temp.		home temp. 34℃、37 ℃、40℃(4 levles)
	Pressure		4 levles
	Heating power		1400W (max)
	Safety device		Leakage protector,Water temperature sensor,Thermal fuse
Drying	Wind temp.		home temp. 45℃、50℃、55℃ (4 levles)
	Heating power		250W
	Safety device		sensitive switch, temp. fuse
Seat heating	Seat temp.		home temp. 34℃、37 ℃、40℃(4 levles)
	Heating power		45W
	Safety device		sensitive switch, temp. fuse
Massage			Variable massage pressure
Nozzle position			adjustable for forward and backward
Inlet water temp.			5℃~35℃
Inlet pressure			1.5–7.5khf/cm² (0.1.5 –0.75Mpa)
Carton size			730mm × 480mm × 540mm
G.W			≈43 kg