


Ceiling Fan

Installation Instruction

SAFETY INFORMATION

Please read all safety information and instructions before installing the ceiling fan and save this manual for future reference.


SAFETY INFORMATION	01
PRE-INSTALLATION	02
INSTALLATION INSTRUCTION	04
OPERATION INSTRUCTION	08
SPECIFICATIONS	09
TROUBLESHOOTING	10

SAFETY INFORMATION

WARNING

- Before connecting the power supply, make sure that the power supply used matches the specifications of the ceiling fan.
- All wiring must comply with national and local electrical codes ANSI/NFPA70. If you are not familiar with wiring, please use a qualified electrician.
- To reduce the risk of fire or electric shock, turn off the power to the fuse box or circuit breaker before installing the fan.
- To reduce the risk of personal injury, attach the fan directly to the building's support structure and ensure that it can accept at least 35 pounds (15.9 kg).
- Make sure that the installation location allows the fan blades to rotate without obstacles.

Installation Location




WARNING


- Do not install the fan with wet hands.
- Do not insert foreign objects between the rotating fan blades.
- Do not bend the fan blades when installing or cleaning the fan.
- Do not disassemble or modify this product or use non-original parts without permission.
- Keep children away from your working area.
- Properly dispose of the fan's packaging material.
- Make sure the ceiling fan is firmly secure to the ceiling. Double check all connections before you restore power.
- Turn off the fan and wait for the blades to stop completely before performing any maintenance or cleaning.

PRE-INSTALLATION


Tools Required (Not Included)


Power Drill



Screwdriver


Step Ladder



Wire Stripper


Electrical Tape


Parts List




Mounting bracket X1




Light Cover X 1



LED & Light Kit Pan X 1




Motor X 1




Canopy X 1




Fan Blade X 3




Blade Screw X 8




Aircraft Cap X 2



Self-tapping Screw X 4




Expansion Bolt X 2



Remote Control Bracket X 1



Remote Bracket Screw X 2




Balance Kit X 2



Wire Caps Screw Terminals X 3




Remote Control X 1




Receiver X 1

INSTALLATION INSTRUCTION

Step 1: Mounting Bracket Installation




1. Drill holes with electric drill (φ8 mm).
2. Use expansion screws to fix the mounting bracket to the ceiling.




Fasten the mounting bracket to the ceiling with self-tapping screws.


Step 2: Fan Blade Installation




1 Loosen and remove the three screws that are not tightened




2 Align the three holes on the canopy with the main body of the motor and secure in place




3 Tighten the three screws.



1 Place the fan blade on top of the motor, align the holes and tighten the screws



2 Install the three fan blades.





3 Loosen the three screws on the light kit mounting plate.


Note:

- The fan blade needs to be aligned with the "center" position of the screw hole group.
- Do not lock the screws when installing the blades and then tighten all the screws after all the fan blades are installed.

Step 3: Installation of LED Board








❸ Thread the motor line through the LED board, then align the LED board with the triangular cover on the motor and put it on.


❹ Install the screws on the triangular cover into the corresponding holes.

❺ Connect the motor line and the lamp panel line.

Step 6: Wiring Instruction

⚠ Shut off the power to the fuse box or circuit breaker before wiring.





❶ The receiver is connected to the motor power cord and the ceiling power cord respectively.


❷ Hang the ceiling fan on the hook of the hanging disc.

Note:
Connect wires color to color, plug to plug.


L Live Wire

N Neutral Wire


Ground Wire




❸ Connect the motor wire and connect the blue and white wires of the lamp wire to the blue and white wires of the receiver respectively



❹ Twist the two black wires (L) together and the two white wires (N) together




❺ Screw on the wire caps at the wire head




❻ Put the receiver inside


Step 6: Install the ceiling fan




❸ Install the screws on both sides of the hanging disc (leave 3-5mm)



❹ Insert the ceiling fan into the gap position





❺ Rotation to the right



❻ Tighten the four screws

Step 7: Install the Lampshade






❶ Put the light cover to the LED board.

❷ Spin forward to tighten the light cover.

OPERATION INSTRUCTION

Control Method



Notice：

The remote controller only needs to be paired once. After the paired product, the controller will have memory. The products have been paired before leaving the factory. When the remote control is damaged or lost, it is necessary to implement remote control pairing before using a new remote control.

(1) **All OFF:**
- Turn OFF the Fan and Light together.
- Long press:press and hold the key for 2-3 seconds. A long press produces a long beep to activate the memory function for the fan's state before power-off. A long Pressing again will produce two short beeps to deactivate the memory function.

(2) **Light ON/OFF:**
- Press the key to turn on or turn off the light.
- Long press:press and hold the key for 2-3 seconds. A long press produces a long beep to activate the memory function for the light's state(on or off) before power-off. A long Pressing again will produce two short beeps to deactivate the memory function.

(Just remember the state (on or off) of the light, not the light's color temperature)

(3) **Fan speed:**
- Press keys 1-6 to adjust the fan speed.

(4) **Fan OFF / Remote control pairing:**
- Turn OFF the fan.
- For remote control pairing, press and hold the button for 3-5 seconds within 30 seconds of powering on. The buzzer will emit a long beep to confirm that the pairing is complete.
  Note: The remote controller only needs to be paired once. After pairing, it will retain memory. Products are pre-paired at the factory. If the remote control is damaged or lost, pairing with a new remote control is necessary before use.

(5) **Timing control of the Fan:**
- Press the 1H/4H/8H keys to set the fan timer for 1, 4, or 8 hours. The fan will automatically turn off when the timer ends. During the timing function, all functions of the ceiling fan can be operated.To cancel the timer setting, press key(1) or key(7) while the timing function is active.

(6) **Natural wind:**
- Press the key to activate the natural wind mode, which automatically adjusts the fan speed between levels 1 and 6.
- Press and hold this button until a long beep is heard to clear the code. Then, press and hold the 'FAN OFF' button to re-pair and restore the program to factory settings.

(7) **Direction of the fan:**
- Change the direction of the fan using the appropriate controls.

(8) **5-minute delay function:**
- Press the key to activate the 5-minute delay function for the light, after which it will automatically turn off.
- Note: After the delay, the fan remains unchanged. This function is primarily for pre-sleep lighting delays. If used before leaving, you'll need to manually turn off the fan with 'Fan OFF'.


(9) **Turn ON/OFF the buzzer sound:**
- Press the key to toggle the buzzer sound on or off.

(10) **Increase brightness:**
- Press the key to increase brightness.


(11) **Decrease brightness:**
- Press the key to decrease brightness.

AAA battery (2):
- Install 2 AAA batteries before use.
- Remove the batteries when not in use for an extended period.

Reversible Function



Summer (Forward):
A downward airflow creates a cooling effect.



Winter (Reverse):
An upward airflow increases the indoor temperature.


PS: If you want to change the fan's rotation direction, please press the button while the fan is running.

Timing Control


1H: The fan will automatically shut off after 1 hour.
4H: The fan will automatically shut off after 4 hours.
8H: The fan will automatically shut off after 8 hours.

Close the Timing Control: Press the button "FAN ON/OFF"

SPECIFICATIONS



Product Name	Ceiling Fan	Size	42"	52"	60"
		Gross Weight	4 KG	5 KG	6 KG
Rated Voltage	110V-265V	Motor Power	19W	35W	40W
Lamp configuration	20W LED	Motor Spec	Φ140*10	Φ140*10	Φ140*15
Lampshade size	Φ180 mm	Overall height	350mm		
control method	Remote Control	Fan blade	3 fan blades		



TROUBLESHOOTING

If there is a problem with the fan during use, please check the following tips for solutions. If the problem still cannot be solved, please contact our after-sales team.

The Fan Dose Not Respond to the Remote Control.

- Check that all wire connections are correct and secure.
- Verify that the power is turned on and reaching the receiver.
- Verify that the batteries of the remote control are installed with the correct polarity, making sure to install the + (positive) end of the batteries on the solid end and the - (negative) end on the spring.

The Fan Makes a Humming Noise.

- Make sure the controls you use are supplied with your fan.
- Make sure all accessories are securely fastened. Loose parts often cause a vibrating noise or buzzing sound.
- Disassemble the fan and reinstalling it can sometimes remedy this resonant vibrating noise.

The Fan Makes a Repetitive Ticking Noise.

- Check for obstructions in the rotor path.
- Make sure mounting hardware at the ceiling is firmly fasten.
- Make sure all other hardware and blade attachments are tight.
- Give the fan a "Break in Period" of a few hours to a few days, then repeat the steps above.

The Fan Wobbles.

- Make sure the mounting plate and hardware at the ceiling are firmly fastened.
- Make sure all screw fittings on the fan are tight.
- If necessary, use the self-tapping screws provided to further secure the bracket to the joist.

Warning sound.

- In the case of a motor fault, a buzzer is typically used to emit a warning sound. When the motor lacks a phase, meaning that one of the phases is not functioning properly, the buzzer will emit a continuous single beep as a warning. This indicates that the motor is unable to operate correctly.
- if the motor gets stuck and cannot rotate, the buzzer will emit a continuous double beep as a warning. These warning sounds are intended to alert users to the abnormal conditions of the motor and prompt them to perform necessary repairs or inspections.

CONTACT INFORMATION

We want to hear your voice! Feel free to touch base if you encounter any issue when using our product(s) or want to know more about our brand.
We will be more than happy to provide top-notch pre-sales & after-sales service 24/7.