HAUTE DECOR

CLASSIC PRE-LIT GARLAND 6 FOOT
Item # HDC1861



Instructions:

1) Place the garland on a flat surface. Straighten and separate all branch tips. To achieve maximum fullness, tips should not touch one another.

2) From back of the garland, find the battery box and open it. Insert 6 AA batteries into the battery box then close it.

3) The battery box has a push button. Press the button once to activate the timer. After pressing the button once, the lights will turn on and remain on for 6 hours, then they will turn off automatically for 18 hours. They will turn on again automatically in 18 hours (at the same time you first pressed the button). This will repeat daily.

4) Press the button again to turn off the lights.

5) Suitable for indoor or outdoor use.

Battery Warning:

1. Adult supervision is necessary when changing and disposing of batteries.
2. Confirm proper polarity when inserting batteries.
3. Do not attempt to charge non-rechargeable batteries. Only recharge rechargeable batteries and do it under adult supervision.
4. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
5. Replace batteries when the light is faint.
6. Replace all batteries at the same time.
7. Remove exhausted/dead batteries from unit.
8. Do not short circuit terminals under any circumstances.
9. Do not allow the bottom of the unit to come in contact with heat.
10. Never throw batteries in a fire or attempt to open batteries. Batteries may explode or leak.
11. Remove all batteries from unit before storage.
12. Batteries are harmful if swallowed. Keep away from young children.

THANK YOU FOR YOUR PURCHASE
Comments or questions?
Call us at 1-877-359-0115 or
Contact us at customerservice@haute-decor.com

Haute Decor
PO Box 1594
Allen, TX 75013

HAUTE DECOR

Made in China
0425 RevA