

CABINET N725P322739

Assembly Instructions - Please keep for future reference





Two people are required to assemble and move this model.

Important – Please read these instructions fully before starting assembly

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them

• Keep children and pets away from the installation area, which may cause choking if small parts are swallowed.


• Make sure you have enough space to layout the parts before

• Do not stand or apply weight to the product during assembly. This may cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damage to the unit or floor.

• It's easier for two people to assemble the parts together.



• To reduce the likelihood of damage to your product, make sure your power drill is set to a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• Check for loose screws on this unit from time to time.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure that all bolts and fittings are correctly tightened.

WARNING
In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


please note that only the anti tip strap is provided.
You will need to provide wall plugs and screws applicable for your wall type

Using Camlocks

Step 1


Connect the male camlock as diected in the assembly instructions using a scewdriver.

1 DO NOT OVER TIGHTEN.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the femle camlock as shown in the instruction.

Note：ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4


Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

































The joint is now secure.



Assembly Instructions










Part List：N725P322739

1  1 PC	2  1 PC	3  1 PC	4  1 PC	5  1 PC
6  1 PC	7  1 PC	8  2 PCS	9  1 PC	10  2 PCS
11  1 PC	12  1 PC	13  1 PC	14  1 PC	15  1 PC
16  2 PCS	17  1 PC	18  1 PC	19  1 PC	20  1 PC
21  1 PC	22  1 PC	23  1 PC	24  1 PC	25  1 PC
26  1 PC	27  1 PC	28  1 PC	29  1 PC	30  1 PC
31  1 PC	31  Hardware 1 PC			

Hardware list：　N725P322739

Please check you have all the panels listed below


Note: The quantitie below are the correcet amount to complete the assembly. In some cases more fittings may be supplied than are required.


A  Male Camlock x 61	**B**  Female Camlock x 61	**C**  Dowel (6x30) x 46
D  Door Hinge x 5	**E**  3.5*12mm Screw x 48	**F**  5*40mm Screw x 14
G  Shelf Support Pin x8	**H**  Laminate grains x2	**I**  Handle & Fixings x 1
J  Handle & Fixings x 2	**K**  Laminate grains x1	**L**  Ø20 Sticker x 50
M  Wall Fixing Pack x 2	**N**  Three folded pages x 2	**O**  Corner codex 2
P  Back Panel Stiffener x 22		



Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identify the screws







The screws length is measured from the head to the point (30mm screw shown).

Assembly Instructions

Step 1





Step 2




Assembly Instructions


Step 3









Step 4







Assembly Instructions


Step 5






Step 6







Assembly Instructions

Step 7







Step 8




Assembly Instructions


Step 9






Step 10










Assembly Instructions


Step 11






Step 12








Assembly Instructions


Step 13


C x 2



Step 14


B x 3







Assembly Instructions

Step 15












Step 16




Assembly Instructions


Step 17






Step 18






Assembly Instructions

Step 19




Step 20




Assembly Instructions

Step 21


B x 1






Step 22

B x 2



Assembly Instructions


Step 23




B



B x 3



Step 24




B x14

B




B x 14

180°




Assembly Instructions

Step 25




Step 26



B




B x 7




Two people are required to assemble and move this model.


B x7




Assembly Instructions


Step 27





Step 28






Assembly Instructions

Step 29

C x 4


A x 4



Step 30

F x 4

B x 4




Assembly Instructions

Step 31

E x 6


A x 7


N x 2



Step 32


B x 5





Assembly Instructions

Step 33



B

B x 2

Step 34

L


L x 9


E


E x 4

O

O x 1











Assembly Instructions

Step 35










L x 5



E x 4





I x 1




O x 1

Step 36








G x 8



L x 36










Assembly Instructions

Step 37




Step 38






Assembly Instructions

Step 39




Step 40



Assembly Instructions


Step 41



E

E x 12

Step 42



E


E x 8


Assembly Instructions


Step 43



DANGER - To prevent furniturefrom toppling attach,
mount, boltor otherwise secure to walls andfloors.
Do not put heavy items ontop shelves.
Do not place unstablefurniture near where children play.
An anchor kit suitable for plasterwalls is included with this item,
if you require a different kit consultyour nearest hardware store.









The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be epaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.


Components Name



Obvious gaps between doors or Doors don't look closed




1 Turn"internal & external screw" fo the right can make the door approach inside.
Please adjust the doors little by little..




※ If the 2 doors are overlap, please turn the"internal & external screw" to the left.

When door is crooked




Please take the following steps to adjust first.

1 Rotate the "font and rear screws to the left




※ After adjusting the "front and rear screw", the door still does not change, please turn the" internal & external screw" to the right Slightly.


2 Push the door to the cabinet




3 Rotate the "font and rear screws to the right




When door is leaning




1 Turn "intemal & external screw" to the left can make the top of the door tilted outward.





1 Turn "intemal & external screw" to the left can make the top of the door tilted outward.



When door is higher on top

1 Turn "up & down screw" to the left

2 Lower the door's height so that 2 doors are of thesame height.


3 Turn "up & down screw" to the right

※ if the door is lower on bottom, piease lift up the left door slightly on step 2

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied wich your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.

Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case.For light loads,general purpose wall plugs can be used.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 "Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 "Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving,wall cabinets and coat racks.

No.6 "Shield Anchor" wall plug - heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.

Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.