
48 INCH GAS FIRE PIT TABLE

Intertek
5024394



ITEM NO.: W5397P536039

Your order contains multiple boxes, these boxes may not be delivered on the same day. Please feel free to contact us on platform if you need any help. Thank you for your patience!

⚠ DANGER

FIRE OR EXPLOSION HAZARD

If you smell gas:

- **Shut off gas to the appliance.**
- **Extinguish any open flame.**
- **If odor continues, leave the area immediately.**
- **After leaving the area, call your gas supplier or fire department.**

Failure to follow these instructions could result in fire or explosion, which could cause property damage, personal injury, or death.

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to the owner's information manual provided with this appliance. For assistance or additional information consult a qualified installer, services agency or the gas supplier.

⚠ WARNING

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

An LP-cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.

⚠ WARNING

For outdoor use only.

Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

⚠ WARNING

If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury,or loss of life.

⚠ WARNING

Do not light or use gas unit if lava rocks are wet. Ensure lava rocks are completely dry before igniting as intense heat could cause the rock to crack. Keep away from the unit for the first 20 minutes after igniting your unit for the first time, since the lavarocks/pumice stones/LavaGlass@ maybe have trapped moisture, which will cause of lava rocks exploding, an lavarocks/pumice stones/LavaGlass@ could pop out and cause injury.
Should any rocks pop out discard them.

⚠ DANGER



CARBON MONOXIDE HAZARD

This appliance can produce carbon monoxide which has no odor.
Using it in an enclosed space can kill you.
Never use this appliance in an enclosed space such as a camper,tent,car or home.

INSTALLER:
Leave this manual with the appliance.
CONSUMER:
Retain this manual for future reference.

Before you assemble or operate this unit, please carefully read this entire manual. Failure to do so may result in a fire, explosion, injury or death.

⚠ WARNING

- The installation of this unit must adhere to local codes or Propane Storage and Handling Code, CSA B149.2.
- THIS UNIT IS INTENDED FOR OUTDOOR USE ONLY! This product shall be used outdoors, in a ventilated space and shall not be used in any enclosed area.
- This unit is to be used with propane gas only! (sold separately)
- Do not attach a remote gas supply to this unit.
- Only use propane gas for this unit.
- Solid fuels shall not be burned in this appliance.
- When igniting this unit, stay away from the burner as the flame will light up and may cause injury.
- LP GAS WARNING: Do not use any more than 1/4in depth lava rocks/pumice stones/LavaGlass® above the burner holes. Doing so will suffocate the flame.
- If the propane gas tank is leaking gas, you may hear, see, or smell a hiss. Do the following:

1. Disconnect the propane gas tank. 2. Do not attempt to fix the problem yourself. 3. Contact your gas supplier or fire department for help.

- Applying too much propane may result in gas pooling and will not burn. Allow fresh air into the unit so that the remaining gas may escape.
- Do not use a flame to check for gas leaks.
- Manifold pressure: 11 inch w.c. (2.74kPa).
- Use LP propane tanks with the following dimensions: diameter 12 in, height 18 in - capacity 20 lbs.
- You must use a propane tank that has a collar to protect the gas valve.
- DO NOT fill tank over 80 percent full.
- The tank system must be set up for vapor withdrawal.
- Discontinue use if any part of the propane tank is damaged. Rust and dents may be hazardous and should be inspected by a gas supplier.
- Do not burn anything other than the provided materials for this fire table.
- Keep away from the unit for the first 20 minutes after igniting your unit for the first time, as lava rocks/pumice stones/LavaGlass® could pop out and cause injury. Should any rocks pop out, discard them.
- Always ensure that lava rocks/pumice stones/LavaGlass® are completely dry before use. Failure to do so will cause them to crack or pop.
- Do not operate unit until all parts are fully assembled.
- Do not paint or color any part of this heating unit.
- Unit may be hot while in use, do not attempt to move it while in use.
- Never leave this heating unit unattended while in use.
- This unit is not intended for cooking.
- Keep any flammable items away and do not use any other fireplace cover for this unit.
- Keep a safe distance to avoid burning skin or clothing.
- Do not sit or rest hands or feet on this heating unit.
- Never place hands or fingers on upper portion of this unit while in use.
- Keep all electrical cords and fuel supply hose away from heated surfaces.

•Combustible material should not be within 60 inches of the top of the unit, or within 48 inches around the entire unit.
•Keep the appliance area clear and free from combustible material,gasnline and other flammble vapors and liquids.

• if the flame goes out while burning, turn the gas valve off. Wait 5 minutes before repeating the initial lighting procedure. Once you have a flame started, hold down the control knob for 1 minute.
• Do not add water into the unit.
• Do not operate unit if any part has been under water. Immediately call a quali ed service technician to inspect the appliance and replace any part of the control system and any gas control that has been under water. Do not disconnect any part while unit is in use.

• Do not store a spare propane tank on or near this unit.
• If the heating unit is indoors, detach the propane tank and leave outdoors.
• Do not operate on a boat or vehicle. Thins unit must be used on a flat surface and outdoors ONLY.
• Always remove protective cover before operating (if applicable).
• Do not set the protective cover over the unit until it is turned off and completely cooled down. Check for leaks after not using the unit for long periods of time.
• Children should never operate this unit. Children must be supervised while near this unit. Keep gas tank at least 5 feet away from unit when lit. (if external tank)
• Maximum gas supply: 250 psi; Min. gas supply: 10 psi.
• All installation and repair should be done by a quaalified professional.This unit should be inspected annually and cleaned regularly.
• Inspect all elements of this heating unit before each use. If there is damage, the burner must be replaced.
• Keep the hose out from any pathways to eliminate any accidental damage.(if external tank)
• Be aware of the hazards of high temperatures and stay away from the unit to avoid any burns or injury.
• The gas supply thak should be constructed and marked with the specificationgs for the LP gas tanks of the U.S. Department of Transportation or the National Standard of Canada CAN/CSA-B339, LP gas tanks, spheres and tubes for Transportation of Dangerous Goods; and Commission.
• The LP gas tank must have a listed overfilling prevention device and a QCCI or Type I, (CGA791) LP gas tank connection.
• This heating appliance should not be used on plastic or artificial wood decks.
• Children and adults should be alerted to the hazards of high surface temperatures and should stay away to avoid burns or clothing ignition.
• Young children should be carefully supervised when they are in the area of the appliance.
• Clothing or other flammable materials should not be hung from the appliance or placed on or near the appliance.
• Any guard or other protective device removed for servicing the appliance shall be replaced prior to operating the appliance.
• Installation and repair should be done by a qualified service person. The appliance should be inspected before use and at least annually by a qualified service person. More frequent cleaning circulating airways of the appliance are kept clean.

IF APPLICABLE:


• Allow heating item to cool completely before placing on lid.

• DO NOT use heating item while lid is installed. Always remove the lid while heating item is in use.

Only use the regulator and hose assembly provided with this unit. Replacement parts must be supplied directly by manufacturer.


Inspect the burner before use of this unit. If the burner shows any kind of damage, do not operate the appliance. For assistance with repair or replacement of the burner or any other parts, Please Contact manufacturer.

NOTE: You must follow all steps to properly assemble this heating item.
Make sure the gas valve is turned “OFF” before assembling. Do NOT attempt to assemble without proper tools.



Combustible materials should not be within 72 inches of the top of the unit, or within 48 inches around the entire unit.


Parts




Item	Description	Qty
A	Door frame	1
B	Side Panel	1
C	Side Panel	1
D	Side Panel	1
E	Door	1
F	Lid	1
G	Metal Stand	1
H	Table Top	1
I	(AAA)Battery	1
J	Protective Cover	1
K	Lava Rocks	2 boxes
L	Screwdriver	1
M	M6 Washer	12
N	M6 x 25 Screw	12
O	M6 x 16 Screw	4
P	Adjustable Foot Pad	4

⚠ Do not lock the screws until the assembly is complete.


1. Check that the control knob for the gas supply system is turned to the “OFF” position before starting any assembly.




2.Attach the adjustable foot pads(P) to the side panels (A,C).




3.Connect panel (A,B,C,D) with 8pcs screws (N) and 8pcs M6 washers(M).




4. Connect the Metal Stand (G) With side panel (B/D) by 4pcs Screws (N).




5.Attach the assembled base to the bottom of top using 4pcs of screws (O), and 4pcs M6 washers(M), make sure the panel (H) faces the valve stem.Tighten all screws.




6.Align door panel E with A and fit it into place.




Place propane gas tank (not included) into the metal stand (G). Make sure the gas tank sits on the metal stand (G) completely.



Turn the cylinder valve on the tank clockwise to close the propane tank. Attach the preassembled regulator from the table top to the cylinder valve by turning the regulator coupling nut clockwise. Make sure it is fastened securely and tighten connections by hand only.



Place the lid (F) on the fire pit.



CAUTION

To ensure proper function, the guard on this burner should be free of Lava rocks at all times.

Before performing a leak test, be sure that no sparks can occur and you are in a spacious outdoor area. Connect the propane gas tank to the regulator and turn the valve on the unit to the “off” position. Brush a soap and water mixture on all connections. Turn the gas supply on; if bubbles occur on any connection there may be a leak. **If you smell gas or a leak is discovered turn the gas valve off, disconnect propane gas tank and do not use the appliance until the leak is repaired.**

Do not use the heating unit without inspecting the gas hose. If there are signs of wear or abrasion you must replace the hose (if applicable). Pumice stones/lava rocks/LavaGlass® could pop up and strike somebody’s face during the process of lighting this unit; stand away from the unit for the first 20 minutes after igniting. Flame height should be a yellow/blue color between 2 - 10 inches in height.

Wait 50 minutes after extinguishing flame prior to placing a lid (if applicable) or protective cover on heating item.

To Light

1.Make sure the control knob is in the "OFF" position.
2.Press and hold the electronic igniter button.
3.Turn the burner control to the high position; press and hold in. When the burner lights , release the electronic igniter button.
4.Continue to depress the burner control knob for 30 seconds and then release.If the flame goes out, repeat the procedure.
5.Adjust the flame to the desired height with the burner control knob.
6.If the burner will not light with the electronicigniter , hold a lit long match or lit long butane lighter to the ignition area of the burner and continue with step 3.
7.To shut down the burner, turn the burner control knob clockwise to the off position. Then turn the gas off at the source (propane cylinder valve or natural gas supply valve).

⚠ WARNING

FOR YOUR SAFETY:
1.Keep your face and body away from burner area when lighting.Ensure burner controls are in the off position. Slowly turn on the gas supply valve.
2.The propane cylinder is equipped with an excess flow device.Unless burners are turned off prior to turning the cylinder on,only small flames and low heat will be achievable.
3.If the burner does not light within10 seconds , turn the valve off and wait for5 minutes for any gas to dissipate before repeating the procedure.

To Extinguish
1.Turn control knob clockwise to the "HIGH " position; push and continue turning the control knob to the "OFF" position.
2.Close the cylinder valve on the propane gas tank if you don't intend to use it for a long time.
Before performing any maintenance always disconnect propane gas tank.

- **Store your product indoors during winter months. Avoiding extreme cold temperatures will prevent from exposure damage.**
- Keep the heating item free and clear from combustible materials.
- Visually inspect burner for obstructions and keep tank enclosure free and clear from debris.
- Use a soft brush to get rid of the mild stains, loose dirt and soil after the burner and pumice stones/ lava rocks/LavaGlass® are completely cooled down. Wipe down with a soft cloth.
- Harsh weather conditions may cause stubborn stains, discoloration and possibly rust pitting.
- Permanent damage may occur if powder or solvent comes in contact with painted or plastic components on this heating unit.
- Keep the heating unit stored away from direct sunlight.
- If storing this unit inside, disconnect the propane gas tank from the gas valve.
- Not using manufacturer approved or supplied parts/accessories may result in a defective condition
- Always place lid (if applicable) or protective cover on heating item when not in use.

TROUBLESHOOTING

Problem	Cause	Solution
Low heat / Low flame when valve turned to high.	incorrect lighting operation.	Ensure the lighting procedure is followed carefully. The valve must be in the off position when the tank valve is turned on. Turn the tank on slowly to allow the pressure to equalize. See lighting instructions.
Burners burn with yellow flame, accompanied by the amell of gas.	Possible cobwebs or other debris.	Thoroughly clean the burner venturi See general maintenance instructions.
Burners will not light with the igniter, but will light with a match.	Loose electrode wire or switch terminalwires.	Check whether the electrode wire is firmly pushed onto the terminal on the back of the igniter. Check that the lead wires from the module to the ignition switch (if equipped) are firmily pushed onto their respective terminals.
Burners will not stay lit when the control knob is released.	Knob not being held in long enough. Too windy. Lava glass or debris in ignition area of the bumner preventing thermocouple from being fully engulfed in flame. Dirty thermocouple or thermocouple connection.	Thermocouple must have time to heat up - hold the knob in for 30 seconds after the bumer lights, then release. if the wind speed ils greater than 10 mph (16 kmyh), the unit will shut down automatically,Either place it in a different area or use it when the wind is low. Ensure that there are no lava glasses or other debris in the ignition area, and that the small hole beloww the thermocouple is unobstructed. Clean the thermocouple and clean the connection between the valve and thermocouple.Ensure the connection is properiy tightened Replace thermocouple and /or walve.
Humming regulator.	Normal occurrence on hot days.	This is not a defect. it is caused by interal vibrations in the regulator and does not affect the performance or safety of the appliance. Humming regulators will not be replaced.
Burner output on "high" setting is too low. (Rumbling noise and fluttering blue flame at burner surface.)	Lack of gas. Supply hose is pinched,Dirty or clogged orifice. Cobwebs or other substances in the venturi tube. Propane regulator in "low flow" state.	Check gas level in the propane cylinder. Reposition the supply hose to Clean the burner orifice. Clean out the venturi tube. Ensure the lighting procedure is followed carefully. All valves must be in the off position when the tank valwe is turned on. Turn the tank on slowly to allow pressure to equalize, See lighting instructions.

Thank you for purchasing this product! If you have any questions about the product, such as missing parts, damaged products, product assembling, and operation, please contact us via online platform, thank you very much!