01 STEP

Take Out the Solar Panels





02 STEP

Rotating Solar Panel