
Children's Wooden Playhouse

Assembly Instruction - Please keep properly for future reference.

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.



CONTACT US

3.8X5 FT

- **Email: service@grandtunnel.com**
  In order to receive assistance more quickly, please provide

THE FOLLOWING INFORMATION:

- Order number
- Purchase platform
- Purchase date
- Detailed description of the issue along with photos (if applicable)

Important – Please read these instructions carefully before starting the installation.

EN

CUSTOMER SERVICE GUIDE

Thank you for choosing our product! We are committed to providing you with excellent service. If you find any missing parts, damaged packaging, or product damage after receiving all packages, please follow the steps below to quickly contact our customer service team. We will do our best to resolve your issue.

1. Missing Parts

Verify Parts:

1. Refer to the **"Parts List"** in the manual to verify the name, specifications, and quantity of the missing parts.
2. Take a clear photo of the parts list and mark the missing parts with detailed information, e.g., "Missing 5 pieces of M6X30mm screws."

Contact Us:

· **By Email:**

Send an email to **service@grandtunnel.com**, with the subject line "Missing Parts Issue." Include the following in the email:

· A description of the missing parts and a photo of the parts list.
· Order details (order number, purchase platform, purchase date).

2. Product or Packaging Damage

If it affects normal use:

Steps:

1. Take clear photos or videos showing the damaged parts and the extent of the damage (multiangle shots are recommended).
2. Email the photos/videos along with order details to **service@grandtunnel.com**, with the subject line "Product Damage Issue."

Resolution:

After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

If it does not affect normal use:

Steps:

1. Contact our customer service team (by email: **service@grandtunnel.com**).
2. Provide a description of the damage and include relevant photos or videos.

Resolution:

We will provide repair guidance or an appropriate compensation plan based on the specific situation.

Contact Us:

· Customer Service Email: **service@grandtunnel.com**






















Helpful Tips

To process your issue efficiently, please prepare the following information:







· Order details (order number, purchase platform, purchase date).
· Clear photos or videos.
· We are committed to providing quick and professional solutions, no matter the size of the issue, to ensure your satisfaction.







Thank you for your trust and support! We hope you enjoy using our product!







Parts List








1  1080X507MM	2  1080X507MM	3  1080X522MM	4  1080X522MM	5  1080X522MM	7  1080X507MM
X1	X1	X1	X1	X1	X1
8  1080X507MM	10  490X196MM	11  491X410MM	12  445X410MM	13  975X150MM	14  437X150MM
X1	X1	X1	X1	X1	X1
15  660X270MM	16  324X240MM	17  943X45MM	18  696X45MM	19  696X45MM	20  352X70MM
X1	X2	X2	X2	X2	X2
21  253X70MM	22  230X140MM	23  140X34MM	24  485X270MM	25  200X70MM	26  400X18MM
X4	X2	X4	X1	X2	X5

Parts List








27	28	29	30	31	32
					
286X18MM	595X34MM	361X288MM	259X34MM	980X80MM	150X34MM
X1	X1	X2	X1	X2	X2



33	34	35	36	37	38
					
400X34MM	280X90MM	300X34MM	300X34MM	660X426MM	1080X348MM
X2	X2	X2	X4	X1	X1


39	40	41	42	43	44	45
						
1080X410MM	1080X360MM	1080X410MM	1045X34MM	1045X34MM	352X34MM	352X34MM
X1	X1	X1	X1	X1	X2	X1

46	47	48	49	50	51	52
						
150X34MM	230X135MM	595X34MM	261X34MM	261X34MM	1080X522MM	490X196MM
X1	X1	X1	X2	X1	X1	X1

Parts List


A  3.5*60	B  3.5*50	C  3.5*45	D  3.5*40	E  3.5*35	F  3.5*30
X33+2	X5+1	X22+2	X20+2	X63+2	X20+2
G  3*22	H  3*18	I  3*12	J  3*15	K  6*30	L  Ø6*20
X4+1	X68+2	X4+1	X4+1	X10+1	X12+1
M 	N 	O 	P 	Q 	R 
X8	X2	X1	X1	X1	X1
S 	T 	U 			
X1	X1	X3			


1	 3 X1	 4 X1				



Connect parts (4) and (3) using wooden dowels (L).


LX2  Ø6*20	


2	 26 X1					



a. Reinforce part (3) with part (4) using screws (A).
b. Fix part (26) to parts (4) and (3) using screws (E).



AX2	EX4
 3.5*60	 3.5*35


3	 17 X1					



Connect part (17) to parts (4) and (3) using wooden dowels (L), then secure with screws (A).

AX4	LX2
 3.5*60	 Ø6*20

4	 18 X1	 19 X1	 20 X1	 21 X2		






Assemble parts (18), (19), (20), and (21) with part (17), then secure with screws (A).

AX3




3.5*60


5	 7 X1	 8 X1				



Connect parts (7) and (8) using wooden dowels (L).

LX2  Ø6*20


6	 26 X2					



a. Reinforce part (7) with part (8) using screws (A).
b. Fix part (26) to parts (7) and (8) using screws (E).

AX2	EX8
 3.5*60	 3.5*35


7	22 X1					




a. Fix part (7) to part (3) using screws (C).
b. Fix part (22) to part (20) using screws (I) (as shown).


CX4	IX2
3.5*45	3*12


8						





a. Fix accessory (U) to part (7) using screws (H) (spacing approx. 130 mm).
b. Hang accessory (Q) onto accessory (U).

HX6	QX1	UX3
 3*18		


9	 15 X1					




Fix accessory (P) to part (15) using screws (E).

EX2  3.5*35	PX1 

10	 16 X2					






Fix part (15) to part (16) using screws (E) (align as shown).


EX4





3.5*35



11						






a. Place accessory (T) onto part (15).
b. Fix part (15) to parts (7) and (8) using screws (E).
c. Reinforce part (16) from parts (8) and (7) using screws (E).

EX7	TX1
 3.5*35	

12	 1 X1	 2 X1				





Connect parts (2) and (1) using wooden dowels (L).

LX2




Ø6*20


13	 26 X1					



a. Reinforce part (1) with part (2) using screws (A).
b. Fix part (26) to parts (2) and (1) using screws (E).

AX3  3.5*60	EX4  3.5*35

14	 23 X2		





Fix part (23) to part (1) using screws (E).

EX2



3.5*35

15	 14 X1		






Fix part (14) to parts (1) and (23) using screws (E).


Note: Leave 5 mm on each side as shown.


EX6


3.5*35


16	 10 X1	 52 X1	













Fix accessory (M) to parts (10) and (52) using screws (H).

Note: Insert accessory (M) into the slot as shown.

HX12  3*18	MX4 

17			



Fix part (10) to part (1) using screws (H).


Note: Align accessory (M) with the pilot holes.

HX6



3*18

18			



Fix part (52) to part (1) using screws (H).


Note: Align accessory (M) with the pilot holes.

HX6





3*18


19			



a. Fix part (1) to part (4) using screws (C).
b. Fix accessory (S) to part (4) using screws (J).


CX4	JX4	SX1
3.5*45	3*15	

20	 11 X1	 12 X1				




Fix accessory (M) to parts (11) and (12) using screws (H).

Note: Insert into slot as shown.

HX12  3*18	MX4 


21						




Fix parts (11) and (12) to part (2) using screws (H).


Note: Align with pilot holes.

HX12




3*18

22	 25 X2	 27 X1	





a. Fix part (25) to the inner side of part (1) using screws (E).
Note: Align with magnetic catches on parts (10) and (52).
b. Fix part (27) to parts (2) and (1) using screws (E).
c. Fix part (25) to the inner side of part (2) using screws (E).
Note: Align with magnetic catches on parts (11) and (12).

EX8





3.5*35


23	 5 X1	 51 X1		



Connect parts (51) and (5) using wooden dowels (L).



LX2  Ø6*20


24	 17 X1	 26 X1	




a. Fix part (26) to parts (51) and (5) using screws (E).
b. Connect part (17) to parts (51) and (5) using wooden dowels (L), then secure with screws (A).

AX4	EX4	LX2
 3.5*60	 3.5*35	 Ø6*20

25	 18 X1	 19 X1	 20 X1	 21 X2	






Assemble parts (18), (19), (20), and (21) with part (17), then secure with screws (A).

AX3




3.5*60

26					







Fix part (2) to part (5) using screws (C),
and fix part (8) to part (51) using screws (C).

CX8




3.5*45

27	 22 X1	 23 X2	 24 X1		




a. Fix part (22) to part (20) using screws (I) (as shown).
b. Fix part (23) to parts (5) and (51) using screws (E).
c. Fix part (24) to part (8) using screws (H).


Note: Leave 85 mm at the top and 11 mm at the side.

EX2  3.5*35	HX4  3*18	IX2  3*12

28



13 X1



Fix part (13) to parts (5) and (51) using screws (E).


Note: Leave 5 mm on each side as shown.

EX8



3.5*35

29	42 X1	43 X1	44 X2	45 X1		





Assemble parts (42), (43), (44), and (45),
then secure with screws (A) (as shown).

AX6



3.5*60

30	 36 X2					




a. Fix part (43) to parts (5) and (51) using screws (B).

Note: Leave 12 mm at the top.

b. Fix part (36) to parts (5), (51), and (44) using screws (D).

BX4	DX4
 3.5*50	 3.5*40



31




Stick accessory (R) in place (as shown).

RX1




32	 38 X1	 40 X1	






Fix parts (38) and (40) using screws (F) (align as shown).

FX4







3.5*30


33	 39 X1	 41 X1	




Connect part (39) with part (38), and part (41) with part (40) using screws (G), then secure with screws (F).

FX12	GX4
 3.5*30	 3*22

34						
						
	28 X1	29 X2	48 X1	49 X2	50 X1	





a. Assemble parts (28), (48), (49), and (50), then secure with screws (A).


Note: The hole edge of part (49) should face outward.

b. Fix parts (29) and (49) using screws (D).

Note: Keep the right angle aligned.

AX6	DX4
 3.5*60	 3.5*40

35




Fix part (29) to parts (40) and (41) using screws (C).

CX4




3.5*45

36



37 X1





Fix part (37) using screws (F).


FX4





3.5*30

37	 32 X2	 33 X2	 34 X2	 35 X2	













a. Fix parts (32), (34), (35), and (33) using bolts (K).
b. Reinforce part (33) with part (35) using screws (C).
c. Fix part (33) and accessory (N) using screws (H).


CX2	HX4	KX10	NX2
 3.5*45	 3*18	 6*30	


38	 30 X1	 31 X2	 46 X1		



a. Fix part (46) to part (30) using screws (B).
b. Fix part (31) to part (32) using screws (D),
then fix part (31) to part (46) using screws (E) (align with holes).


BX1	DX8	EX4
 3.5*50	 3.5*40	 3.5*35

39	 36 X2				




Fix part (36) to parts (31) and (34) using screws (D).

DX4




3.5*40

40



Fix parts (33), (5), and (51) using screws (H).

HX4




3*18

41



47 X1



Hang part (47) onto accessory (O), then secure using screws (H).

HX2	OX1
 3*18	

Children's Wooden Playhouse

SKU:
C000939020

V2.0