

INSTALLATION
Product Manual

Version: 460154US-01-26A-FR




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.




For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.


Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.













When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 92+5	B x 92+5	C x 40	D x 232+5	E x 1
				
∅6 x 35 mm	∅15 x 11 mm	∅8 x 30 mm	∅3 x 12 mm	

F x 1	G x 20	H x 40+4	J x 8	K x 8
				
				∅4 x 20 mm

L x 8	M x 8	N x 2	P x 8	Q x 16+1
				
∅6 x 25 mm	∅6 x 20 mm	N-1 N-2 N-3 N-4		∅3 x 14 mm

R x 8	S x 2	T x 92+5	U x 12	V x 32+3
				



⚠WARNING






Children have died from furniture tipover.To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


This is a permanent label.
Do not remove!




ASSEMBLED BY 2 ADULTS


1


A x 16



∅6 x 35 mm








Screw eccentric bolt (A) onto Panel 14.


2

B x 16



∅15 x 11 mm







Connect Panel 14 to Panel 15, then tighten by turning eccentric wheel (B) clockwise.


3

A x 20	C x 8	
∅6 x 35 mm	∅8 x 30 mm	





Screw eccentric bolt (A) and insert dowel pin (C) to Panels 3 and 6.





4

B x 20




∅15 x 11 mm









Connect Panels 14 and 15 to Panels 3 and 6, then tighten by turning eccentric wheel (B) clockwise.




5

A x 8	C x 8	
		
∅6 x 35 mm	∅8 x 30 mm	






Screw eccentric bolt (A) and insert dowel pin (C) to Panels 3 and 6.





6

A x 4





∅6 x 35 mm





Screw eccentric bolt (A) onto Panels 11 and 12.







7

B x 4




∅15 x 11 mm






Connect Panels 11 and 12 to Panel 16, then tighten by turning eccentric wheel (B) clockwise.





8

A x 4





∅6 x 35 mm





Screw eccentric bolt (A) onto Panels 11 and 13.







9

B x 4




∅15 x 11 mm





Connect Panels 11 and 13 to Panel 16, then tighten by turning eccentric wheel (B) clockwise.





10


B x 8




∅15 x 11 mm











Connect Panels 11 and 12 to Panel 3, and Panels 13 and 11 to Panel 6, then tighten by turning eccentric wheel (B) clockwise.



11





Insert Panels 22 and 24 along the available slots.




12

A x 12	C x 4	
		
∅6 x 35 mm	∅8 x 30 mm	





Screw eccentric bolt (A) and insert dowel pin (C) to Panels 2, 7 and 8.





13


B x 8




∅15 x 11 mm










Connect Panels 7 and 8 to Panel 16, then tighten by turning eccentric wheel (B) clockwise.


14

B x 4




∅15 x 11 mm






Connect Panels 7 and 8 to Panel 2, then tighten by turning eccentric wheel (B) clockwise.






15


Insert Panel 21 along the available slots.




16


A x 12	C x 4	
		
∅6 x 35 mm	∅8 x 30 mm	





Screw eccentric bolt (A) and insert dowel pin (C) to Panels 5, 7 and 10.







17

B x 8



∅15 x 11 mm






Connect Panels 7 and 10 to Panel 16, then tighten by turning eccentric wheel (B) clockwise.


18

B x 4




∅15 x 11 mm







Connect Panels 7 and 10 to Panel 5, then tighten by turning eccentric wheel (B) clockwise.



19






Insert Panel 23 along the available slots.




20

D x 4	L x 4	N x 1	S x 1	
∅3 x 12 mm	∅6 x 25 mm	N-1 N-2		


Secure Panels 26 and 28 to Panel 1 using screw (L).
Secure part (M) to Panels 26 and 28 using screw (D).
Note: Align Panels 26 and 28 before tightening the screws in this step.
Secure part (N-1) to Panel 1 using screw (N-2).






21


D x 4	L x 4	N x 1	S x 1	
 ∅3 x 12 mm	 ∅6 x 25 mm	 N-1 N-2		

Secure Panels 27 and 29 to Panel 4 using screw (L).
Secure part (M) to Panels 27 and 29 using screw (D).
Note: Align Panels 27 and 29 before tightening the screws in this step.
Secure part (N-1) to Panel 4 using screw (N-2).




22


A x 8	Q x 8	R x 4	
 ∅6 x 35 mm	 ∅3 x 14 mm		




Screw eccentric bolt (A) onto Panels 1 and 4.
Secure part (R) to Panels 1 and 4 using screw (Q).

23




B x 4	C x 4	
		
∅15 x 11 mm	∅8 x 30 mm	




Connect Panels 7 and 8 to Panel 1 using dowel pin (C), then tighten by turning eccentric wheel (B) clockwise.




24


A x 4	Q x 4	R x 2	
			
∅6 x 35 mm	∅3 x 14 mm		




Screw eccentric bolt (A) onto Panel 2.
Secure part (R) to Panel 2 using screw (Q).




25



B x 4	C x 4	
		
∅15 x 11 mm	∅8 x 30 mm	




Connect Panels 7 and 10 to Panel 4 using dowel pin (C), then tighten by turning eccentric wheel (B) clockwise.




26


A x 4	Q x 4	R x 2	
			
∅6 x 35 mm	∅3 x 14 mm		




Screw eccentric bolt (A) onto Panel 5.
Secure part (R) to Panel 5 using screw (Q).




27


B x 4	C x 4	
		
∅15 x 11 mm	∅8 x 30 mm	




Connect Panels 11 and 12 to Panel 2 using dowel pin (C), then tighten by turning eccentric wheel (B) clockwise.



28


B x 4	C x 4	
		
∅15 x 11 mm	∅8 x 30 mm	




Connect Panels 11 and 13 to Panel 5 using dowel pin (C), then tighten by turning eccentric wheel (B) clockwise.

29


M x 8



∅6 x 20 mm





Secure Panels 10 and 13 to Panels 8 and 12 using screw (M).



30

Assembly complete. Peel off the protective film from the glass.






31

V x 32




Install part (V) onto Panels 7, 8, 10, 11, 12 and 13.




32

Place Panel 25 on top of part (V).



33

F x 1




Option A

Feed the LED strip light (F) through the reserved wiring holes on back Panels 21 and 22 into the cabinet, then complete the plug-in connection.

34



F x 1





Option B

Feed the LED strip light (F) through the reserved wiring holes on back Panels 23 and 24 into the cabinet, then complete the plug-in connection.

35


D x 24	U x 12	F x 1	
			
∅3 x 12 mm	∅3 x 14 mm		








Peel off the adhesive backing film from LED strip (F), stick it onto Panels 1, 2, 4 and 5, then secure it with screw (D) and clip (U).


OR








36

D x 44	E x 1	H x 40	
 ∅3 x 12 mm			













Insert clip (H) into the back panel slots and secure them using screw (D).
Secure part (E) to Panels 28 and 29 using screw (D).

37

D x 56	G x 12	P x 4	
 ∅3 x 12 mm			








Secure hinge (G) and iron plate (P) to Panels 17 and 18 using screw (D).



38

D x 40	G x 8	P x 4	
∅3 x 12 mm			


Secure hinge (G) and iron plate (P) to Panels 19 and 20 using screw (D).



39

D x 30	J x 4	K x 4	
			
∅3 x 12 mm		∅4 x 20 mm	


Secure Panels 18 and 20 to Panels 7, 8, 11 and 12 respectively via the hinges using screw (D).
Secure knob (J) using screw (K).



40

D x 30	J x 4	K x 4	
∅3 x 12 mm		∅4 x 20 mm	

Secure Panels 17 and 19 to Panels 7, 10, 11 and 13 respectively via the hinges using screw (D).
Secure knob (J) using screw (K).





41

N x 2


N-3

N-4







1.




2.



3.




4.





Install the anti-tip device as shown.

42

T x 92







Apply masking tape (T) to the eccentric wheel holes.

WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

- The product must be used in accordance with the instructions provided. For health reasons.

- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.

- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.

- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
  In all circumstances please save all packaging material and paperwork for the order.
  Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.

AFTER-SALES CONTACT



