
ANPABO

RIDE ON UTV

OWNER'S MANUAL



NOTE: Manual illustrations are for demonstration purposes only. Illustrations may not be the same with the exact appearance of the actual product. Please keep the 17-character order ID with your side before contacting us for assistance or replacement parts.

Order ID: _____ - _____ - _____

Read and understand this entire manual before allowing children to use this product.

For assistance, please send Email to: anpabo.service@gmail.com, (24/7)

Table of Contents

1. Specification - 01
2. Kind Reminder - 02
3. Parts Diagram - 03
4. Parts Name - 04
5. Installation Steps - 05-14
6. Remote Control - 15
7. Fault and Solutions - 16
9. Safety Warning - 17
10. Reminder and Maintenance - 18

• Please read this manual carefully before installation to avoid misoperation or damage.

• Keep the child safe.

• Users should keep the instructions properly.


Specification

Storage battery	24V 7Ah
Electric motor	Drive motors 24v 75w*4 steering motor: 24v 8w*1 rear bucket motor 24v*30w*1
Suitable age	37-95 months
Max weight	110 lbs
Size	55.9*31.7*30.3 inches
Speed	3.7-5.0 mph
Utility	8-12 hours(charger) 60-80 minutes(use)
Charger	AC 100-240V 50Hz(input) DC 24V(output)
Battery of remote control	2 pieces of AAA1.5V (Not included)

⚠ Kind reminder


- Product should be adult assembly！ Please be careful with screw split pin and other dangerous sharp tip!
- In order to avoid small parts caused by injury and accidental ingestion may cause choking hazard， please send small parts away from children under 3 years old!
- The children can not drive alone without adults,and caregivers in use process shall not be allowed to leave!
- Please recharge before using this product and charging the storage battery by the adults!
- To avoid harming children， please keep the packaging materials such as plastic bags away from them!
- Please check the product regularly to make sure that the electric wire, plugs, outer case and other parts are normal. If something is damaged, please stop using the car until it is fixed!
- Two AAA dry cells are for the remote control!
- Use all the cells or batteries in right way!
- Please don’t insert the output socket If the line with no connection!
- The packaging and instructions must be retained since it contains important information!

Parts Diagram




Parts Names

Number	Name	Quantity(PCS)	Remarks
1	Car body	1	
2	Seat back	1	
3	Seat bottom plate	1	
4	Seat headrest	1	
5	Steering wheel	1	
6	Dump bed hook	1	
7	Driving motor	4	
8	Left & right plastic bracket	2	
9	Wheel	4	
10	Wheel cover	4	
11	Front windshield	1	
12	Top bracket	2	
13	Dump bed	1	
14	Dump bed rear door	1	
15	Shovel	1	
16	Dump bed plastic part	1	
17	License plate	1	
18	Rear axle	1	
19	Charger	1	
20	Remote control	1	
21	Manual	1	
hardware	4X12mm self-tapping screw	51	Spare parts：4 pcs
	4X12mm black self-tapping screw	8	
	M10 lock nut	4	
	M5 lock nut	4	
	M12 washer	4	
	5X55mm screw	1	
	5X35mm screw	2	
	5X12mm screw	1	
	Wrench	3	Plastic wrench:2pcs Iron wrench:1pc




1.Adjust the position of steering bracket

Adjust the steering bracket from Figure A to Figure B,then use a screwdriver and the iron wrench to fix the steering bracket with a 5x12mm screw and M5 lock nut.Please don't over tighten the screw.




2.Install the front wheels

a.Put the "L"drive motor to the left side of the front axle and the "R"drive motor to the right side.Connect the motor wires with power wires protruding from the car body.
b.Install the left and right wheels to the front axle,add the M12 washer and M10 lock nut,then fix them with the plastic wrench.Finally,aim the wheel cover at the holes in the wheel and clamp it.



3.Install the Left and right plastic bracket


First insert the left and right plastic bracket into the bottom of the car body separately, and then fix it with eight 4*12mm self-tapping screws.



4.Install the rear axle


Insert the rear axle into the car body in the direction of the arrow,and make the length of the left and right sides of the rear axle symmetrical.

Installation Steps:



5.Install the rear wheels


a.Put the “L”drive motor to the left side of the rear axle and the “R”drive motor to the right side.Connect the motor wires with power wires protruding from the car body.
b.Install the left and right wheels to the rear axle,add the M12 washer and M10 lock nut, then fix them with the plastic wrench.Finally,aim the wheel cover at the holes in the wheel and clamp it.



6.Install the joystick and steering wheel


- **Install the joystick:**
  a. Hold the joystick and insert it into the switch seat on the dashboard.
  b. Fix it with two black 4*12mm self-tapping screws.
- **Install steering wheel:**
  a. Connect the wire of the steering wheel to the power wire protruding from the steering wheel base.
  b. Push the steering lever to make the lever inserted into the center hole of the steering wheel. Then insert a 5*55mm screw through the hole on the steering column base and fix it with a M5 lock nut.

Note: Please make sure all holes are aligned, otherwise, the screw will not be inserted successfully.




7.Install the front windshield

Install the front windshield into the hole of the car body, and then fix it with four black 4*12mm self-tapping screws.




8.Install the seat headrest and fix the seat back

a. Install the seat back to the car body and fix it with five 4*12mm self-tapping screws.
b. Insert the seat headrest into the frame on both sides of the car body as shown in the figure, then fix the seat headrest to the seat back with four 4*12mm self-tapping screws.




9.Connect the power wires and install the seat bottom plate

a.Connect the power wires: Connect the power wire on the battery to the power wire on the receiver.
b.Install the seat bottom plate: First slide the seat bottom plate into the hole under the seat back, then fix it with two 4*12mm self-tapping screws.




10.Install the dump bed assembly ①

a.First insert the dump bed plastic part into the front of the dump bed in the direction of the arrow,and fix it with two black 4*12mm self-tapping screws.
b.Then insert both sides of the rear door into the holes on both sides of the dump bed.
c.Finally insert the shovel into the dump bed groove.



11.Install the dump bed assembly ②

Turn the dump bed over. Fix the license plate and dump bed hook to the bottom of the dump bed with four 4*12mm self-tapping screws separately.




12.Install the rear dump bed

There are four fixed positions on the rear dump bed.


a. Align the 4 fixed positions on the rear dump bed with the car body respectively (please look at the numbers ①-④ marked in the picture and align the places with the same numbers one by one).

b. Fix those parts with fourteen 4*12mm self-tapping screws in turn. (Referring to Picture).




13.Install the top bracket

a.First insert the top brackets into the holes on both sides of the seat,and align the center holes.
b.Then insert 5*35mm screws through the holes and fix with M5 lock nuts.
c. The method to open the car door: Press the button as shown in Figure B and pull the bracket upward.
If the door cannot be opened, while press the button as shown in Figure B, press the position shown in Figure A with the other hand, and then pull the bracket upward.



14. Dashboard indication

A.Power key switch
Insert the key into the keyhole,turn right to power up the car with the engine sound.
B.Forward/Backward switch
In manual steering mode.children can press the Forward/Back switch to go forward,reverse or stop.
C.Speed switch
Press the green switch to choose speed mode. “I” for low speed. “II” for high speed.
D.Light switch
Press the red switch to turn on/off the front lights.
E.Music and horn button
There are two buttons on both sides of the steering wheel.
Press the music button (on the right side of the steering wheel) to play built-in music,
and press the horn button (on the left side) to play the horn sound.
F.Joystick
Push the joystick to control the dump bed.
G.Foot pedal
Step the foot pedal can control the car to move forward, backward or stop.
H.Music panel
Music panel is on the right side of the steering wheel.You can either press the music button on the steering wheel or on the music panel to play built-in music.
Two volume buttons are for volume adjustment.
To play music or story from external source,you can press the B button for mobile connection or use port for USB connection.
If you want to switch from Bluetooth mode back to playing built-in music, just press the B button on the music panel again.
I.Joystick unlocking switch (Located directly under the seat)
1. Pull out the unlock switch.
2. Pull the joystick backward until the rear bucket is raised and then release the unlock switch.
Note: After the Joystick drops to the bottom, it will lock the rear bucket. You must repeat step 1 and 2 to control it again!
J: Towing mode switch
Press this switch to enable or disable towing mode. Note: In towing mode, the car won't move.
Turn the towing switch from "O" to "I" gear to achieve drive mode.




15.Towing switch operation method

Towing mode: Make the towing switch is placed in “O” gear, the vehicle cannot move. (the vehicle is protected, not faulty)
Driving mode: Make the towing switch is placed in “I” gear.
Note : Make the towing switch is placed in “I” gear when pair the remote, otherwise the code cannot be paired !

16.Charging indication

a.When the power indicator on the music player lights up two or fewer red light, it indicates the battery is running down. And you will hear a voice prompt. Please stop using the car and recharge the battery in time to avoid irreversible damage to the battery.
b. Charging method: Insert the output end of the charger into the charging port on the car body, and the charger into the power socket.
Note: While charging, the car is in charge protection mode and has no function. Only when the charger is pulled out from the charging port, the car will return to the normal!

2.4G Remote control instructions



The remote needs to be paired with the vehicle before the first use. Due to the memory function, there is no need to pair the vehicle again next time you use the remote.

How to pair the remote with the vehicle?

Step 1: Open the battery cover of the remote control and put 2 pcs AAA(1.5V) batteries into it. (Note: batteries are not included in the package.)

Step 2: Turn on the power switch on the car;

Step 3: Press and hold the "code" button for more than 15 seconds, or press and hold the Forward and Back buttons at the same time for more than 15 seconds, the speed display light will flash and then turned to a long bright red light, which means the remote control and the car have been paired successfully.

Speed button: a red light for low speed, two red lights for medium speed, three red lights for high speed

Brake button: Press the brake button (P button) to stop the car,the three red speed display lights on the remote will all flash. Press the brake button once again to release the brake.

Note:

1. When being not operated for more than 10 seconds, the remote will turn to automatic standby state. Press any key to wake it up.
2. When the remote control is paired and in operation, the remote will override the manual mode, and the pedal switch of the car will be invalid. If the remote is paired but not in operation, the pedal switch can be used normally.
3. The remote control shall be used by caregivers and not be touched by children.

Fault and Solutions:

Type of fault	Analysis of causes	Solutions
Can not move	1. Voltage is below normal level	Charge the battery
	2. Safety wire protects	Wait for a while for the fuse to reset
	3. The screws on the wheels have fell off	Tighten the screws again
	4. Loose battery wire connections	Reconnect the wires
	5. Battery is damaged	Change the battery
	6. Electrical equipment is damaged	Contact the seller or ANPABO Customer Service
	7. The motor is damaged	Contact the seller or ANPABO Customer Service
	8. The towing switch is placed in "o" gear.	Turn the towing switch to the "I" gear.
The battery cannot be charged	1. Loose battery wire connections	Reconnect the wires
	2.Charger is broken	If the indicator light of the charger keeps showing red and never turns green, please contact customer service to get a new charger.
	3. The battery charger is damaged	Replace the battery charger
	4.The charging port is broken	When the charger is plugged into the wall plug or socket, but the green light of the charger is always on (the battery is run out of power at this time), please contact customer service to get a new charging port.
Short run time	1.Battery is not full	Charge the battery again
	2.Battery is old and will not accept full charge	Replace the battery
Charger is warm when charging the battery	1.Chemical reaction	Normal. No action is needed.

Low speed	1. Battery is old	Change the battery
	2. Battery is out of power	Charge the battery again
	3. Overweight	Lighten the weight to less than 66 lbs
	4. Driving conditions are too stressful	Use only on generally level ground
Gear case with noise	1. Gear is broken	Contact the seller or ANPABO Customer Service
The car shakes when it goes forward	1. Bad connection of the motor connector wires	Please reconnect all connector wires
	2. Something wrong with the motor	Contact the seller or ANPABO Customer Service
Drive without music	1. Electrical equipment is damaged	Contact the seller or ANPABO Customer Service
For assistance, please send an Email to: anpabo.service@gmail.com.		

Safety Warning :

- Do not drive the car on the slipped street, road, slop and other dangerous places.
- Do not drive the car on the smooth surface, such as marble and floor tile.
- The maximum load is 110lbs. Do not overload the vehicle.
- Do not adapt the wiring or other electronic devices.
- Keep the remote and vehicle away from the rain and fire.
- The vehicle may stop moving when the car confronting big obstacles. Remove the obstacles and the car will move again.
- Do not drive the car in the water. Do not put the water or other liquid into the storage batteries of the car.
- Do not drive the car in narrow spaces to avoid collision.

Kind reminder for charging:

- Make sure the battery has been charged over 8 to 12 hours or the charger indicator turns green before the first use, otherwise the battery will be damaged forever.
- Connect the charger connector to the battery connector, then insert the charger on the plug.
- After using 1 hour,you should charge in time. It takes 8 to 12 hours to charge normally.
- Do not charge over 20 hours one time.
- It is normal to have some heat for charger and battery when it is charging.(low than 60°C)
- In order to protect charger,battery and circuit,please use the special charger and battery from factory.
- Connecting terminal can not be a short circuit.
- Do not mix to use old and new batteries or different types of batteries.
- Make the battery charge once a month at least when the car is not driven for long time.
- Charge the battery by the adult.

Chargers and battery maintenance:

- Unscrew the screw on the battery cover, remove the battery cover, take out and put the battery, finally fix the battery cover with the screw.
- The charger and battery should be stored in waterproof and moisture-proof environment.
- Before charging, check whether the external surface of the charger is damaged, whether the plug is corroded, and whether the wire is cracked. The charger cannot be used if it is damaged.
- Check the battery regularly. Stop use it if there is leakage.
- Charge only under adult supervision.
- Batteries should be connected with correct polarity. (Red to red, black to black)
- Avoid short circuit.

Maintenance:

- Before the installation, make sure the parts are complete. If you have any question,please feel free to contact us.
- Make sure every part is complete when installing and using.
- Please clean the car regularly.Do not damage the electrical equipment.
- Please check and maintain the car for the children's safety.

Criteria of product operation :

EN71 EN62115 ASTM F963 CPSIA