



Olla De Cocimiento Lento de 2.0 cuartos

Model: ZES012



Manual de Instrucciones

LEA TODAS LAS INSTRUCCIONES ANOTES
DE USAR ESTE APARAT

**DISCOVER
more of our
products!**



Roaster Oven



2-Pot Slow Cooker



3-Pot Slow Cooker



6QT Slow Cooker



Wax Warmer

Sunvivi®

**Experience the brighter side of life:
Sunvivi, infusing your everyday
with warmth.**

At Sunvivi, we believe in infusing your life with sunshine, not just through our innovative products but also through the joy and convenience they bring. Embrace the brighter side of life with Sunvivi's range of smart home appliances, designed to make every day a little brighter.



Locking Slow Cooker



12-in-1 Cooker

We are developing more...

For purchases and negotiation inquiries,
please feel free to contact us.



707-392-8405



support@sunvivi.com



www.sunvivi.com

IMPORTANT SAFETY PRECAUTIONS

Definitions

The following terminology refers to safety warnings and potential property dangers, indicating the level of risk.



This is the safety alert symbol. It warns of potential dangers that could cause personal injury. Please read all safety warnings associated with this symbol to prevent personal injury or death.

Danger: This indicates a situation of imminent danger that, if not prevented, could lead to severe injury. The use of this term in a warning is limited to extreme situations.

Warning: It indicates a potentially dangerous situation that, if not prevented, could result in serious injuries or death.

Caution: It indicates a potentially dangerous situation that, if not prevented, could result in moderate or minor injury.

Notice: It indicates dangers with no relation to personal injury, such as damage to the product and /or property.

When using this or any other electrical devices, please follow the safety precautions, especially when children are present.

READ ALL THE INSTRUCTIONS BEFORE USE



WARNING: To reduce the risk of fire, electric shock or severe personal injuries:

- This product is not intended for use by children. Keep out of reach of children and pets. If using this product near children, please pay close attention.
- Make sure that the product is disconnected from any electrical outlet source and it has cooled off before assembling, disassembling, moving or cleaning.
- Do not leave the product unattended while in use. Disconnect the product from any power source when not in use.
- Do not immerse the power cord, plug or base of this product in water or any other liquids, nor expose them to such liquids.
- Do not touch any hot surfaces. Use the handles and knobs when operating the product. Use gloves or oven mittens to prevent burns or injuries when removing the lid or handling hot containers.
- Take appropriate measures to prevent burns, fires, personal injury, or damage to property, as this product generates heat and steam while in use.
- Do not put water directly on the base; water and other ingredients

should be solely placed in the ceramic container

- Do not use accessories not recommended or sold by the manufacturer. Accessories, while in use, can overheat. Allow the accessories to cool before moving.
- Allow the accessories to cool before moving.
- **Do not place the product on electrical or hot gas stoves, near them, or near a hot oven or any other hot surfaces.**
- Pay close attention when moving the product if containing food, water, or any other hot liquids.
- Use the product in a well-ventilated area. Maintain at least 4 to 6 inches of space on each side of the product to allow adequate air circulation.
- Keep the product away from curtain, wallpaper, clothing, dishtowel, or other flammable materials.
- Do not plug or unplug the product with damp or wet hands.
- **Stop using the product immediately if the lid or ceramic container is cracked or damaged. Cracks in the container can come into contact with electric cables and pose a safety hazard.**



CAUTION: To reduce the risk of personal injuries

- This product is designed for home use only, not for commercial or industrial purpose with the intent of preparing food for human



consumption; Do not use it outdoors or for any other purposes.

- Keep the inner ceramic container free of foreign substances to prevent malfunction.
- Do not operate the product when empty.
- Do not leave the cord hanging at the edge of the table or counter, where one may trip over it. Do not let the cable touch hot surfaces.
- Do not operate the product if the plug or power cord has cracks or is damaged; if there are exposed cables; if it does not function properly; if it falls on the ground or is damaged; or if the motor encasement has been exposed to water. This product does not have parts that can be repaired by the user, if breaking down. Do not attempt to examine or repair this product on your own. Only a qualified technician can perform repairs. Bring the product to a certified repair center for inspection and repair.

NOTICE: To reduce the risk of damage to the product and/or to the property:

- To disconnect the product from a power source, turn the control knob to the position “OFF” and then unplug directly; do not unplug the power feed.
- Do not force the power feed into connection zone, as the cable may be scraped or damaged.

SPECIAL INSTRUCTIONS

- A short power cord should be provided to reduce the risk of tripping or entangling. Use of an extension cords to operate this product is not recommended, unless necessary:
 - The rated electrical capacity must be at least equal to that of the product.
 - If the product is a three-prong grounded type, such an extension cable should be used.
 - The extension cord should be well-placed so that it is not hanging from a counter or table, where it may be tripped over.

WARNING: This product is equipped with a polarized plug (one prong is wider than the other) to reduce the risk of electric shock. This is a safety setting. The plug can only fit into a polarized outlet in one way. If you can not fit the plug into the outlet, try to reverse it. If the plug still doesn't fit, consult a qualified electrician. Never use the plug with an extension cord, unless it can fit into the cord outlet completely. Do not alter the plug. Do not attempt to circumvent the safety purpose of the polarized plug. Do not attempt to bypass the safety precaution of the polarized plug.



KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

Components



Before First Use

IMPORTANT: Wash the ceramic container and the glass cover in warm soapy water, rinse thoroughly, and dry. Before using this product to cook food, operate it the first time using water only.

WARNING: Do not wash any part of this product in a dishwasher.



1. Set the ceramic container on the base, add two cups of water inside, and cover.

2. Plug the product in 120 volt AC current and set the control knob on “HIGH”. Allow the product to operate for approximately 20 minutes.

NOTE: It is likely that there will be a light smell, but this will disappear promptly.

3. When the time is up, turn the control knob to “OFF” and unplug the product from the power source. Allow the product to cool for about 15 minutes .

4. When the product has cooled off completely, remove the lid and the container from the base, and empty out the water. Rinse and dry.

METHOD OF USE

WARNING:

- Do not use the product to cook entire pieces of raw meat(i.e. roasts, steaks, etc.), whole chicken, whole fish or ground meat. Cook ground meat separately and cut large pieces of meat/poultry/vegetables into small pieces before putting them into the product.
- According to the U.S. Department of Agriculture’s Food Safety and Inspection Service, food product such as meat, fish or poultry must be fully cooked before consumption to prevent food-borne illness. Before consumption, determine the food’s internal temperature with a thermometer(not included). Refer to the the U.S. Department of

Agriculture’s website to obtain information about the regulations on the temperatures of food products.

- Defrost all food before placing it into the product.
1. Add liquids and then food up to two inches below the top of the container and cover.
- CAUTION:** Do not fill the product excessively, nor operate it when empty.
2. Place the product container on the base and plug into 120V current.
 3. Turn the control knob to desired position [LOW, HIGH]
 4. WARM setting is only for keeping already cooked food warm, DO NOT cook on the WARM setting. We do not recommend using the WARM setting for more than 4 hours
 5. When the heating completes, turn the control knob to the position “OFF” and unplug the product from the power source.

WARNING: The product should be unplugged from the power source when not in use or when unattended.

Working hours	Average Temperature in the high position	Average Temperature in the low position
4 hours	82°C-95°C (179°F-203°F)	/
6 hours	90°C-99°C (194°F-210°F)	82°C-95°C (179°F-203°F)
8 hours	/	90°C-99°C (194°F-210°F)

NOTICE: Do not operate this product for more than 8 hours consecutively.

Suggestions:

- To avoid excessive steam when the heating completes, remove the lid

and turn the control knob to the position ‘HIGH’ for 30 or 45 minutes approximately.

- In order to avoid heat loss, place and center the lid on the container and keep it on while in use (except to reduce steam).

Safety and Maintenance

WARNING: The product should be unplugged from the power source when not in use or when unattended.

NOTICE: To avoid product damage, do not put freezing water in the container immediately after use, nor use abrasive cleaners or soak to clean any part of the product.

- Remove the container and the lid from the base and use a mild soap and sponge to clean.
- To clean the base, wipe with a smooth damp cloth.
- Dry all parts completely before storing or reusing.

Electrical Specifications

Voltage	Frequency	Wattage	Amperage
120VAC	60Hz	100W	0.8A

GUARANTEE

If any part malfunctions or is defective, please contact customer service at support@sunvivi.com

MEDIDAS DE PROTECCION IMPORTANTES

Definiciones

Siempre que se usan, los siguientes términos identifican mensajes de seguridad y de posibles daños a la propiedad y designan un nivel de gravedad del riesgo.

 - Este es el símbolo de alerta de seguridad. Le alerta de posibles peligros de lesión personal. Obedezca todos los mensajes de seguridad que acompañen a este símbolo para evitar posibles lesiones o la muerte.

PELIGRO: Indica una situación de peligro inminente que, si no se evita, provocará la muerte o una lesión grave. El uso de esta palabra en una señal se limita a las situaciones más extremas.

ADVERTENCIA: Indica una situación posiblemente peligrosa que, si no se evita, podría provocar la muerte o lesiones graves.

ATENCIÓN: Indica una situación posiblemente peligrosa que, si no se evita, podría provocar una lesión menor o moderada.

AVISO: Se refiere a prácticas no relacionadas con lesiones personales, como daños al producto y/o a la propiedad.

Cuando utilice este o cualquier otro artefacto eléctrico, siempre siga estas precauciones básicas de seguridad, especialmente cuando haya niños presentes.



LEA TODAS LAS INSTRUCCIONES ANTES DE USAR.

 **ADVERTENCIA:** Para reducir el riesgo de incendio, descarga eléctrica o lesiones personales graves:

- Este producto no ha sido diseñado para que lo usen los niños. Mantenga el producto fuera del alcance de niños y mascotas. Cuando se utiliza este producto cerca de los niños, es necesario prestar mucha atención.

- Asegúrese siempre de que el producto esté desenchufado de la toma de corriente y que se haya enfriado antes de ensamblarlo, desensamblarlo, cambiarlo de lugar o limpiarlo.
- No deje el producto sin vigilancia cuando esté en uso. Siempre desenchufe el producto de la toma de corriente cuando no esté en uso.
- No sumerja el cable de alimentación, el enchufe ni la base de este producto en agua u otros líquidos ni los exponga a tales líquidos.
- No toque las superficies calientes. Use las manijas y las perillas cuando esté manipulando el producto. Use mitones o guantes de protección para el horno para evitar quemaduras o lesiones personales al retirar la tapa o manipular recipientes calientes.
- Tome las precauciones apropiadas para prevenir quemaduras, incendios, daños personales o daños a la propiedad dado que este artefacto genera calor y vapor durante el uso.
- No vierta agua directamente en la base; debe verter el agua y otros contenidos únicamente en el contenedor de cerámica.
- No utilice accesorios que el fabricante del producto no recomiende ni venda. Los accesorios, cuando se los suministra, pueden calentarse durante el uso. Permita que los accesorios se enfrien antes de manipularlos.
- No coloque el producto sobre quemadores eléctricos o de gas calientes ni cerca de ellos, ni en un horno caliente u otra superficie caliente.
- Preste extrema atención cuando mueva un artefacto que tenga alimentos, agua u otros líquidos calientes.
- Utilice el producto en un área bien ventilada. Mantenga al menos entre 4 y 6 pulgadas de espacio en todos los lados del producto para permitir una circulación adecuada del aire.
- Mantenga el producto alejado de cortinas, empapelados, ropa, paños de cocina u otros materiales inflamables.
- No enchufe ni desenchufe el producto de la toma de corriente con la mano mojada.
- Suspenda el uso del producto si la tapa o el contenedor de cerámica están agrietados o dañados. Las grietas en el contenedor pueden hacer que entre en contacto con los cables eléctricos y crear un riesgo.



ATENCIÓN: Para reducir el riesgo de lesiones personales:

- Este producto ha sido diseñado exclusivamente para uso residencial, no comercial ni industrial, con el objetivo de preparar alimentos destinados al consumo humano; no lo use al aire libre ni para ningún otro propósito.

- Mantenga la parte inferior del contenedor de cerámica libre de sustancias extrañas para prevenir el mal funcionamiento.
- No haga funcionar el producto cuando está vacío.
- No permita que el cable cuelgue del borde de una mesa o encimera, donde pueda tropezarse o tirar de él. No permita que el cable toque superficies calientes.
- No haga funcionar el producto si el enchufe o el cable de alimentación están dañados o con cortes, si hay cables expuestos, si no funciona correctamente, si se cae o daña, o si la carcasa del motor estuvo expuesta al agua o se cayó en ella. Este producto no tiene piezas que el usuario pueda reparar. No intente examinar ni reparar este producto por sus propios medios. Solamente el personal de servicio calificado debe realizar las reparaciones. Lleve el producto a un taller de reparaciones de artefactos de su preferencia para que lo revisen y reparen.

AVISO: Para reducir el riesgo de daños al producto y/o a la propiedad:

- Para desconectar el producto de una toma de corriente, gire la perilla de control a la posición "OFF" (APAGADO) y luego tire directamente del enchufe; no tire del cable de alimentación.
- No fuerce el cable de alimentación en la zona donde se conecta al producto, ya que dicho cable podría pelarse o dañarse.

INSTRUCCIONES ESPECIALES:

- Se proporciona un cable corto de alimentación eléctrica a fin de reducir el riesgo de enredos o tropiezos con un cable más largo. No se recomienda usar un cable de extensión con este producto, pero si necesita usar uno:
 - La capacidad eléctrica nominal indicada debe ser por lo menos igual a la del producto.
 - Si el producto es del tipo de puesta a tierra de tres clavijas, debe utilizarse un cable de extensión de puesta a tierra de 3 clavijas.
 - El cable de extensión se debe colocar de modo que no cuelgue de una encimera o mesa donde pueda tropezarse o tirar de él.

ADVERTENCIA: Este producto está equipado con un enchufe polarizado (una clavija es más ancha que la otra) para reducir el riesgo de descarga eléctrica. Esta es una característica de seguridad. El enchufe entrará en una toma polarizada de una sola manera. Si no puede introducir el enchufe en la toma de



corriente, intente invertir el enchufe. Si el enchufe tampoco entra de ese modo, consulte a un electricista calificado. Nunca use el enchufe con un cable de extensión, a menos que pueda introducir completamente el enchufe en el cable de extensión. No modifique el enchufe. No intente eludir el objetivo de seguridad del enchufe polarizado.

**GUARDE ESTAS
INSTRUCCIONES COMO
REFERENCIA EN EL FUTURO**

Piezas



Antes de utilizar por primera vez

IMPORTANTE: Lave el contenedor interno de cerámica y la tapa de vidrio en agua tibia y jabonosa, enjuague bien y seque por completo. Antes de utilizar el producto para cocinar alimentos, utilícelo por primera vez con agua solamente.

ADVERTENCIA: No lave ninguna pieza del producto en un lavavajillas.

1. Coloque el contenedor de cerámica en la base, vierta dos tazas de agua en su interior y luego cúbralo con la tapa.
2. Enchufe el producto en una toma de corriente estándar de 120 voltios CA y luego gire la perilla de control a "HIGH" (ALTO). Permita que el producto funcione durante aproximadamente 20 minutos.
NOTA: *Es probable que advierta un ligero olor pero debe desaparecer rápidamente.*
3. Cuando haya transcurrido el tiempo, gire la perilla de control a la posición "OFF" (APAGADO) y luego desenchufe el producto de la toma de corriente. Permita que el producto se enfríe durante aproximadamente 15 minutos.

4. Cuando el producto se ha enfriado por completo, retire la tapa y el contenedor de la base, y luego vierta el agua del contenedor. Enjuague y seque por completo.

Modo de uso

ADVERTENCIA:

- No utilice el producto para cocinar piezas enteras de carne cruda (p. ej. asados, bistecs, etc.), pollos enteros u otras aves, pescado entero o carne molida. Cocine la carne molida de manera separada y corte las piezas o grandes pedazos de carne/ave/vegetales en trozos pequeños antes de agregarlos al producto.
 - Según el Servicio de Inspección y Seguridad de los Alimentos del Departamento de Agricultura de los Estados Unidos (U.S. Department of Agriculture's Food Safety and Inspection Service), los alimentos como la carne, el pescado y las aves deben cocinarse por completo antes de consumirlos para evitar enfermedades transmitidas por alimentos. Antes de consumirlos, determine la temperatura de los alimentos con un termómetro para alimentos (no se incluye). Refiérase al sitio web del Departamento de Agricultura de los Estados Unidos (U.S. Department of Agriculture, USDA) para obtener información sobre las reglas de la temperatura de los alimentos.
 - Siempre descongele todo contenido congelado antes de colocarlo en el producto.
1. Agregue líquidos y después los alimentos hasta dos pulgadas por debajo de la parte superior del contenedor y cúbralo con la tapa.
ATENCIÓN: No llene excesivamente el producto ni lo haga funcionar cuando esté vacío.
 2. Coloque el contenedor en la base y luego enchufe el producto en una toma de corriente estándar de 120 voltios CA.
 3. Gire la perilla de control a la posición deseada (LOW [BAJO], HIGH [ALTO]).
 4. Cuando se haya completado el calentamiento, gire la perilla de control a la posición "OFF" (APAGADO) y luego desenchufe el producto de la toma de corriente.
ADVERTENCIA: Siempre desenchufe el producto de la toma de corriente cuando no esté en uso o cuando lo deje sin vigilancia.

Tiempo de funcionamiento	Temperatura aproximada en la posición HIGH (ALTO)	Temperatura aproximada en la posición LOW (BAJO)
4 horas	82 °C-95 °C(179 °F-203 °F)	/
6 horas	90 °C-99 °C(194 °F-210 °F)	82 °C-95 °C(179 °F-203 °F)
8 horas	/	90 °C-99 °C(194 °F-210 °F)

AVISO: No haga funcionar el producto por más de seis horas consecutivas.

Consejos:

- Para eliminar la humedad excesiva cuando se haya completado el calentamiento, retire la tapa y gire la perilla de control a la posición "HIGH" (ALTO) durante aproximadamente 30 a 45 minutos.
- Para evitar la pérdida de calor, coloque y centre la tapa en el contenedor y no la retire mientras esté en uso (excepto al eliminar el exceso de humedad).

Cuidado y mantenimiento

ADVERTENCIA: Siempre desenchufe el producto y deje que se enfríe antes de limpiarlo o guardarlo.

AVISO: Para evitar dañar el producto, no vierta agua helada en el contenedor de cerámica después de su uso ni utilice almohadillas/limpiadores abrasivos para limpiar cualquier parte del producto.

- Retire el contenedor y la tapa de la base y utilice un jabón suave y una esponja para limpiarlos.
- Para limpiar la base, pase un paño suave y húmedo por su superficie.
- Seque todas las partes completamente antes de guardarlas o utilizarlas otra vez.

Especificaciones eléctricas

Voltaje	Frecuencia	Potencia en vatios	Ampérage
120 VCA	60 Hz	120W	0.8A

GARANTÍA

Si cualquier parte funciona mal o está defectuosa, por favor contacte al servicio de atención al cliente en support@sunvivi.com.

★ Ready to be Sunvivi Product Tester? ★

Your opinion matters! Share your experience with us on Amazon and you could become our Product Tester. Don't miss out on this exciting opportunity to be the FIRST to try out our latest products!

Scan the QR code and explore our website for more information.



LEARN MORE

Sunvivi®



Any Problem? Let Us Know



We're here to help!



707-392-8405



support@sunvivi.com



www.sunvivi.com



@sunviviofficial



Sunvivi®