OVENTE®

# ELECTRIC WARMING TRAY

FW170 SERIES




*Before use, please read this manual thoroughly and save for future reference.*

# ELECTRIC WARMING TRAY

FW170 SERIES

## TABLE OF CONTENTS


IMPORTANT SAFEGUARDS . . . . . 3

PARTS & FEATURES . . . . . 5

USING THE WARMING TRAY . . . . . 6

CARE & MAINTENANCE . . . . . 7

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to prevent risk of fire, electric shock, burns, or other injuries or damages.

- Before connecting the warming tray, check whether the voltage indicated at the bottom corresponds to the local mains voltage.
- DO NOT operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or has been damaged in any manner. If the mains cord is damaged, contact Customer Service on 1-855-926-2626 immediately.
- To protect against electrical hazards, DO NOT immerse the cord, plugs, or the appliance itself in water or other liquid.
- Do not let any water or other liquid enter the warming tray to prevent electric shock.
- DO NOT let the cord hang over the edge of a table or counter, and do not let it touch hot surfaces.
- Regularly check the main cord to see whether it is in a safe condition.
- To avoid circuit overload, do not operate another high-voltage appliance on the same circuit.
- Do not plug in the warming tray or operate the control panel with wet hands.
- Warming tray should always be used on a dry and level surface.
- Do not place the warming tray against a wall or against other appliances. Leave at least a 4-inch space on all sides of the warming tray (including above it).
- Do not place the warming tray on or near a gas oven or electric burner, or combustible materials, such as a tablecloth or curtains.
- Do not touch hot surfaces while the warming tray is operating, as it can become very hot.
- This warming tray is not designed for heating cold or frozen food.
- Close supervision is necessary when the warming tray is used near children.

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to prevent risk of fire, electric shock, burns, or other injuries or damages.

- This warming tray is not intended to be used by persons (including children) with reduced physical, sensory and mental capabilities. This warming tray is not for persons with a lack of experience and knowledge, unless they have been given supervision or instructions concerning the use of the warming tray by a person responsible for their safety.
- Unplug from outlet when not in use and before cleaning. Allow cooling before putting on or taking off parts.
- To avoid electrical shocks, do not clean the warming tray with metal scouring pads.
- DO NOT touch hot surfaces. Use handles or knobs.
- DO NOT move the warming tray when it is still hot.
- DO NOT leave the warming tray unattended while in use.
- The warming tray is not intended to be operated with an external timer or separate remote control system.
- Do not use outdoors or for purposes other than intended use.
- CAUTION: This warming tray generates heat during use. Proper precautions must be taken to prevent the risk of burns, fires, or other damage to property caused by touching the parts while in use or during cooling.
- WARNING: Only use the warming tray on a flat and heat-resistant surface.

POLARIZED PLUG

This warming tray has a polarized plug, which means that the plug has a small blade for the hot wire and a wide blade for the neutral wire. To reduce the risk of electric shock, only insert the plug into the outlet slots in one direction – wide blade to wide slot and narrow blade to narrow slot. If the plug does not fit fully in the outlet, reverse the plug. If it still doesn't fit, contact a qualified electrician. Do not modify the plug in.

# PARTS & FEATURES

**IDEAL FOR ALL COOKWARE**

Ceramic, metal, glass and aluminum tray.



**COMPACT & PORTABLE**

**Ultra-thin (17 x 9.6-inch) space-saving tray lets you warm different foods together and is easy to store**

**COOL-TOUCH HANDLES**

**Protect hands from burns and secure grip for safe transport**

**HIGH-QUALITY STAINLESS STEEL**

**Made of materials that make it easy to remove grease and stains for convenient cleaning**




**LED LIGHT**

**Allows you to see when the tray is in use**

**ADJUSTABLE TEMPERATURE KNOB**

**Allows you to set your desired warming level**

# USING THE WARMING TRAY

- Note: During the first few uses, a slight odor may be noticeable. This is due to manufacturing residue burning away.
- WARNING: This warming tray gets hot during use, please exercise extreme caution.

1. Remove all packaging materials.
2. Place the warming tray on a flat, stable, and heat-resistant surface.
3. Plug the warming tray into an electric outlet. The LED indicator light will turn red to indicate that it is switched on. The light will turn off when the warming tray has reached the desired warming level.
4. Pre-heat the warming tray for 10 minutes.
5. Place the dish with food on top of the warming tray.
6. When you have finished using the warming tray, unplug from the mains power supply and allow to cool for approximately 90 minutes before cleaning or storing.

## TIPS & TRICKS

- The warming surface is ideal for any oven-safe dish, such as a casserole dish or baking sheet.
- Food should never be placed directly on the warming surface. Place the food in an oven-safe container before placing it on top of the tray.
- You can keep your main course warm while preparing the table or other dishes.
- The warming tray can be used to present and serve warm desserts.
- HIGH settings are used when warming prepared foods to maintain proper safe temperature; LOW settings are ideal for warming baked goods as well as keeping melted chocolate at the proper consistency.

# CARE & MAINTENANCE

- Before cleaning the warming tray, check whether it is unplugged and has cooled down completely.
- Do not immerse the warming tray in water.
- The safe way to clean the warming tray is to use a soft, damp cloth with mild detergent.
- Do not use scouring pads as they can damage the warming tray.
- Make sure that water does not enter the frame of the tray.

### STORAGE

- Let the warming tray cool down before storing, and make sure to store it in a cool, dry place.
- Do not put heavy objects on top of the tray, because they can damage it.
- Before use, make sure that no foreign objects (thread, aluminum foil, etc.) are stuck on the plug's peg as they may cause a short circuit.

# ELECTRICAL REQUIREMENTS

Voltage: 120V

Hertz: 60Hz

Wattage: 200W




# OVENTE WARRANTY

## LIMITED ONE (1) YEAR WARRANTY

At Ovente, we aim to make your life easier by producing top-quality housewares, designed with you in mind. We have pledged to uphold all our offerings to the highest standards, and we back all our food warmers with a one-(1) year warranty from the date of purchase from an authorized retailer. This warranty covers defects in workmanship and materials. It does not include damage due to abuse, misuse, commercial use, accidents or natural wear and tear. In case of replacement, shipping and handling fees may apply.

## LIMITATIONS

The warranty stated above is the only warranty applicable to this product. Other expressed or implied warranties are hereby disclaimed. No verbal or written information given by the Manufacturer, its agents or employees shall create a guarantee or in any way increase the scope and duration of this warranty. Repair or replacement as provided under this warranty is the exclusive remedy of the consumer. The manufacturer shall not be liable for incidental or consequential damages resulting from the use of this product. Any implied warranty of merchantability or fitness for a particular purpose on this product is limited to the applicable warranty period set forth above except to the extent prohibited by law. Proof of purchase may be required to validate the order. Promotional items may not be covered under any warranty. Consumer rights may vary from state to state.

For product support email **support@ovente.com** or call **1-855-926-2626.**
Visit us at ovente.com