Assembly Instructions

Caution: You must read these Assembly Instructions before you proceed


Care & Maintenance



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



- Not for commercial use. For residential use only.




- Stains may be removed with mild soap solution and damp cloth.



- Dust and pick-up spills using a clean, non-colored, lint- free cloth.



Please look into the Seat Panel for hardware packs.

Boho Dining Chair





Caution: This Chair is NOT a TOY.
Keep your child/children at bay during the assembly process.

Part List

Label	Picture	Description	Qty
Ⓐ		Seat	2
Ⓑ		Chair legs	2


Hardware

No.	Picture	Description	Qty
①		Screw (M6x20mm)	08
②		Washer	08
③		Bolt cap	08
④		Allen Wrench	02


Assembly Preparation


Before Beginning Assembly:

Ⓐx2



Ⓑx2






- Read instructions, cover to cover-
- Do not assemble on flooring or carpet-
- Assemble on a clean non-marring surface (packing foam)-
- Save all packaging until finished-


Assembly Steps


Overview




This Chair has multiple parts and may require up to 20 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1 (x2)






Unpack and place all parts on a clean, non-marring surface.
Note: The front legs are high and the back ones are low.



Place the Seat (A) facedown onto a clean, non-marring surface.
Align the Seat (A) to the Chair Legs(B) as shown above.
Attach the Seat (A) to the Chair Legs(B) using Bolts(①), Washers(②) and the Allen Key(④).
Do not fully tighten the Bolts

Step 2 (x2)



Stand the chair up.

Exert pressure floorwards, onto the chair with both your hands.

This pressure will help the legs and chair top reach full alignment status.

Check for wobbles on a LEVEL surface.


If no wobbles are found, proceed to tighten the bolts in a sequential manner until evenly secured.

When tightening the bolts, tighten sequentially.

Do not tighten any bolt fully and then move on towards the next one.

If there are still wobbles, loosen the bolts and execute the same above process.

If the chair is not stable, it could lead to damage of the product.



Turn over the chair.
Cover the Bolts(①) using Caps(③).
Your Chair is ready for use.
This Chair can only be used on a flat and level surface