

INSTALLATION
Product Manual




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product.follow the manual thoroughly and keep it for further reference.




AVOID SCRATCHES!

In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.


IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.



For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag.For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.




Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.












When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 50	B x 2	C x 52	D x 12	E x 8
				
∅6 x 40 mm	∅6 x 40 mm	∅15 mm	∅8 x 30 mm	

F x 4	G x 2	H x 22	J x 92	K x 1
				
M5 x 35 mm			M3.5 x 14 mm	

M x 2	N x 4	P x 4	Q x 4	R x 12
				

S x 1	T x 6	U x 1
		



⚠WARNING






Children have died from furniture tipover.To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand,climb or hang on drawers,doors,or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


This is a permanent label.
Do not remove!




ASSEMBLED BY 2 ADULTS


1


A x 10



∅6 x 40 mm








Screw eccentric rod (A) onto plates 1 and 13.


2

C x 4



∅15 x 10 mm






Connect plates 9 and 10 to plate 1, then insert the eccentric wheel (C) and turn it clockwise to tighten.


3


C x 6




∅15 x 10 mm








Connect plates 1, 9, 10, and 11 to plate 13, then insert the eccentric wheel (C) and turn it clockwise to tighten.




4

Insert panel 18 along the available slots.





5


A x 6



∅6 x 40 mm








Screw eccentric rod (A) onto plate 14.


6

C x 6




∅15 x 10 mm







Connect plates 1, 9, 10, and 11 to plate 14, then insert the eccentric wheel (C) and turn it clockwise to tighten.



7


J x 8	P x 2	
 M3.5 x 14 mm		

Secure corner bracket (P) to plates 1, 13, and 14 using screw (J).




8

Insert panel 18 along the available slots.





9


A x 6



∅6 x 40 mm








Screw eccentric rod (A) onto plate 16.


10

C x 4



∅15 x 10 mm






Connect plate 11 to plate 16, then insert the eccentric wheel (C) and turn it clockwise to tighten.

11

Insert panel 19 along the available slots.





12


C x 2



∅15 x 10 mm









Connect plate 2 to plate 16, then insert the eccentric wheel (C) and turn it clockwise to tighten.


13


A x 6



∅6 x 40 mm








Screw eccentric rod (A) onto plate 15.


14

C x 6




∅15 x 10 mm






Connect plates 2 and 11 to plate 15, then insert the eccentric wheel (C) and turn it clockwise to tighten.




15




Insert plates 19 and 20 along the available slots.

Note: The orientation of panel 20.





16

D x 4



∅8 x 30 mm







Connect plate 12 to plates 15 and 16 using wooden dowel (D).


17

F x 4



M5 x 35 mm







Secure plate 12 to plates 15 and 16 using screw (F).


18


A x 8




∅6 x 40 mm









Flip 180°




Screw eccentric rod (A) onto **both sides of** plate 4.

19


C x 4	D x 4	
		
∅15 x 10 mm	∅8 x 30 mm	




Connect plate 4 to plates 15 and 16 using wooden dowel (D), then insert the eccentric wheel (C) and turn it clockwise to tighten.
Note: The orientation of plate 4.



20


C x 4	D x 4	
		
∅15 x 10 mm	∅8 x 30 mm	




Connect plate 4 to plates 13 and 14 using wooden dowel (D), then insert the eccentric wheel (C) and turn it clockwise to tighten.

Note: This installation step requires two or more adults.


21


G x 2	J x 8	P x 2	
	 M3.5 x 14 mm		




Secure anti-tip device (G) to plate 12.
Secure corner bracket (P) to plates 4, 13, and 14 using screw (J).

22



E x 8	R x 12	
		




Install layer pin (E) onto plates 15 and 16, and place plate 3 on pins.
Apply the masking tape (R) to the exposed eccentric wheel holes.



23

H x 22	J x 38	Q x 4	
			
∅3.5 x 14 mm	M3.5 x 14 mm		




Insert clip (H) into the slots on the backplates and secure them using using screw (J).


Secures iron plate (Q) to plates 13, 14, 15, and 16 using screw (J).


24

A x 10



∅6 x 40 mm






Screw eccentric rod (A) onto plates 5, 6, and 7.


25

C x 2




∅15 x 10 mm





Connect plate 5 to plate 8, then insert the eccentric wheel (C) and turn it clockwise to tighten.





26

C x 4




∅15 x 10 mm





Connect plates 5 and 8 to plate 7, then insert the eccentric wheel (C) and turn it clockwise to tighten.





27

C x 4




∅15 x 10 mm









Connect plates 5 and 8 to plate 6, then insert the eccentric wheel (C) and turn it clockwise to tighten.





28

A x 4	B x 2	
		
∅6 x 40 mm	∅6 x 40 mm	






Screw eccentric rod (A) and (B) onto plates 21.







29


J x 12	T x 6	
 M3.5 x 14 mm		



Secure hinge (T) to plates 17 and 21 using screw (J).

30

J x 24	N x 4	M x 2	
 M3.5 x 14 mm			



Secure plates 17 and 21 to plates 16 and 1, respectively, via the hinges using screw (J). **Note: When installing plate 21, use a foam padding under it.**


Secure handle (M) to plates 17 and 21 using screw (N).


31

C x 6




∅15 x 10 mm






Connect plates 6, 7, and 8 to plate 21, then insert the eccentric wheel (C) and turn it clockwise to tighten.




32


G x 2









1.




2.



3.



4.




Install the anti-tip device as shown.

33

U x 1







Assemble the components as shown.

34

U x 1









Secure part (U) to plates 14 and 21.

35


K x 1







Place part (K) into the assembly unit.


36








If there is misalignment after you install,
adjust the screw to the best condition














WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.

- The product must be used in accordance with the instructions provided. For health reasons.

- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.

- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.

- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOU ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
  In all circumstances please save all packaging material and paperwork for the order.
  Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.