WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.



NOTE:

This brochure contains IMPORTANT safty info. Please read and keep for future reference.

MAINTAINANCE
AND WARNING

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- To obtain the longest lifespan of your outdoor products, avoid exposure to rain or snow, and direct sunshine for long time. Whenever possible cover the product and/or place under patio or awnings.
- Not for commercial use, For residential use only.

Weight Limitation

220LBS

PARTS
LIST

Ax1

Bx1



Cx1

Dx1

Ex1

Estimated Duration Of Assembly

5-10 MINUTES

HARDWARE
LIST

Fx4



Gx1

SPARE

Fx1

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.

ASSEMBLY
INSTRUCTIONS



STEP 1:Insert gas lift E through decoration ring C to center hole of metal base D.



STEP 2:Place the chair back A on a clean padded surface, Use bolt F, allen key G to attach mechanism B to bottom of the seat A.



STEP 3:Carefully align bottom hole of mechanism with top pin of gas lift then push all the way down to secure.



STEP 4 : Assembly completed.