
TV STAND

USER MANUAL



SAVE THESE INSTRUCTIONS FOR FUTURE USE

PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!!
We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Before Installation

Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly,and follow the assembly steps to assemble your newly purchased product correctly and efficently.

Cam Lock Assembly Instructions





Diagram A



Insert Cam Bolt into hole as shown in diagram A.





Diagram B



Make sure not to insert the Cam Bolt:
Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.







Diagram C




Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.




Connect the panels together.



Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.




To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver.
**Do not use an automatic screwdriver as it may bend or break if too much power is imposed.*



Ax20	Bx20	Cx24 M6x30	Dx12 M4x40	Ex8 M4x30	Fx16 M3x12
Gx18 M3x14	Hx36 M4x14	Ix32 M4x12	Jx8	Kx8 M6x18	Lx1
Mx6	Nx2 M4x35	Ox8 M4x18	Px3	Qx2	Rx4
Sx4	Tx20	Ux16	Vx2	Yx1	CRx2 300mm
CLx2 300mm	DRx2 300mm	DLx2 300mm	Xx2		

STEP 1


Ax12




Gx2



Lx1





STEP 2


Fx8





CLx2



CRx2







STEP 3

Bx6




Dx6




Tx6





STEP 4




STEP 5

Dx6



Cx6





STEP 6

Bx6




Dx6





M6x30


Tx6












STEP 7




STEP 8

Dx6




Cx6





STEP 9


Kx4





Tx8



Vx2









STEP 10

Jx8



Ix32






STEP 11

Sx4




Rx4






STEP 12

Yx1






STEP 13


Hx12




Ox4



Mx16



Px1




Qx2




STEP 14

Hx24








(For detailed hinge adjustment instructions, please refer to the last page.)

STEP 15

Ax8




Ox4



Px2






x2

STEP 16


Ex8





x2

STEP 17





x2


STEP 18

Bx8











x2

STEP 19

DRx2




DLx2




Fx8





x2

STEP 20



STEP 21

Ux16




Xx2




Gx16




Ix2







STEP 22

Nx2






HINGE ADJUSTMENTS




1 Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from the side of the cabinet
anticlockwise to move the door closer to the side of the cabinet



2 4 Height adjustment

While supporting the weight of the door, turn the screws
clockwise to move the door up
anticlockwise to move the door down



3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw
clockwise to decrease the gap between the door and the cabinet
anticlockwise to increase the gap between the door and the cabinet

