286x210mm

143mm

143mm

210mm

Assembly&Instruction Manual

INSTRUCTION MANUAL
INSTANT POP UP CANOPY WITH SIDEWALLS

English ——— 01-11
Deutsch ——— 12-23
Français ——— 24-35

EN-01

PRECAUTIONS

1. Please unpack the product with care and do not scratch it with sharp objects. Remove all the packaging.
2. Take out the tent from package box carefully, and put it on the ground. Check if the parts are complete.
3. Check if the screws are fastened before using the tent.
4. For any bending or deformation of the tent bracket, also please contact customer service for repairing. Make sure that it is not put before maintenance.
5. It is suggested to assemble the tent by 2-3 adults to avoid damage.
Do not try to assemble the tent alone, to avoid any damage.
6. Do not step on the tent roof, avoid heavy pressure or logs. Tents will be damaged if they are not properly stored or used.
7. Avoid rusting and fingers by jamming when assembling or folding the tent.
8. Pay special attention to wind prevention when using. Please fasten the guy ropes to the ground with pegs. The tent may become inconvenient to the first rules, which causes damage to the tent. Please do not use the tent in order to prevent damage caused by wind.
9. Please keep the tent zippers in parallel, the big plane of two adjacent tents should be bundled through ribbon or nylon rope to avoid damage to the tent caused by the zipper being.
10. Do not bend big pipes of two tents with adhesive tape, otherwise, the residues of adhesive tape may block the internal diameter of the tent pipe.

EN-02

10. Fix the tent via windproof rope. Fix one end of windproof rope on the tent, connect the other end to the stake, and insert the stake into the ground at an angle of 45 degrees outward. When tent is placed on the solid surface, tie the 4 foot pipes with windproof rope, and fix the rope with the stake.
11. Do not hang heavy objects on the tent or climb to the roof. Please do not put the tent under the eaves to avoid the water from the roof.
12. When the tent is used for a long period, remove dust on it via warm and hot soapy water, however, do not attempt to use chemical detergents, bleaches or petrol based products for cleaning, do not store the tent immediately, but put it in dry and ventilated place to avoid mildew and damage of tent.
13. Do not use a candle, match or open flame in any form inside the tent, as this will cause a fire hazard.
14. **Do not assemble the tent in rainy tent can be damaged, and the tent should be dried before folding and storage.**
Please contact the manufacturers if the tent is wrinkled and moldy and has incompatibilities.
15. Do not bend big pipes of two tents with adhesive tape, otherwise, the residues of adhesive tape may block the internal diameter of the tent pipe.

EN-03

PACKING INCLUDES

EN-04

OPENING THE CANOPY FRAME

ATTACHING THE CANOPY TOP

EN-05

Place one hand on the upper frame and use the other hand to push the upper crossbars up until it clicks into the pole.

EN-06

ADJUSTING THE CANOPY HEIGHT

Push the button on each leg and raise or lower to adjust the canopy height.

EN-07

ATTACH THE SIDEWALL

EN-08

SECURING THE CANOPY IN PLACE

Pull the guy ropes out from the end of each canopy leg. Secure each rope from the each leg to a proper distance and secure all sides to the ground. Fix the guy ropes with the pegs to the ground. Please install the tent on the proper location. Fix up the sandbags and fix them to the feet.

EN-09

TAKE DOWN THE CANOPY

EN-10

EN-11

WHEEL INSTALLATION PROCEDURE

EN-12

VORSICHTSMASSNAHMEN

1. Bitte packen Sie das Produkt vorsichtig aus und kratzen Sie es nicht mit scharfen Gegenständen. Entfernen Sie die Verpackung.
2. Nehmen Sie das Zelt vorsichtig aus der Verpackung und legen Sie es auf eine trockene Stelle. Prüfen Sie vorsichtig, ob die Teile vollständig sind.
3. Prüfen Sie, ob die Schrauben der Zelt Stangen fest angeschraubt sind, bevor Sie das Zelt benutzen.
4. Wenn sich die Zeltstangenhalterung verbiegt oder verformt, wenden Sie sich bitte an den Kundendienst zur Reparatur. Vergewissern Sie sich, dass der Fehler behoben ist, bevor Sie das Zelt wieder benutzen.
5. Es wird empfohlen, das Zelt von 2-3 Erwachsenen aufbauen zu lassen, um Schäden zu vermeiden.
Versuchen Sie nicht, das Zelt allein aufzubauen, um Schäden zu vermeiden. Das Zelt sollte trocken sein, bevor es zum Zusammenklappen und Lagern kommt.
Bitte wenden Sie sich an den Hersteller, wenn das Zelt schimmelig ist und Inkompatibilitäten aufweist.
6. Vermeiden Sie es, sich beim Auf- und Abbau die Finger einzuklemmen oder zu verletzen.
7. Achten Sie besonders auf den Windschutz, wenn Sie ein einziehes Zelt verwenden. Bitte befestigen Sie die Abspannseile mit Heringen am Boden. Das Zelt kann durch ungünstig herumliegendes werden. Bitte beachten, dass das Zelt nicht durch Wind beschädigt wird, um Schäden durch Wind zu vermeiden.
8. Bitte achten Sie auf Windschutz, wenn Sie ein einziehes Zelt verwenden. Bitte befestigen Sie die Abspannseile mit Heringen am Boden. Das Zelt kann durch ungünstig herumliegendes werden. Bitte beachten, dass das Zelt nicht durch Wind beschädigt wird, um Schäden durch Wind zu vermeiden.

DE-13

TAKE DOWN THE CANOPY

DE-14

DE-15

DIE VERPACKUNG UMFASST

DE-16

ÖFFNEN DES RAHMENS DER ÜBERDACHUNG

ANBRINGEN DES DACHABDECKUNG

DE-17

EINSTELLEN DER HÖHE DES ÜBERDACHUNG

DE-18

DE-19

DE-20

DE-21

ABBAU DES ÜBERDACHUNG

DE-22

DE-23

Verfahren zum Einbau der Räder

VORSICHTSMASSNAHMEN

1. Déballer le produit avec précaution et ne pas le rayer avec des objets pointus pour éviter d'endommager l'aspect de la tente.
2. Sortez la tente de l'emballage avec précaution et déposez-la sur un endroit propre. Vérifiez si les pièces du sont complètes.
3. Vérifiez si les vis sont bien serrées avant d'utiliser la tente.
4. Si la tente est pliée ou déformée, veuillez immédiatement contacter le service après-vente pour réparation. Assurez-vous que l'utilisation est bien réparée avant de l'utiliser.
5. Il est conseillé d'assembler la tente par 2 ou 3 adultes pour éviter tout endommagement.
N'essayez pas de monter la tente seul, afin d'éviter toute pression inutile sur les jambes. pression inutile sur les jambes. Les tentes seront endommagées si elles ne sont pas dépliées ou rangées correctement.

FR-24

DE-24

DE-25

DE-26

DE-27

L'EMBALLAGE COMPREND

DE-28

OUVERTURE DU CADRE DE L'AUVENT

FIXATION DU TOIT DE L'AUVENT

DE-29

FR-28

RÉGLAGE DE LA HAUTEUR DE L'ÉCRAN

FR-29

FR-30

DÉMONTER LA CANOPÉE

FR-33

FR-34

FR-35

Procédure d'installation des roues

END