
Wardrobe



RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

•If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

•If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please consult our FAQ section as there maybe a simple solution to the issue.

DAMAGED ITEMS

•If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.

•In all circumstances, please save all packaging material and paperwork for the order.

•Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the retailer, you jeopardize your chances of making a claim, and you may not receive a credit for the return.

WARRANTY

WARRANTY CLAIMS

•There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.

•The product must be used in accordance with the instructions provided. For health reasons.

•For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

•Failure to follow the furniture instructions will invalidate the warranty. Attention please.
•Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

•Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.

•After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

•Sheet parts: 1 month from the date of purchase.

•Electrical parts: 1 month from the date of purchase.

IMPORTANT INFORMATION!

•please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.

AVOID SCRATCHES!

•In order to avoid scratching this furnuture should be assembled on a soft layer-could be a rug.

IMPROVE EFFICIENCY !

•Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.

IMPORTANT !


•It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly,and once every 3 months - in order to assure stability through-out the lifespan of the product.


•For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

•Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.

ANTI-TOPPLE WARNING !

Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.







SIIdes Must be Separated Before Assembly.
After Separated,Set Aside Until Needed for Assembly.


Las diapositivas debensepararse antes del montaje.
Despu! s delaseparadi$n,d! jelo a un lado hasta que sea necesario.

Les glissi&res doivent etres! par! es avant tassemblage.
Apr&s las! paration,mettez dec(t! jusqu'au moment deiassemblage.




Step 1: Extend sllde
Extender la dapositiva
Extendre la dapositive






Step 3: RemoveRunner
Quitar el corredor
Enlever le coureur

Step 2: Push Lever Up
Empujar hacia arriba
Lewer le levir





Installation Guide

Exploded Views





Please prepare the following tools








When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 48	B x 48	C x 12	D x 1	E x 24
				
Ø6 x 39mm	Ø15 x 10mm	Ø6 x 20mm	M4	Ø4 x 30mm

F x 28	H x 48	I x 3	J x 3	K x 2
				
Ø3.5 x 16mm	Ø3.5 x 14mm	Ø3.5 x 18mm		


M x 2	N x 4	O x 2	P x6	V x 3
				
Ø55 x 20mm	Ø3.5 x 22mm		40mm	300mm

Troubleshoot


Product Category	Fault	Cause Analysis	Handing Method
Wood furniture	Door opening is not flexible	The furniture is not leveled	Use items to level the furniture
		The door hinges should be adjusted properly.	Adjust door hinges and apply lubricating oil.
	Inflexible opening of drawer	Overload or deformation	Reduce weight,adjust guide rails, lubricate
	Loose component connection	Loose hinges or screws	The poke part should be coated with an appropriate amount of 502 glue, then re-install or tighten the screws.
	Minor scratches	friction with hard o sharp objects	Use a brush to apply similar pigment ink along wood grain to the scratches, then wipe off the excess.
	Corrosive stains	Accidentally stained with chemical solvents such as nail polish, nail polish remover, ect.	Wipe them with a dry cotton cloth immediately

Possible Issues During Assembly:

- The two boards can't be aligned at he same level.




- Holes on the bards and poles are not aligned, so screws can't be installed.



Recommended Solution:

- Please sightly loosen all screws and adjust the bards. Because the diameter of the holes on the pipes 23 mm lager than that of bots, the position of the boards can be adjusted.




- If it is still doesn't work after adjustment, please contact us for more solutions.


1


Ax6



Ø6x39mm









2


Bx6




Ø15x10mm








3


Ax18	Hx18	Vx3
		
Ø6x39mm	Ø3.5x14mm	300mm




4

Bx7


Ø15x10mm





Ensure all panel grooves are perfectly aligned before assembly.

5





6


Bx2




Ø15x10mm







7





8


Bx2




Ø15x10mm










Ensure all panel grooves are perfectly aligned before assembly.


9

Bx7



Ø15x10mm







10

Ax8



Ø6x39mm







11

Bx8




Ø15x10mm





When installing Panel 3, gently tap it to ensure proper alignment and smooth installation.





12


Ax6



Ø6x39mm









13

Ax4	Fx4	Mx2
		
Ø6x39mm	Ø3.5x16mm	Ø55x20mm








14

Bx3


Ø15x10mm







15





Ensure all panel grooves are perfectly aligned before assembly.


16

Bx2











Ensure all panel grooves are perfectly aligned before assembly.

17






Ensure all panel grooves are perfectly aligned before assembly.


18


Bx5



Ø15x10mm









19


Ax6



Ø6x39mm









20

Bx6



Ø15x10mm






When installing Panel 1, gently tap it to ensure proper alignment and smooth installation.


21

Ex24




Ø4x30mm







22


Cx12	Dx1	Ix3	Jx3
			
Ø6x20mm	M4	Ø3.5x18mm	







23

Hx18	Vx3
	
Ø3.5x14mm	300mm







24



25


Hx12	Px6
	
Ø3.5x14mm	40mm






26

Fx12	Kx1	Nx2
		
Ø3.5x16mm		Ø3.5x22mm




First, use one screw for alignment and adjustment, then tighten the others once properly positioned.




27


Fx12	Kx1	Nx2
		
Ø3.5x16mm		Ø3.5x22mm



First, use one screw for alignment and adjustment, then tighten the others once properly positioned.





28




29

Ox2








Instalationinstructions

1. Mark the distance of the bracket on the wall with a pencil.
2.Drill holes at the markers with a drill.
3.Insect the expansion screws into the holes.
4.Connect the bracket to the wall with screws.
5. Place the furniture against the wall and align the brackets vertically.
6.Secure the brackets to the top of the closet using the short screws provided.


Door Panel Adjustment Instruction



Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.


Adjustment range: 4mm



Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm




Up-Down Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm


Door Panel Adjustment Instruction

Common Door Panel Issues:





Door panel is not straight

Adjust the door hinges




Finished







The gap between door panels is too large

Adjust the door hinges




Finished







The door panels are not coplanar

Adjust the door hinges



Finished





The two door panels are not at the same height

Adjust the door hinges

Finished